

Quick Installation Guide

300Mbps Wireless ADSL2/2+ Broadband Router With USB Port

DG-BG4300NU



Copyright:

Copyright 2016 by Digisol Systems Ltd.All rights reserved.
Company has an on-going policy of upgrading its products and it may be possible that information in this document is not up-to-date.
Please check with your local distributors for the latest information.
No part of this document can be copied or reproduced in any form without written consent from the company.

Trademarks:

 $DIGISOL^{TM}$ is a trademark of Digisol Systems Ltd. All other trademarks are the property of the respective manufacturers.

Package Contents

The following items should be present in your package:

- DG-BG4300NUADSL 2/2+ Broadband Router
- POTS splitter
- AC power adapter
- · Ouick Installation Guide
- · Installation Guide CD(includes user manual, QIG & utility)
- Patch cord (1 No.)
- RJ-11 cables (2 Nos.)

Make sure that the package contains above items. If any of the listed items is damaged or missing, please contact your retailer immediately.

Product Overview

Thank you for purchasing DG-BG4300NU 300Mbps Wireless ADSL2/2+ Broadband Router with USB port! This router is the best choice for Small office / Home office users, all computers and network devices can share a single Internet connection at high speed. Easy Installation wizard provided with this router is designed to setup an Internet connection in a very short time by accessing the web configuration of the router. With its wireless speed up to 300Mbps users can experience uninterrupted Internet and multimedia access.

Product Features

- High Internet Access throughput. Downstream up to 24 Mbps and Upstream up to 1 Mbps.
- · Wireless speed up to 300Mbps.
- · Robust WLAN Security.
- Supports URI blocking & Firewall.
- Dedicated WPS and WLAN push button.
- Dynamic DNS and VPN Pass through support.
- USB2.0 Port for 3G Dongle & Mass Storage.
- Allows multiple users to share a single ADSL internet connection.
- Access private LAN servers from the Internet.
- Four wired LAN ports (10/100M) and one WAN port (RJ-11).
- . Works with IEEE 802.11b/g/n wireless LAN devices.
- Supports IPv6.
- · Supports DHCP (Server/Client) for easy IP-address setup.

System Requirements

The following system requirements are recommended:

- Notebook or desktop PC with network adapter (wired/WLAN)
- Windows 98/Me/2000/XP/Vista
- Web browser
- AC power socket (100 240 V, 50/60Hz)

Top Panel

Below shown is the Top view of the product.



Below shown are the LED description of the product.

| LEDs | Color | Status | Description | | |
|----------|-------|----------|--|--|--|
| Power | Red | On | Device is initializing or initialization has failed. | | |
| | | Off | Power is off. | | |
| | Green | On | Power is on. | | |
| DSL | Green | On | Physical link is up | | |
| | | Blinking | ADSL handshaking process is on or ADSL line unplugged. | | |
| Internet | Green | On | Internet connection is established. | | |
| | | Blinking | Data is being transmitted or received. | | |
| | | Off | Device is not connected to internet. | | |
| | Red | On | PPPoE/PPPoA username-password not set | | |
| | | | or wrong. | | |
| LAN | Green | On | PC is connected to the LAN port | | |
| 1/2/3/4 | | Off | PC is unplugged/not connected. | | |
| USB | Green | On | USB device is plugged. | | |
| USB | Cieen | Off | USB device is not plugged. | | |
| | Green | On | Wireless is enabled. | | |
| WLAN | | Blinking | Data is being transmitted or received. | | |
| | | Off | Wireless is not enabled. | | |
| WPS | Green | Blinking | WPS negotiation is enabled waiting for the | | |
| | | | clients. | | |
| WPS | | Off | WPS negotiation is not enabled on the | | |
| | | | device. | | |

Rear View

Below shown is the rear view of the product.




The following table describes the interfaces of the device.

| Item | Description | | | |
|------------|--|--|--|--|
| Antennas | Two 5dBi fixed diplole antennas. | | | |
| DSL | RJ-11 interface, for connecting to the ADSL interface or a splitter using a telephone cable. | | | |
| LAN4/3/2/1 | RJ-45 interface, for connecting to the Ethernet interface of a computer or the Ethernet devices through an Ethernet cable/LAN Cable. | | | |
| Power | Power interface, for connecting to the power adapter. | | | |
| ON/OFF | Power switch, to power on or power off the device. | | | |

Software Installation

 Insert the Setup CD into your CD-ROM drive of notebook/desktop computer.



 Explore the CD and execute the "India_autorun.EXE" file. Screen given below will be displayed. Click 'Start' to continue.




Connect the ADSL line and the phone line to the router. Click 'Next'.



 Connect the power adapter to the AC Mains and the other end to the power interface on the router. Push the power button on the router to power up the device. Click 'Next'.



 Connect the Ethernet interface on the router to the LAN card on the computer using the Ethernet cable. Click 'Next'.



 After powering up the router, verify the status of the LED indicators on the front panel of the router. Click 'Next'.



Below as shown please select the "WAN Mode" type.
 Suppose you select "ADSL and 3G" option to setup 3G failover click "Next"



Please select your 'Country' and ADSL service provider. VPI and VCI values will auto fill.



Select the network protocol for WAN interface. Click 'Next'.



 All the utility installation steps till here are the common steps to be followed for the modes.

Following are the steps for configuring PPPoE connection: Enter the username and password provided by your ISP. Click 'Next'.



Configure the 3G Dialup parameters and click "Next"



· Configure a wireless name (SSID) for your router. Click 'Next'.



· Configure the wireless security. Click 'Next'.




• The next screen is a summary of the wireless settings of the router.



• Click on 'Next', the following screen will appear.



 Once the connection is established, the router connection status will appear.



Bridging Mode

• To configure the router in the bridge mode select "Bridging" option. Click 'Next'



• Configure a wireless name (SSID) for your router. Click 'Next'.



. Configure the wireless security.



Click on 'Next' the following screen will appear.



 Click on 'Finish' to complete the configuration of the router in Bridge mode.

The router installation is now complete

Wizard Installation

- To access the web configuration of the router, assign a static IP address to your notebook/desktop computer in the subnet 192.168.1.X with the subnet mask 255.255.255.0 and gateway as 192.168.1.1. For example, assign the IP address 192.168.1.10.
- Open a web browser and enter "http://192.168.1.1" in the address bar, and press 'Enter'. A login screen will appear, assign username as "admin" and password as "admin". Press 'Log In'.



• Once you log in the following screen will appear.



FAQ

Following are the solutions to problems that may occur during the installation and operation of the DIGISOL DG-BG4300NU Wireless Broadband Router

- 1. Cannot login into the router.
 - Verify whether username and password you entered is correct.
 - If you have forgotten the password, then reset the router using reset button available on the rear side of the router.
 - Please keep reset button pressed till the router reboots to reset to factory default settings. Now, you can try login into the router using default username and password.
 - Ensure that you take backup of the router configuration so you can restore the router back after resetting it.
- 2. Router cannot get connected to Internet.
 - Access the router's web configuration and verify Internet connection status.
 - If you were previously able to connect a computer to Internet directly, try to do that again, and verify whether you can access Internet with your computer directly attached to the device provided by your Internet service provider.
 - Check PPPOE user ID and password again.
 Call your Internet Service Provider and verify whether there is some issue with their service.
 - Try to reboot the router and verify whether it connects to Internet or not.
 - Try to use IP address instead of hostname. If you can use IP address to communicate with a remote server, but can't use hostname, please check DNS setting.

3. Wireless client cannot locate the router.

- Verify whether 'SSID Broadcast' is set to off in router's web configuration.
- Verify whether the antenna is properly connected and in correct direction
- Is your wireless client far away from your router? Try to get closer to the router.
 - Ensure that you input ESSID on your wireless client manually, if SSID broadcast is disabled.







This Product is covered under DIGICARE Limited Lifetime Warranty program backed by DIGICARE Service Center. To avail this Limited Lifetime Warranty offer, customer needs to contact DIGICARE's Technical Assistance Center for the same. You may be asked to provide proof of purchase of product for warranty claim of defective product. Please refer website www.digisol.com for the detailed support terms & conditions and support process.

Warranty Policy

- Hardware Warranty: Hardware warranty period shall be limited up to Three years. External Power Adapter shall carry One year warranty only against manufacturing defects. Any repair or replacement will be rendered by DIGICARE at its Service Center only.
- 2. Software Warranty: DIGISOL issues this Limited Software Warranty that the software portion of the product ("Software") will substantially confirm to DIGISOL's then current functional specifications for the software, as set forth in the applicable documentation, from the date of original retail purchase of the Software for a period of one year ("Software Warranty period"), provided that the Software is properly installed on approved hardware and operated as contemplated in its documentation.
- 3. Governing Law: This warranty shall be governed by Indian Laws.
- Limited Lifetime Warranty shall subject to the terms & conditions specified in the DIGISOL PRODUCT WARRANTY policy displayed on www.digisol.com

JIGICARE

% helpdesk@digisol.com 1800 209 3444





DIGISOL SYSTEMS LIMITED

Smartlink House, Plot. No. 5, Off CST Road, Bandra-Kurla Complex Road, Santacruz (East), Mumbai - 400 098, India.

Tel: +91 22 3061 6666 / 2652 6696,

Fax: +91 22 2652 8914

A Subsidiary of Smartlink Network Systems Ltd.

www.digisol.com



