



Interface Range Commands

As our products undergo continuous development the specifications are subject to change without prior notice.

Table of Contents

Chapter 1 Interface Range Command.....	1
1.1 Interface Range.....	1

Chapter 1 Interface Range Command

1.1 Interface Range

Syntax

```
interface range type slot / <port1-port2 | port3> [, <port1-port2 | port3>]
```

Parameter

Name	Description	Range
<i>type</i>	Port type	All legal port types, except management ports on the main board of the rackmount switch.
<i>slot</i>	Slot number	All legal slot number.
<i>port1</i>	Beginning value of the port number	All legal port numbers on the slot.
<i>port2</i>	Ending value of the port number	All legal port numbers on the slot except for port 1.
<i>port3</i>	A single port.	All legal port numbers on the slot.

Default

None

Usage Guidelines

Use this command to enter the interface range mode.

Example

Use the following command to enter the enterface configuration mode, including the Ethernet ports 1, 2, 3 and 4:

```
switch_config# interface range gigaEthernet 0/1-4  
switch_config_if_range#
```

Note:

There are no space on either side of "-" and ","