

OSPFv3 Configuration Commands

Table of Contents

Chapter 1 OSPFv3 Configuration Commands.....	1
1.1 OSPFv3 Configuration Commands.....	1
1.1.1 area default-cost	2
1.1.2 area nssa	3
1.1.3 area range.....	5
1.1.4 area stub	6
1.1.5 area virtual-link	7
1.1.6 debug ipv6 ospf	9
1.1.7 debug ipv6 ospf events	11
1.1.8 debug ipv6 ospf ifsm	13
1.1.9 debug ipv6 ospf lsa	14
1.1.10 debug ipv6 ospf nsm	17
1.1.11 debug ipv6 ospf nsm.....	19
1.1.12 debug ipv6 ospf packet	20
1.1.13 debug ipv6 ospf route	22
1.1.14 default-information originate.....	24
1.1.15 default-metric	25
1.1.16 filter	26
1.1.17 ipv6 ospf area	27
1.1.18 ipv6 ospf cost.....	28
1.1.19 ipv6 ospf database-filter all out.....	29
1.1.20 ipv6 ospf dead-interval	29
1.1.21 ipv6 ospf hello-interval.....	30
1.1.22 ipv6 ospf mtu-ignore	31
1.1.23 ipv6 ospf neighbor	32
1.1.24 ipv6 ospf network.....	33
1.1.25 ipv6 ospf priority	34
1.1.26 ipv6 ospf retransmit-interval	35
1.1.27 ipv6 ospf transmit-delay.....	36
1.1.28 passive-interface	37
1.1.29 redistribute	38
1.1.30 router ospfv3	39
1.1.31 router-id	40
1.1.32 show ipv6 ospf	41
1.1.33 show ipv6 ospf database	42
1.1.34 show ipv6 ospf interface.....	44
1.1.35 show ipv6 ospf neighbor.....	46
1.1.36 show ipv6 ospf route	47
1.1.37 show ipv6 ospf virtual-link	48
1.1.38 summary-prefix	50
1.1.39 timers delay.....	51
1.1.40 timers hold.....	52

1.1.41 timers age	52
-------------------------	----

Chapter 1 OSPFv3 Configuration Commands

1.1 OSPFv3 Configuration Commands

The OSPFv3 configuration commands include:

- area default-cost
- area nssa
- area range
- area stub
- area virtual-link
- debug ipv6 ospf
- debug ipv6 ospf events
- debug ipv6 ospf ifsm
- debug ipv6 ospf lsa
- debug ipv6 ospf n fsm
- debug ipv6 ospf nsm
- debug ipv6 ospf packet
- debug ipv6 ospf route
- default-information originate
- default-metric
- filter
- ipv6 ospf area
- ipv6 ospf cost
- ipv6 ospf database-filter all out
- ipv6 ospf dead-interval
- ipv6 ospf hello-interval
- ipv6 ospf mtu-ignore
- ipv6 ospf neighbor

- `ipv6 ospf network`
- `ipv6 ospf priority`
- `ipv6 ospf retransmit-interval`
- `ipv6 ospf transmit-delay`
- `passive-interface`
- `redistribute`
- `router ospfv3`
- `router-id`
- `show ipv6 ospf`
- `show ipv6 ospf database`
- `show ipv6 ospf interface`
- `show ipv6 ospf neighbor`
- `show ipv6 ospf route`
- `show ipv6 ospf virtual-link`
- `summary-prefix`
- `timers delay`
- `timers hold`
- `timers age`

1.1.1 **area** default-cost

Syntax

To specify the cost of the default summary route in the NSSA or STUB area, run the first one of the following two commands:

area *area-id* **default-cost** *cost*

no area *area-id* **default-cost** *cost*

Parameter

Parameter	Description
<i>area-id</i>	Means the ID of the NSSA or STUB area.
<i>cost</i>	Means the cost of the default summary route.

Default value

The default value is 1.

Command mode

Routing configuration mode

Usage guidelines

The command is helpful only when it is used on the boundary router connecting the NASSA area or the STUB area.

After the **area stub default-information-originate** command is configured, the cost configured by this command will be used in LSA to set the corresponding cost.

Example

The following example shows how to set the default cost of stub domain 36.0.0.0 to 20:

```
interface vlan 1
  ipv6 add 2001::1/64
  ipv6 ospf 1 area 36.0.0.0
!
router ospfv3 1
  router-id 2.2.2.2
  area 36.0.0.0 stub
  area 36.0.0.0 default-cost 20
```

Related command

area nssa

area stub

1.1.2 **area nssa**

Syntax

To configure a NSSA area, run the first one of the following two commands:

```
area area-id nssa [default-information-originate [metric value] [metric-type {1 | 2}]]
[interval value] [no-redistribute] [no-summary] [range {ipv6-prefix/prefix-length}
[advertise | not-advertise]] [translator {always|candidate}]
```

```
no area area-id nssa [default-information-originate [metric value] [metric-type {1 |
2}]] [interval value] [no-redistribute] [no-summary] [range {ipv6-prefix/prefix-length}
[advertise | not-advertise]] [translator {always|candidate}]
```

Parameter

Parameter	Description
<i>area-id</i>	Sets the ID of the NSSA area. It can be a decimal number or an IP address.
default-information-originate	Means to send the default route to the NSSA area. After this command is configured, if it is a non-ABR in the NSSA area, it needs an IPv6 default route on the device before sending the default route to the NSSA area; on the ABR, regardless of whether there is an IPv6 default route on the device, it will be sent to NSSA Area sending default route
metric value	Stands for the cost of the default route, which ranges from 1 to 16777214.
metric-type {1 2}	Means the cost type of the default route.
interval value	Means the stable time of the NSSA translator role, which ranges from 1 to 65535.
no-redistribute	Means not to redistribute a route to the NSSA area.
no-summary	Forbids the ABR router to send the summary link to the NSSA area.
range	Means to conduct summary when type-7 LSA is translated into type-5 LSA.
translator	Stands for the NSSA translator role; if the parameter “always” is used, it means it is always the translator, and if it is the parameter “candidate”, it means it can be chosen as a translator.

Default value

Non-NSSA area

Command mode

Routing configuration mode

Usage guidelines

All routers and access servers in the NSSA area will be configured by the **area nssa** command.

To decrease the number of LSA's, you can run **no summary** on the ABR router to forbid the summary LSA to enter the NSSA area.

The parameter “no-distribute” is always used for ABR and its purpose is to stop redistributed routes from being sent to the NSSA area.

Example

The following example shows how to set the NSSA area of 36.0.0.0:

```
interface vlan 1
  ipv6 address 2001::1/64
  ipv6 ospf 1 area 36.0.0.0
!
router ospfv3 1
  router-id 2.2.2.2
  area 36.0.0.0 nssa
!
```

Related command

area stub

1.1.3 **area range**

Syntax

To summarize the routes at the field boundary, run **area area-id range**. To cancel the previous settings, run **no area area-id range**.

area area-id range {ipv6-prefix /prefix-length} [advertise | not-advertise]

no area area-id range {ipv6-prefix /prefix-length}

Parameter

Parameter	Description
<i>area-id</i>	Means the fields where the fields will be summarized. It can be a decimal number or an IPv6 address.
<i>ipv6-prefix</i>	Means the prefix of the IPv6 address.
<i>prefix-length</i>	Means the length of the IPv6 address' prefix.
advertise	Means that the routes are released after they are summarized.
not-advertise	Means that the routes are not released after they are summarized.

Default value

The command has no effect by default.

Command mode

Routing configuration mode

Usage guidelines

The **area range** command is not run on the ABR router, enabling ABR to be broadcast to other routers through a summary route. In this way, the route of the field boundary is miniaturized. As to the outside of the area, each address range has only one summary route.

The command can be configured on the routers in multiple areas, and OSPF, hence, can summarize many address ranges.

Example

The following example shows how to set the prefix of the summarized IPv6 address in area 1, 2001:0DB8:0:1::/64:

```
interface vlan 1
  ipv6 address 2001::1/64
  ipv6 ospf 1 area 1
!
router ospfv3 1
  router-id 192.168.255.5
  area 1 range 2001:0DB8:0:1::/64
```

1.1.4 area stub

Syntax

To configure a STUB area, run the first one of the following two commands. To cancel the configuration, run the other command.

area *area-id* **stub** [**no-summary**]

no area *area-id* **stub** [**no-summary**]

Parameter

Parameter	Description
<i>area-id</i>	Sets the ID of the STUB area. It can be a decimal number or an IP address.
no-summary	Forbids the ABR router to send the summary link to the STUB area.

Default value

Non-stub area

Command mode

Routing configuration mode

Usage guidelines

All routers and access servers in the STUB area will be configured by the **area stub** command. The ABR router adopts the **default-cost** option to set the cost from the internal router to the STUB area.

The **default-cost** subcommand is only used on the domain border router connected to the stub area to set the cost of the convergence route generated by the domain border router to reach the stub area.

To decrease the number of LSA's, you can run **no summary** on the ABR router to forbid the summary LSA to enter the STUB area.

Example

The following example shows how to set the STUB area of 36.0.0.0:

```
interface vlan 1
  ipv6 address 2001::1/64
  ipv6 ospf 1 area 36.0.0.0
!
router ospfv3 1
  router-id 2.2.2.2
  area 36.0.0.0 stub
!
```

Related command

area nssa

1.1.5 area virtual-link

Syntax

To configure a virtual link, run the first one of the following two commands.

area *area-id* **virtual-link** *neighbor-ID* [**dead-interval** *dead-value*][**hello-interval** *hello-value*][**retransmit-interval** *retrans-value*][**transmit-delay** *dly-value*]

no area *area-id* **virtual-link** *neighbor-ID*

Parameter

Parameter	Description
<i>area-id</i>	Specifies the transit-area of the virtual link.
<i>neighbor-id</i>	OSPF router ID of the peer router of virtual link
<i>dead-value</i>	Stands for the interval for the local router to regard that the neighbor dies, whose unit is second. The values configured at the two terminals of the

	virtual link must be same.
<i>hello-value</i>	Stands for the interval for the router to transmit the HELLO packet on the virtual link, whose unit is second. The values configured at the two terminals of the virtual link must be same.
<i>retrans-value</i>	Interval for the router to transmit the re-transmit packet on the virtual link, whose unit is second The values configured at the two terminals of the virtual link must be same.
<i>dly-value</i>	Delay value which is reported by the router to LSA on the virtual link, whose unit is second The values configured at the two terminals of the virtual link must be same. The values configured at the two terminals of the virtual link must be same.

Default value

The virtual link is not configured.

The default values of other parameters are shown in the following:

Hello-value: 10s, Dead-value : 40s, Retrans-value : 5s, dly-value : 1s

Command mode

Routing configuration mode

Usage guidelines

In order to create a virtual link, you have to perform configuration at the two terminals of the virtual link. If only one terminal need be configured, the virtual link cannot function.

The **area-id** parameter cannot be zero because the transit area of the virtual link must not be the backbone area. The area-id configured at the two terminals of the virtual link must be same.

Parameters configured at the two terminals of the virtual link must be same.

After the virtual link is created (the neighborhood is in the FULL state), the virtual link works in the Demand Circuit mode, that is, the periodical Hello packet and the LSA refresh packet are not transmitted.

You can run no **area area-id virtual-link neighbor-ID** to cancel the previous configuration of the virtual link.

You also can run **show ip ospf virtual-link** to check the state of the virtual link.

Example

The following example shows how to create a virtual link between router A and router B.

Configuration of Switch A(router-id: 200.200.200.1)

```
!  
interface vlan 1  
    ipv6 address 2001::1/64  
    ipv6 ospf 1 area 1  
!  
router ospfv3 1  
    router-id 200.200.200.1  
    area 1 virtual-link 200.200.200.2  
!
```

Configuration of Switch B(router-id: 200.200.200.2):

```
!  
interface vlan 1  
    ipv6 address 2001::2/64  
    ipv6 ospf 1 area 1  
!  
router ospfv3 1  
    router-id 200.200.200.2  
    area 1 virtual-link 200.200.200.1  
!
```

Related command

show ipv6 ospf virtual-link

1.1.6 **debug** ipv6 ospf

Syntax

To open all debugging switches of the OSPFv3 module, run the first one of the following two commands:

debug ipv6 ospf

no debug ipv6 ospf

Parameter

None

Default value

None

Command mode

EXEC

Usage guidelines

This command can be used to collect all debugging information about the OSPFv3 for the R&D engineers and technical support staff.

Example

```
Switch# debug ipv6 ospf
LSA[Area(0.0.0.1):Type(0x2009):0.0.0.1:200.200.200.1 *]: Install Intra-Area-Prefix-LSA to Area 0.0.0.1
LSA[Area(0.0.0.1):Type(0x2009):0.0.0.1:200.200.200.1 *]: consider flooding through interface[FastEthernet0/0]
LSA[Area(0.0.0.1):Type(0x2009):0.0.0.1:200.200.200.1 *]: Intra-Area-Prefix-LSA(0x38110c0) originated
VLINK[VLINK1]: local address is 101::1VLINK[VLINK1]: peer 200.200.200.2 link upLSA[Link(FastEthernet0/0):Type(0x0008):0.0.0.4:200.200.200.1 *]: Install Link-LSA to Link FastEthernet0/0
LSA[Link(FastEthernet0/0):Type(0x0008):0.0.0.4:200.200.200.1 *]: consider flooding through interface[FastEthernet0/0]
LSA[Link(FastEthernet0/0):Type(0x0008):0.0.0.4:200.200.200.1 *]: Link-LSA(0x381ec40) originated
OSPFv3D: Received ospfv3 message: OSPFV3_MSG_RCV_EVENT.
LSA[Area(0.0.0.1):Type(0x2001):0.0.0.0:200.200.200.1 *]: Install Router-LSA to Area 0.0.0.1
LSA[Area(0.0.0.1):Type(0x2001):0.0.0.0:200.200.200.1 *]: consider flooding through interface[FastEthernet0/0]
LSA[Area(0.0.0.1):Type(0x2001):0.0.0.0:200.200.200.1 *]: Router-LSA(0x381ec20) originated
IFSM[FastEthernet0/0]: Down (InterfaceUp)
IFSM[FastEthernet0/0]: Status change Down -> Waiting
SPF[0.0.0.0]: Calculation timer scheduled [delay 5 secs]
LSA[Area(0.0.0.0):Type(0x2001):0.0.0.0:200.200.200.1 *]: Install Router-LSA to Area 0.0.0.0
LSA[Area(0.0.0.0):Type(0x2001):0.0.0.0:200.200.200.1 *]: consider flooding through interface[VLINK1]
LSA[Area(0.0.0.0):Type(0x2001):0.0.0.0:200.200.200.1 *]: Router-LSA(0x38297e0) originated
IFSM[VLINK1]: Down (InterfaceUp)
IFSM[VLINK1]: Status change Down -> Point-To-Point
ROUTER[1]: Change status to ABR
IFSM[FastEthernet0/0]: Hello timer expire
Packet[SEND]: src(fe80:4::2e0:fff:fe26:2d98) -> dst(ff02::5)
OSPFv3 Header
  Version 3  Type 1 (Hello)  Packet length 36
  Router ID 200.200.200.1
```

```

Area ID 0.0.0.1
Checksum 0x0000 Instance ID 0
OSPFv3 Hello
Interface ID 4
RtrPriority 1 Options 0x000013 (-|R|-|E|V6)
HelloInterval 10 RtrDeadInterval 40
DRouter 0.0.0.0 BDRouter 0.0.0.0
# Neighbors 0
OSPF6D: Received ospfv3 message: OSPFV3_MSG_RCV_TIMER.
OSPF6D: Received ospfv3 message: OSPFV3_MSG_RCV_EVENT.
OSPF6D: Received ospfv3 message: OSPFV3_MSG_RCV_SOCKET.
.....

```

1.1.7 debug ipv6 ospf events

Syntax

To enable the event debug switch of the OSPFv3 module, run the first one of the following two commands:

debug ipv6 ospf events {abr|asbr|vlink|os|router}

no debug ipv6 ospf events { abr|asbr|vlink|os|router }

Parameter

Parameter	Description
<i>abr</i>	Opens the state change debug switch of ABR.
<i>asbr</i>	Opens the state change debug switch of ASBR.
<i>vlink</i>	Opens the state change debug switch of the virtual link.
<i>os</i>	Opens the state change debug switch of socket.
<i>router</i>	Opens the debug switch of OSPF.

Default value

None

Command mode

EXEC

Usage guidelines

According to the information exported by the command, you can check the OSPF port and the neighbor trigger event.

Example

Switch# debug ip ospf events

```

OSPF6D: Received ospfv3 message: OSPFV3_MSG_RCV_TIMER.
OSPF6D: Received ospfv3 message: OSPFV3_MSG_RCV_TIMER.
OSPF6D: Received ospfv3 message: OSPFV3_MSG_RCV_EVENT.
ROUTER[1]: Change status to ABR
OSPF6D: Received ospfv3 message: OSPFV3_MSG_RCV_EVENT.
OSPF6D: Received ospfv3 message: OSPFV3_MSG_RCV_SOCKET.
OSPF6D: Received ospfv3 message: OSPFV3_MSG_RCV_TIMER.
OSPF6D: Received ospfv3 message: OSPFV3_MSG_RCV_SOCKET.
OSPF6D: Received ospfv3 message: OSPFV3_MSG_RCV_EVENT.
OSPF6D: Received ospfv3 message: OSPFV3_MSG_RCV_SOCKET.
OSPF6D: Received ospfv3 message: OSPFV3_MSG_RCV_SOCKET.
OSPF6D: Received ospfv3 message: OSPFV3_MSG_RCV_EVENT.
OSPF6D: Received ospfv3 message: OSPFV3_MSG_RCV_SOCKET.
OSPF6D: Received ospfv3 message: OSPFV3_MSG_RCV_SOCKET.
OSPF6D: Received ospfv3 message: OSPFV3_MSG_RCV_EVENT.
OSPF6D: Received ospfv3 message: OSPFV3_MSG_RCV_EVENT.
OSPF6D: Received ospfv3 message: OSPFV3_MSG_RCV_TIMER.
OSPF6D: Received ospfv3 message: OSPFV3_MSG_RCV_SOCKET.
OSPF6D: Received ospfv3 message: OSPFV3_MSG_RCV_TIMER.
OSPF6D: Received ospfv3 message: OSPFV3_MSG_RCV_TIMER.
OSPF6D: Received ospfv3 message: OSPFV3_MSG_RCV_EVENT.
OSPF6D: Received ospfv3 message: OSPFV3_MSG_RCV_SOCKET.
VLINK[VLINK1]: peer 200.200.200.2 link downROUTER[1]: Change status to non-ABR
OSPF6D: Received ospfv3 message: OSPFV3_MSG_RCV_EVENT.
OSPF6D: Received ospfv3 message: OSPFV3_MSG_RCV_TIMER.
ROUTER[Process:1]: GC timer expire
OSPF6D: Received ospfv3 message: OSPFV3_MSG_RCV_SOCKET.
OSPF6D: Received ospfv3 message: OSPFV3_MSG_RCV_TIMER.
OSPF6D: Received ospfv3 message: OSPFV3_MSG_RCV_TIMER.
OSPF6D: Received ospfv3 message: OSPFV3_MSG_RCV_TIMER.
OSPF6D: Received ospfv3 message: OSPFV3_MSG_RCV_TIMER.
OSPF6D: Received ospfv3 message: OSPFV3_MSG_RCV_SOCKET.
OSPF6D: Received ospfv3 message: OSPFV3_MSG_RCV_TIMER.
OSPF6D: Received ospfv3 message: OSPFV3_MSG_RCV_EVENT.
OSPF6D: Received ospfv3 message: OSPFV3_MSG_RCV_TIMER.
OSPF6D: Received ospfv3 message: OSPFV3_MSG_RCV_TIMER.
OSPF6D: Received ospfv3 message: OSPFV3_MSG_RCV_SOCKET.
OSPF6D: Received ospfv3 message: OSPFV3_MSG_RCV_TIMER.
OSPF6D: Received ospfv3 message: OSPFV3_MSG_RCV_TIMER.
OSPF6D: Received ospfv3 message: OSPFV3_MSG_RCV_TIMER.
OSPF6D: Received ospfv3 message: OSPFV3_MSG_RCV_TIMER.
ROUTER[Process:1]: GC timer expire
OSPF6D: Received ospfv3 message: OSPFV3_MSG_RCV_SOCKET.

```

```

OSPF6D: Received ospfv3 message: OSPFV3_MSG_RCV_SOCKET.
join AILDRouters on FastEthernet0/0
OSPF6D: Received ospfv3 message: OSPFV3_MSG_RCV_EVENT.
OSPF6D: Received ospfv3 message: OSPFV3_MSG_RCV_EVENT.
OSPF6D: Received ospfv3 message: OSPFV3_MSG_RCV_EVENT.
.....

```

1.1.8 debug ipv6 ospf ifsm

Syntax

To enable the state machine's debug switch of the OSPFv3 module, run the first one of the following two commands:

debug ipv6 ospf ifsm {status|events|timers}

no debug ipv6 ospf ifsm {status|events|timers}

Parameter

Parameter	Description
<i>status</i>	Opens the state debug switch of the interface state machine.
<i>events</i>	Opens the event debug switch of the interface state machine.
<i>timers</i>	Opens the timer debug switch of the interface state machine.

Default value

None

Command mode

EXEC

Usage guidelines

According to the information exported by the command, you can check the whole process of the state machine of the OSPF interface.

Example

```

Switch # debug ipv6 ospf ifsm
IFSM[VLINK1]: Down (InterfaceUp)
IFSM[VLINK1]: Status change Down -> Point-To-Point
IFSM[FastEthernet0/0]: Down (InterfaceUp)
IFSM[FastEthernet0/0]: Status change Down -> Waiting
IFSM[FastEthernet0/0]: Hello timer expire
IFSM[VLINK1]: Hello timer expire

```



```

IFSM[VLINK1]: ifsm_ignore called
IFSM[VLINK1]: Point-To-Point (NeighborChange)
IFSM[FastEthernet0/0]: ifsm_ignore called
IFSM[FastEthernet0/0]: Waiting (NeighborChange)
IFSM[VLINK1]: LS ack timer expire
IFSM[VLINK1]: LS ack timer expire
IFSM[VLINK1]: Point-To-Point (InterfaceDown)
IFSM[VLINK1]: Status change Point-To-Point -> Down
IFSM[VLINK1]: ifsm_ignore called
IFSM[VLINK1]: Down (NeighborChange)
IFSM[FastEthernet0/0]: Hello timer expire
IFSM[FastEthernet0/0]: Hello timer expire
IFSM[FastEthernet0/0]: Hello timer expire
IFSM[FastEthernet0/0]: Wait timer expire
IFSM[FastEthernet0/0]: DR-Election[1st]: Backup 200.200.200.2
IFSM[FastEthernet0/0]: DR-Election[1st]: DR      200.200.200.2
IFSM[FastEthernet0/0]: Waiting (WaitTimer)
IFSM[FastEthernet0/0]: Status change Waiting -> DROther
IFSM[VLINK1]: Down (InterfaceUp)
IFSM[VLINK1]: Status change Down -> Point-To-Point
IFSM[FastEthernet0/0]: DR-Election[1st]: Backup 200.200.200.1
IFSM[FastEthernet0/0]: DR-Election[1st]: DR      200.200.200.2
IFSM[FastEthernet0/0]: DR-Election[2nd]: Backup 200.200.200.1
IFSM[FastEthernet0/0]: DR-Election[2nd]: DR      200.200.200.2
IFSM[FastEthernet0/0]: DROther (NeighborChange)
IFSM[FastEthernet0/0]: Status change DROther -> Backup
IFSM[FastEthernet0/0]: Hello timer expire
IFSM[FastEthernet0/0]: LS ack timer expire
IFSM[VLINK1]: Hello timer expire
IFSM[FastEthernet0/0]: LS ack timer expire
IFSM[VLINK1]: Point-To-Point (InterfaceDown)
IFSM[VLINK1]: Status change Point-To-Point -> Down
IFSM[VLINK1]: Down (InterfaceUp)
IFSM[VLINK1]: Status change Down -> Point-To-Point
IFSM[FastEthernet0/0]: LS ack timer expire
IFSM[VLINK1]: Hello timer expire
.....

```

1.1.9 debug ipv6 ospf lsa

Syntax

To enable the LSA-related debug switch of the OSPFv3 module, run the first one of the following two commands:

```
debug ipv6 ospf lsa { generate|flooding|install|maxage|refresh }
```

no debug ipv6 ospf lsa { generate|flooding|install|maxage|refresh}

Parameter

Parameter	Description
<i>generate</i>	Opens the debug switch of LSA create.
<i>flooding</i>	Opens the debug switch of LSA exchange.
<i>install</i>	Opens the debug switch of LSA installation.
<i>maxage</i>	Opens the debug switch of LSA timeout.
<i>refresh</i>	Opens the debug switch of LSA-Refresh.

Default value

None

Command mode

EXEC

Usage guidelines

According to the information exported by the command, you can browse the operation that OSPF performs to LSA and related events.

Example

```
Switch # debug ipv6 ospf lsa
LSA[Area(0.0.0.1):Type(0x2009):0.0.0.1:200.200.200.1 *]: Install Intra-Area-Prefix-LSA to Area
0.0.0.1
LSA[Area(0.0.0.1):Type(0x2009):0.0.0.1:200.200.200.1 *]: consider flooding through
interface[FastEthernet0/0]
LSA[Area(0.0.0.1):Type(0x2009):0.0.0.1:200.200.200.1 *]: Intra-Area-Prefix-LSA(0x3824ba0)
originated
LSA[Area(0.0.0.0):Type(0x2001):0.0.0.0:200.200.200.1 *]: Install Router-LSA to Area 0.0.0.0
LSA[Area(0.0.0.0):Type(0x2001):0.0.0.0:200.200.200.1 *]: consider flooding through
interface[VLINK1]
LSA[Area(0.0.0.0):Type(0x2001):0.0.0.0:200.200.200.1 *]: consider flooding to
neighbor[200.200.200.2]
LSA[Area(0.0.0.0):Type(0x2001):0.0.0.0:200.200.200.1 *]: Router-LSA(0x3819be0) originated
LSA[Link(FastEthernet0/0):Type(0x0008):0.0.0.4:200.200.200.1 *]: Install Link-LSA to Link
FastEthernet0/0
LSA[Link(FastEthernet0/0):Type(0x0008):0.0.0.4:200.200.200.1 *]: consider flooding through
interface[FastEthernet0/0]
LSA[Link(FastEthernet0/0):Type(0x0008):0.0.0.4:200.200.200.1 *]: Link-LSA(0x3819bc0)
originated
LSA[Area(0.0.0.1):Type(0x2001):0.0.0.0:200.200.200.1 *]: Install Router-LSA to Area 0.0.0.1
```

```

LSA[Area(0.0.0.1):Type(0x2001):0.0.0.0:200.200.200.1 *]: consider flooding through
interface[FastEthernet0/0]
LSA[Area(0.0.0.1):Type(0x2001):0.0.0.0:200.200.200.1 *]: Router-LSA(0x3824740) originated
LSA[Area(0.0.0.0):Type(0x2001):0.0.0.0:200.200.200.2]: instance(0x380bf60) created with Link
State Update
LSA[Area(0.0.0.0):Type(0x2003):0.0.0.1:200.200.200.2]: instance(0x38246c0) created with Link
State Update
LSA[Area(0.0.0.0):Type(0x2001):0.0.0.0:200.200.200.2]: flood started
LSA[Area(0.0.0.0):Type(0x2001):0.0.0.0:200.200.200.2]: consider flooding through
interface[VLINK1]
LSA[Area(0.0.0.0):Type(0x2001):0.0.0.0:200.200.200.2]: consider flooding to
neighbor[200.200.200.2]
LSA[Area(0.0.0.0):Type(0x2001):0.0.0.0:200.200.200.2]: neighbor is not Full state
LSA[Area(0.0.0.0):Type(0x2001):0.0.0.0:200.200.200.2]: Install Router-LSA to Area 0.0.0.0
LSA[Area(0.0.0.0):Type(0x2003):0.0.0.1:200.200.200.2]: flood started
LSA[Area(0.0.0.0):Type(0x2003):0.0.0.1:200.200.200.2]: consider flooding through
interface[VLINK1]
LSA[Area(0.0.0.0):Type(0x2003):0.0.0.1:200.200.200.2]: consider flooding to
neighbor[200.200.200.2]
LSA[Area(0.0.0.0):Type(0x2003):0.0.0.1:200.200.200.2]: neighbor is not Full state
LSA[Area(0.0.0.0):Type(0x2003):0.0.0.1:200.200.200.2]: Install Inter-Area-Prefix-LSA to Area
0.0.0.0
LSA[Area(0.0.0.0):Type(0x2001):0.0.0.0:200.200.200.1 *]: Install Router-LSA to Area 0.0.0.0
LSA[Area(0.0.0.0):Type(0x2001):0.0.0.0:200.200.200.1 *]: consider flooding through
interface[VLINK1]
LSA[Area(0.0.0.0):Type(0x2001):0.0.0.0:200.200.200.1 *]: consider flooding to
neighbor[200.200.200.2]
LSA[Area(0.0.0.0):Type(0x2001):0.0.0.0:200.200.200.1 *]: added to neighbor[200.200.200.2]'s
retransmit-list
LSA[Area(0.0.0.0):Type(0x2001):0.0.0.0:200.200.200.1 *]: sending update to interface[VLINK1]
LSA[Area(0.0.0.0):Type(0x2001):0.0.0.0:200.200.200.1 *]: Router-LSA refreshed
  OSPFv3 LSA Header
    LS age 0
    LS type 0x2001 (Router-LSA)
    Advertising Router 200.200.200.1
    Link State ID 0.0.0.0
    LS sequence number 0x80000002
    LS checksum 0x5ff7
    length 40
LSA[Area(0.0.0.0):Type(0x2001):0.0.0.0:200.200.200.1 *]: consider flooding through
interface[VLINK1]
LSA[Area(0.0.0.1):Type(0x2001):0.0.0.0:200.200.200.1 *]: Install Router-LSA to Area 0.0.0.1
LSA[Area(0.0.0.1):Type(0x2001):0.0.0.0:200.200.200.1 *]: consider flooding through
interface[FastEthernet0/0]
LSA[Area(0.0.0.1):Type(0x2001):0.0.0.0:200.200.200.1 *]: Router-LSA refreshed
  OSPFv3 LSA Header
    LS age 0
    LS type 0x2001 (Router-LSA)
    Advertising Router 200.200.200.1
    Link State ID 0.0.0.0

```

```

LS sequence number 0x80000002
LS checksum 0x5382
length 24
LSA[Area(0.0.0.1):Type(0x2009):0.0.0.1:200.200.200.1 *]: Install Intra-Area-Prefix-LSA to Area
0.0.0.1
LSA[Area(0.0.0.1):Type(0x2009):0.0.0.1:200.200.200.1 *]: consider flooding through
interface[FastEthernet0/0]
LSA[Area(0.0.0.1):Type(0x2009):0.0.0.1:200.200.200.1 *]: Intra-Area-Prefix-LSA refreshed
OSPFv3 LSA Header
LS age 0
LS type 0x2009 (Intra-Area-Prefix-LSA)
Advertising Router 200.200.200.1
Link State ID 0.0.0.1
LS sequence number 0x80000002
LS checksum 0x3631
length 64
.....

```

1.1.10 **debug ipv6 ospf nfsm**

Syntax

To enable the state machine's debug switch of the OSPFv3 neighbor, run the first one of the following two commands:

debug ipv6 ospf nfsm {status|events|timers}

no debug ipv6 ospf nfsm {status|events|timers}

Parameter

Parameter	Description
<i>status</i>	Opens the state debug switch of the neighbor state machine.
<i>events</i>	Opens the event debug switch of the neighbor state machine.
<i>timers</i>	Opens the timer debug switch of the neighbor state machine.

Default value

None

Command mode

EXEC

Usage guidelines

According to the information exported by the command, you can check the whole process of the OSPF neighbor's state machine.

Example

```
Switch # debug ipv6 ospf nfsm
NFSM[200.200.200.2-00000004]: Full (HelloReceived)
NFSM[200.200.200.2-00000004]: nfsm_ignore calledNFSM[200.200.200.2-00000004]: Full
(2-WayReceived)
NFSM[200.200.200.2-00000004]: Down (HelloReceived)
NFSM[200.200.200.2-00000004]: Status change Down -> Init
NFSM[200.200.200.2-00000004]: nfsm_ignore called
NFSM[200.200.200.2-00000004]: Init (1-WayReceived)
NFSM[200.200.200.2-00000004]: Init (HelloReceived)
NFSM[200.200.200.2-00000004]: Init (2-WayReceived)
NFSM[200.200.200.2-00000004]: Status change Init -> 2-Way
NFSM[200.200.200.2-00000004]: 2-Way (HelloReceived)
NFSM[200.200.200.2-00000004]: nfsm_ignore called
NFSM[200.200.200.2-00000004]: 2-Way (2-WayReceived)
NFSM[200.200.200.2-00000004]: 2-Way (AdjOK?)
NFSM[200.200.200.2-00000004]: Status change 2-Way -> ExStar
tNFSM[200.200.200.2-00000004]: ExStart (HelloReceived)
NFSM[200.200.200.2-00000004]: nfsm_ignore called
NFSM[200.200.200.2-00000004]: ExStart (2-WayReceived)
NFSM[200.200.200.2-00000004]: DD Retransmit timer expire
NFSM[200.200.200.2-00000004]: ExStart (NegotiationDone)
NFSM[200.200.200.2-00000004]: Status change ExStart -> Exchange
NFSM[200.200.200.2-00000004]: Exchange (ExchangeDone)
NFSM[200.200.200.2-00000004]: Status change Exchange -> Loading
NFSM[200.200.200.2-00000004]: nfsm_ignore called
NFSM[200.200.200.2-00000004]: Loading (LoadingDone)
NFSM[200.200.200.2-00000004]: Status change Loading -> Full
NFSM[200.200.200.2-80000001]: Down (HelloReceived)
NFSM[200.200.200.2-80000001]: Status change Down -> Init
NFSM[200.200.200.2-80000001]: Init (2-WayReceived)
NFSM[200.200.200.2-80000001]: Status change Init -> ExStart
NFSM[200.200.200.2-80000001]: ExStart (NegotiationDone)
NFSM[200.200.200.2-80000001]: Status change ExStart -> Exchange
NFSM[200.200.200.2-80000001]: Exchange (ExchangeDone)
NFSM[200.200.200.2-80000001]: Status change Exchange -> Loading
NFSM[200.200.200.2-80000001]: nfsm_ignore called
NFSM[200.200.200.2-80000001]: Loading (LoadingDone)
NFSM[200.200.200.2-80000001]: Status change Loading -> Full
NFSM[200.200.200.2-00000004]: Full (HelloReceived)
NFSM[200.200.200.2-00000004]: nfsm_ignore called
```

```

NFSM[200.200.200.2-00000004]: Full (2-WayReceived)
NFSM[200.200.200.2-00000004]: Full (AdjOK?)
NFSM[200.200.200.2-00000004]: LS update timer expire
NFSM[200.200.200.2-80000001]: LS update timer expire
NFSM[200.200.200.2-00000004]: LS update timer expire
NFSM[200.200.200.2-80000001]: LS update timer expire
NFSM[200.200.200.2-80000001]: Full (HelloReceived)
NFSM[200.200.200.2-80000001]: nfsm_ignore called
NFSM[200.200.200.2-80000001]: Full (2-WayReceived)
NFSM[200.200.200.2-00000004]: Full (HelloReceived)
NFSM[200.200.200.2-00000004]: nfsm_ignore called
NFSM[200.200.200.2-00000004]: Full (2-WayReceived)
NFSM[200.200.200.2-00000004]: LS update timer expire
NFSM[200.200.200.2-80000001]: LS update timer expire
.....

```

1.1.11 **debug ipv6 ospf nsm**

Syntax

To open the debug switch of information transmission between the IPv6 routing table's management module and the OSPFv3 module, run the first one of the following two commands:

debug ipv6 ospf nsm { redistribute | interface }

no debug ipv6 ospf nsm { redistribute | interface }

Parameter

Parameter	Description
<i>redistribute</i>	Opens the debug switch of routing information forwarding.
<i>interface</i>	Opens the debug switch of interface events.

Default value

None

Command mode

EXEC

Usage guidelines

According to the information exported by this command, you can browse information exchange between OSPF and routing management module.

Example

```
Switch # debug ipv6 ospf nsm
Sep      17      16:43:53      OSPFv3:      Received
[NSM_MSG_ROUTE_CHG_NOTIFY:NSM_REDISTRIBUTE_DEL] message
Sep      17      16:43:53      OSPFv3:      Received
[NSM_MSG_ROUTE_CHG_NOTIFY:NSM_REDISTRIBUTE_DEL] message
Sep      17      16:43:53      OSPFv3:      Received
[NSM_MSG_ROUTE_CHG_NOTIFY:NSM_REDISTRIBUTE_DEL] message
Sep      17      16:43:53      OSPFv3:      Received
[NSM_MSG_ROUTE_CHG_NOTIFY:NSM_REDISTRIBUTE_DEL] message
Sep 17 16:43:53 OSPFv3: Receive [NSM_MSG_GLBL_ENAIPV6] message
.....
```

1.1.12 debug ipv6 ospf packet

Syntax

To enable the debug switch of OSPFv3 transmission and reception, run the first one of the following two commands:

debug ipv6 ospf packet { hello|dd|ls-request|ls-update|ls-ack |detail}

no debug ipv6 ospf packet { hello|dd|ls-request|ls-update|ls-ack|detail }

Parameter

Parameter	Description
<i>hello</i>	Opens the debug switch of Hello packets.
<i>dd</i>	Opens the debug switch of DD packets.
<i>ls-request</i>	Opens the debug switch of IS-REQUEST packets.
<i>ls-update</i>	Opens the debug switch of IS-Update packets.
<i>ls-ack</i>	Opens the debug switch of IS-Ack packets.
<i>detail</i>	Observes the details of packets.

Default value

None

Command mode

EXEC

Usage guidelines

According to the information exported by the command, you can check the exchange of the OSPF packets.

Example

```
Switch # debug ipv6 ospf packet
Packet[SEND]: src(fe80:4::2e0:fff:fe26:2d98) -> dst(ff02::5)
OSPFv3 Header
  Version 3  Type 1 (Hello)  Packet length 40
  Router ID 200.200.200.1
  Area ID 0.0.0.1
  Checksum 0x0000  Instance ID 0
OSPFv3 Hello
  Interface ID 4
  RtrPriority 1  Options 0x000013 (-|R|-|E|V6)
  HelloInterval 10  RtrDeadInterval 40
  DRouter 200.200.200.2  BDRouter 200.200.200.1
  # Neighbors 1
    Neighbor 200.200.200.2
Packet[RECV]: src(101::2) -> dst(101::1)
OSPFv3 Header
  Version 3  Type 1 (Hello)  Packet length 40
  Router ID 200.200.200.2
  Area ID 0.0.0.0
  Checksum 0x5774  Instance ID 0
OSPFv3 Hello
  Interface ID 2147483649
  RtrPriority 1  Options 0x000013 (-|R|-|E|V6)
  HelloInterval 10  RtrDeadInterval 40
  DRouter 0.0.0.0  BDRouter 0.0.0.0
  # Neighbors 1
    Neighbor 200.200.200.1
RECV[Hello]: Neighbor(200.200.200.2) declare 0.0.0.0 as DR, 0.0.0.0 as Backup
Packet[SEND]: src(101::1) -> dst(101::2)
OSPFv3 Header
  Version 3  Type 1 (Hello)  Packet length 40
  Router ID 200.200.200.1
  Area ID 0.0.0.0
  Checksum 0x0000  Instance ID 0
OSPFv3 Hello
  Interface ID 2147483649
  RtrPriority 1  Options 0x000013 (-|R|-|E|V6)
  HelloInterval 10  RtrDeadInterval 40
  DRouter 0.0.0.0  BDRouter 0.0.0.0
  # Neighbors 1
```



```

Neighbor 200.200.200.2
Packet[RECV]: src(fe80::2e0:fff:fe26:a8) -> dst(ff02::5)
OSPFv3 Header
  Version 3  Type 1 (Hello)  Packet length 40
  Router ID 200.200.200.2
  Area ID 0.0.0.1
  Checksum 0xa8a8  Instance ID 0
OSPFv3 Hello
  Interface ID 4
  RtrPriority 1  Options 0x000013 (-|R|-|-|E|V6)
  HelloInterval 10  RtrDeadInterval 40
  DRouter 200.200.200.2  BDRouter 200.200.200.1
  # Neighbors 1
    Neighbor 200.200.200.1
  RECV[Hello]: Neighbor(200.200.200.2) declare 200.200.200.2 as DR, 200.200.200.1 as Backup
  Packet[SEND]: src(fe80:4::2e0:fff:fe26:2d98) -> dst(ff02::5)
OSPFv3 Header
  Version 3  Type 1 (Hello)  Packet length 40
  Router ID 200.200.200.1
  Area ID 0.0.0.1
  Checksum 0x0000  Instance ID 0
OSPFv3 Hello
  Interface ID 4
  RtrPriority 1  Options 0x000013 (-|R|-|-|E|V6)
  HelloInterval 10  RtrDeadInterval 40
  DRouter 200.200.200.2  BDRouter 200.200.200.1
  # Neighbors 1
    Neighbor 200.200.200.2
    .....

```

1.1.13 debug ipv6 ospf route

Syntax

To enable the debug switch of OSPFv3 routing information, run the first one of the following two commands:

debug ipv6 ospf route { ase|install|spf|ia|nssa}

no debug ipv6 ospf route { ase|install|spf|ia|nssa }

Parameter

Parameter	Description
<i>ase</i>	Opens the debug switch of exterior routing calculation.
<i>install</i>	Opens the debug switch of routing installation procedure.

<i>spf</i>	Opens the debug switch of SPF calculation.
<i>ia</i>	Opens the debug switch of between-domain routing calculation.
<i>nssa</i>	Opens the debug switch of nssa type exterior routing calculation.

Default value

None

Command mode

EXEC

Usage guidelines

According to the information exported by the command, you can browse the calculation, deletion and addition of OSPF routes.

Example

```
Switch # debug ipv6 ospf route
Route[IA:0.0.0.0]: No SPF tree, schedule SPF calculationSPF[0.0.0.1]: SPF calculation timer
expire
SPF[0.0.0.1]: SPF calculation (1st STAGE)
SPF[0.0.0.1]: Vertex[200.200.200.1-0.0.0.0]
SPF[0.0.0.1]: SPF calculation (2nd STAGE)
SPF[0.0.0.1]: SPF calculation (END)
Route[IA:0.0.0.1]: Cleanup IA route because of no ABRsRoute[IA:0.0.0.1]: Cleanup IA route
because of no ABRsSPF[0.0.0.1]: Calculation completed [0.170000 sec]
SPF[0.0.0.1]: Calculation timer scheduled [delay 9 secs]
SPF[0.0.0.1]: SPF calculation timer expire
SPF[0.0.0.1]: SPF calculation (1st STAGE)
SPF[0.0.0.1]: Vertex[200.200.200.1-0.0.0.0]
SPF[0.0.0.1]: SPF calculation (2nd STAGE)
SPF[0.0.0.1]: SPF calculation (END)
Route[IA:0.0.0.1]: Cleanup IA route because of no ABRsSPF[0.0.0.1]: Calculation completed
[0.180000 sec]
SPF[0.0.0.1]: Calculation timer scheduled [delay 10 secs]
SPF[0.0.0.0]: Calculation timer scheduled [delay 5 secs]
Route[IA:0.0.0.1]: 888::/64 calculating Network routeRoute[IA:0.0.0.1]: 888::/64 Can't find route
to ABR (200.200.200.2)Route[IA:0.0.0.0]: No SPF tree, schedule SPF calculationSPF[0.0.0.0]:
SPF calculation timer expire
SPF[0.0.0.0]: SPF calculation (1st STAGE)
SPF[0.0.0.0]: Vertex[200.200.200.1-0.0.0.0]
SPF[0.0.0.0]:   Link[0] (200.200.200.2-128.0.0.1): Virtual-Link
SPF[0.0.0.0]:   Calculate nexthop for (200.200.200.2-0.0.0.0)
Route[0.0.0.0:SPF]:   ADD      Stub      Route      for      (200.200.200.2)SPF[0.0.0.0]:
Vertex[200.200.200.2-0.0.0.0]
```

```

SPF[0.0.0.0]: Link[0] (200.200.200.1-128.0.0.1): Virtual-Link
SPF[0.0.0.0]: LSA[Area(0.0.0.0):Type(0x2001):0.0.0.0:200.200.200.1 *] is already in SPF
tree
SPF[0.0.0.0]: SPF calculation (2nd STAGE)
SPF[0.0.0.0]: SPF calculation (END)
SPF[0.0.0.0]: Calculation completed [0.580000 sec]
.....

```

1.1.14 default-information originate

Syntax

To introduce the default route to the OSPFv3 routing domain, run the following command:

```

default-information originate [ always | metric value | metric-type {1 | 2} | tag tag ]
no default-information originate

```

Parameter

Parameter	Description
Always	Generates and releases an ASE-LSA, which describes the default route, or just releases it out if the default route exists in the routing table.
metric <i>value</i>	Stands for the cost of the default route, which ranges from 1 to 16777214.
metric-type	Means the cost type of the default route.
tag <i>tag</i>	Means the routing identifier, which ranges from 0 to 4294967295.

Default value

No default route is introduced.

Command mode

Routing configuration mode

Usage guidelines

The redistribute command cannot introduce the default route, and if you want to introduce the default route, you can use this command.

If the **always** parameter is set, no matter whether the default route exists in the current routing table, ASE-LSA, describing the default route, will be released out; if the **always** parameter is not set, ASE-LSA will be released out only when the default route exists in the current routing table.

Example

The following example shows how to introduce the default route from the OSPFv3 autonomous system.

```
router ospfv3 1
  router-id 2.2.2.2
  default-information originate always
```

Related command

redistribute

1.1.15 default-metric

Syntax

To set the default weight of the introduced route, run the first one of the following two commands:

default-metric *value*

no default-metric

Parameter

Parameter	Description
<i>value</i>	Stands for the to-be-set route weight, ranging between 1 and 16777214.

Default value

The default route weight is 10.

Command mode

Routing configuration mode

Usage guidelines

The **default-metric** command is used to set the default routing weight when the route of other routing protocol is guided into the OSPF packet. When the **redistribute** command is used to guide the route of other routing protocol, the default routing weight designated by the **default-metric** command will be guided the specific routing weight will not be specified.

Example

The following example shows how to introduce the static route and set the default route weight of other routing protocol to 3:

```
interface vlan 1
  ipv6 address 2001::1/64
  ipv6 ospf 1 area 36.0.0.0
!
router ospfv3 1
  router-id 2.2.2.2
  default-metric 3
  redistribute static
```

Related command

redistribute

1.1.16 filter

Syntax

To set the routing filtration table, run **filter**. To resume the default settings, run **no filter**.

filter {*vlan* *vlan-interface-number* | *} {*in* | *out* } {**access-list** *access-list-name* | **gateway** *access-list-name* | **prefix-list** *prefix-list-name*}

no filter {*vlan* *vlan-interface-number* | *} {*in* | *out* }

Parameter

vlan	Vlan interface
<i>vlan-interface-number</i>	Interface number
*	All interfaces
<i>In</i>	Filtrates the received OSPF routes.
<i>out</i>	Filters the transmitted routes, which is not for a specific interface but for all interfaces.
<i>access-list-name</i>	Name of the IP access control list
<i>access-list-name</i>	Name of the IP access control list
<i>prefix-list-name</i>	Name of the prefix list

Default value

None

Command mode

Routing configuration mode

Example

The following example shows how to filter the received routes according to the **mylist** ACL.

```
router ospfv3 1
  filter * in access-list mylist
```

Related command

None

1.1.17 ipv6 ospf area**Syntax**

To enable the OSPFv3 protocol on an interface and specify an area for this interface, run the first one of the following two commands:

ipv6 ospf *process-id* **area** *area-id* [**instance** *instance-id*]

no ipv6 ospf *process-id* **area** *area-id* [**instance** *instance-id*]

Parameter

Parameter	Description
<i>process-id</i>	Stands for the OSPF process.
<i>area-id</i>	Stands for the OSPF area ID, which is specified by the interface.
<i>instance-id</i>	Specifies the OSPF instance ID of the interface, whose default value is 0.

Default value

None

Command mode

Interface configuration mode

Example

The following example shows how to enable OSPFv3 process 1 for interface vlan1 and set its area ID to 0.

```

interface vlan 1
  ipv6 address 2001::1/64
  ipv6 ospf 1 area 0
!
router ospfv3 1
  router-id 2.2.2.2

```

Related command

None

1.1.18 **ipv6 ospf cost**

Syntax

To designate the cost for the OSPFv3 protocol running on the interface, run **ipv6 ospf cost cost**. To resume the default settings, run **no ipv6 ospf cost**.

ipv6 ospf cost cost [**instance** *instance-id*]

no ipv6 ospf cost cost [**instance** *instance-id*]

Parameter

Parameter	Description
<i>cost</i>	Cost for the OSPF protocol, which is an integer between 1 and 65535
<i>instance-id</i>	Specifies the OSPF instance ID of the interface, whose default value is 0.

Default value

The default cost for the OSPFv3 protocol running on the interface is obtained based on the rate of the port.

Command mode

Interface configuration mode

Example

The following example shows how to set the cost for the OSPFv3 protocol running on interface vlan1 to 2:

```

interface vlan 1
  ipv6 ospf cost 2

```

Related command

None

1.1.19 **ipv6** ospf database-filter all out

Syntax

To designate an interface to filter those to-be-transmitted LSA, run the first one of the following two commands:

ipv6 ospf database-filter all out [*instance instance-id*]

no ipv6 ospf database-filter all out [*instance instance-id*]

Parameter

Parameter	Description
<i>instance-id</i>	Specifies the OSPF instance ID of the interface, whose default value is 0.

Default value

The interface does not filter those to-be-transmitted LSAs.

Command mode

Interface configuration mode

Example

The following example shows how to set interface vlan 1 to filter those to-be-transmitted LSAs:

```
interface vlan 1
  ipv6 ospf database-filter all out
```

Related command

None

1.1.20 **ipv6** ospf dead-interval

Syntax

To designate the dead interval of the neighboring router, run **ipv6 ospf dead-interval seconds**. To resume the default value, run **ipv6 ospf dead-interval**.

ipv6 ospf dead-interval *seconds* [**instance** *instance-id*]

no ipv6 ospf dead-interval *seconds* [**instance** *instance-id*]

Parameter

Parameter	Description
<i>seconds</i>	Value of the dead interval for the neighboring router, which ranges from 1 to 2147483647 seconds
<i>instance-id</i>	Specifies the OSPF instance ID of the interface, whose default value is 0.

Default value

The dead interval for the neighboring router is four times of hello-interval by default.

Command mode

Interface configuration mode

Usage guidelines

The value of the **dead-interval** parameter will be written to the HELLO packet and will be transmitted along with the HELLO packet. It must be ensured that the **dead-interval** parameter must be identical with that between the neighboring routers and the value of the **dead-interval** parameter must be four times of the value of the **hello-interval** parameter.

Example

The following example shows how to set the dead interval of the neighboring router on interface vlan1 to 60 seconds.

```
interface vlan 1
  ipv6 ospf dead-interval 60
```

Related command

None

1.1.21 **ipv6 ospf hello-interval**

Syntax

To designate the interval for transmitting the HELLO packet on the interface, run **ipv6 ospf hello-interval** *seconds*. To resume the default settings, run **no ipv6 ospf hello-interval**.

ipv6 ospf hello-interval *seconds* [**instance** *instance-id*]

no ipv6 ospf hello-interval *seconds* [**instance** *instance-id*]

Parameter

Parameter	Description
<i>seconds</i>	Transmission interval of the HELLO packet, ranging from 1 to 65535 seconds
<i>instance-id</i>	Specifies the OSPF instance ID of the interface, whose default value is 0.

Default value

The interval for the P2P or Broadcast interface to send Hello packets is 10 seconds, while the interval for the P2MP or NBMA interface to send Hello packets is 30 seconds.

Command mode

Interface configuration mode

Usage guidelines

The value of the **dead-interval** parameter will be written to the HELLO packet and will be transmitted along with the HELLO packet. The smaller the hello-interval is, the sooner the change of the network topology will be found. However, much more path cost will be paid. It must be ensured that the parameter must be identical with that between the neighboring routers.

Example

The following example shows that the interval for transmitting the HELLO packet on interface vlan1 is set to 20 seconds.

```
interface vlan 1
    ipv6 ospf hello-interval 20
```

Related command

ipv6 ospf dead-interval

1.1.22 **ipv6 ospf mtu-ignore**

Syntax

To set the MTU value of the transmitted DD packet to 0 on an interface and meanwhile omit the checkup of the MTU domain of the received DD packet, run the first one of the following two commands:

ipv6 ospf mtu-ignore [*instance instance-id*]

no ipv6 ospf mtu-ignore [*instance instance-id*]

Parameter

Parameter	Description
<i>instance-id</i>	Specifies the OSPF instance ID of the interface, whose default value is 0.

Default value

The value of the MTU domain of the DD packet is set to be the MTU value of this interface and MTU checkup is not omitted.

Command mode

Interface configuration mode

Usage guidelines

OSPF judges whether the MTU value of the network segment, where an interface belongs, is consistent by checking the MTU value of the exchanged DD packet. If the MTU value of the received DD packet is bigger than the MTU value of this interface, the OSPF neighborhood cannot be set up.

Example

The following example shows how to set interface vlan1 to omit MTU checkup.

```
interface vlan 1
    ipv6 ospf mtu-ignore
```

Related command

None

1.1.23 **ipv6 ospf neighbor**

Syntax

To set the OSPF neighbor on the non-broadcast network interface, run the first one of the following two commands:

ipv6 ospf neighbor *router-id ipv6-address* [*cost number*] [*database-filter all out*] [*poll-interval seconds*] [*priority number*] [*instance instance-id*]

no ipv6 ospf neighbor *router-id ipv6-address* [*cost number*] [*database-filter all out*] [*poll-interval seconds*] [*priority number*] [*instance instance-id*]

Parameter

Parameter	Description
router-id	Means the router ID of a neighbor.
<i>ipv6-address</i>	Means the local address of the neighbor's link.
cost <i>number</i>	Means the neighbor's cost, whose value ranges from 1 to 65535.
database-filter all out	Filters the transmitted LSAs.
poll-interval <i>seconds</i>	Means the query interval of a neighbor.
priority <i>number</i>	Means the neighbor's priority, whose value ranges from 0 to 255.
instance <i>instance-id</i>	Specifies the OSPF instance ID of the interface, whose default value is 0.

Default value

No neighbors are set.

Command mode

Interface configuration mode

Usage guidelines

You shall specify a neighbor manually on the non-broadcast network. If neighbors invalidate, the Hello packet should be sent to this neighbor in poll interval.

Example

The following example shows how to set the neighbor of interface vlan1.

```
interface vlan 1
```

```
    ipv6 ospf neighbor 1.1.1.1 FE80::FEFA:F7FF:FE2E:2B63
```

Related command

None

1.1.24 **ipv6** ospf network

Syntax

To set the network type for the interface, run the first one of the following two commands.

ipv6 ospf network { broadcast | non-broadcast | point_to_multipoint [broadcast | non-broadcast] | point-to-point} [instance *instance-id*]

no ip ospf network { broadcast | nonbroadcast | point_to_multipoint [broadcast | non-broadcast] | point-to-point} [instance *instance-id*]

Parameter

Parameter	Description
broadcast	Sets the network type of the interface to broadcast .
nonbroadcast	Sets the network type of the interface to NBMA .
point-to-multipoint	Sets the network type of the interface to point-to-multipoint .
point-to-point	Sets the network type of the interface to point-to-point .
instance <i>instance-id</i>	Specifies the OSPF instance ID of the interface, whose default value is 0.

Command mode

Interface configuration mode

Usage guidelines

The interface in the broadcast network without multi-address access should be set to NBMA. In the NBMA network, the network should be set to **point-to-multipoint** if any two routers cannot be ensured to be directly reachable.

Example

The following example shows how to set interface vlan1 to NBMA.

```
interface vlan 1
    ipv6 ospf network non-broadcast
```

Related command

None

1.1.25 **ipv6 ospf priority**

Syntax

To configure the priority for the interface to choose the router, run **ipv6 ospf priority *priority***. To resume the default value, run **no ipv6 ospf priority**.

ipv6 ospf priority *priority* [instance *instance-id*]

no ipv6 ospf priority *priority* [instance *instance-id*]

Parameter

Parameter	Description
<i>priority</i>	Priority to choose the router, ranging between 0 and 255
<i>instance-id</i>	Specifies the OSPF instance ID of the interface, whose default value is 0.

Default value

The default priority for the interface to choose the routers is 1.

Command mode

Interface configuration mode

Usage guidelines

When two routers in the same network segment want to be the selection router, the router with higher priority will be selected. If the priority of the two routers is the same, the router with a larger ID is selected. When the priority of a router is 0, the router cannot be selected as the designated router or the standby designated router. The priority is effective only on the networks except the nonpoint-to-point network.

Example

The following example shows how to set the priority to 8 when interface vlan1 selects the selection router.

```
interface vlan 1
  ipv6 ospf priority 8
```

Related command

None

1.1.26 **ipv6 ospf retransmit-interval**

Syntax

To designate the retransmission interval for transmitting LSA between the interface and the neighboring router, run **ipv6 ospf retransmit-interval seconds**. To resume the default value, run **no ipv6 ospf retransmit-interval**.

ipv6 ospf retransmit-interval seconds [*instance instance-id*]

no ipv6 ospf retransmit-interval seconds [*instance instance-id*]

Parameter

Parameter	Description
<i>seconds</i>	Transmission interval for transmitting the link state broadcast between the interface and the neighboring router, ranging between 1 and 3600 seconds
<i>instance-id</i>	Specifies the OSPF instance ID of the interface, whose default value is 0.

Default value

The default interval for transmitting the link state broadcast between the interface and the neighboring router is 5 seconds.

Command mode

Interface configuration mode

Usage guidelines

When a router transmits the link-state broadcast to its neighbor, the command will maintain the link-state broadcast until the peer receives the acknowledgement. If the link-state broadcast is not received during the transmission interval, it will be retransmitted. The value of the **seconds** parameter must be larger than the round-trip time for a packet transmitting between two routers.

Example

The following example shows how the default interval for transmitting the link-state broadcast between interface vlan1 and the neighboring router is set to 8 seconds.

```
interface vlan 1
  ipv6 ospf retransmit-interval 8
```

Related command

None

1.1.27 **ipv6 ospf transmit-delay**

Syntax

To set the delay for the link-state broadcast to be transmitted on the interface, run **ipv6 ospf transit-delay time**. To resume the default value, run **no ipv6 ospf transit-delay**.

ipv6 ospf transmit-delay time [*instance instance-id*]

no ipv6 ospf transmit-delay time [*instance instance-id*]

Parameter

Parameter	Description
<i>time</i>	Means the delay of link state broadcast transmission on an interface, which ranges from 1 to 3600 seconds.
<i>instance-id</i>	Specifies the OSPF instance ID of the interface, whose default value is 0.

Default value

The default delay for the link-state broadcast to be transmitted on the interface is 1 second.

Command mode

Interface configuration mode

Example

The following example shows how to set the delay for transmitting the link-state broadcast on interface vlan1 to 3 seconds.

```
interface vlan 1
  ipv6 ospf transmit-delay 3
```

Related command

None

1.1.28 passive-interface

Syntax

To forbid a designated interface to transmit or receive the OSPFv3 packets, run the first one of the following two commands:

passive-interface { *interface-type* *interface-number* | all }

no passive -interface { *interface-type* *interface-number* | all }

Parameter

Parameter	Description
<i>interface-type</i> <i>interface-number</i>	Means the interface type and the interface ID.
all	Means all interfaces.

Default value

The interface is allowed to transmit or receive the OSPFv3 packets.

Command mode

Routing configuration mode

Usage guidelines

Different processes can forbid a same interface to transmit or receive the OSPFv3 packets, but the passive-interface command takes effect only on the OSPFv3 interface.

Example

The following example shows how to forbid interface vlan1 to receive and transmit the OSPFv3 packets in the OSPFv3 process.

```
router ospfv3 100
  passive-interface vlan 1
```

Related command

None

1.1.29 redistribute**Syntax**

To configure the route where OSPF forwards other routing protocols, run **redistribute**. To resume the default settings, run **no redistribute**.

redistribute protocol [*as-number*] [**route-map** map-tag]

no redistribute protocol [*as-number*] [**route-map**]

Parameter

Parameter	Description
protocol	Means to forward the learned original protocol.
<i>as_number</i>	Means the number of the autonomous system which is not for the connect or static parameter.
<i>map-tag</i>	Means the name of the route map.

Default value

Not forward

Command mode

Routing configuration mode

Usage guidelines

None

Example

The following example shows how to forward the static route in OSPF process 1:

```
interface vlan 1
  ipv6 ospf 1 area 0
!
router ospfv3 1
  router-id 2.2.2.2
  redistribute static
```

1.1.30 router ospfv3**Syntax**

To enable OSPFv3 and enter the OSPFv3 configuration view, run the first one of the following two commands:

router ospfv3 *process-id*

no router ospfv3 *process-id*

Parameter

Parameter	Description
<i>process-id</i>	Identifies the OSPF process. It is a positive integer distributed by the local router.

Default value

None

Command mode

Global configuration mode

Usage guidelines

One router may have multiple OSPFv3 processes.

Example

The following example shows how to set an OSPFv3 process, whose process ID is 109:

```
router ospfv3 109
```

Related command

ipv6 ospf area

1.1.31 **router-id**

Syntax

To set the router ID in the autonomous system for the router on which the OSPFv3 protocol is running, run the first one of the following two commands:

router-id *router-id*

no router-id *router-id*

Parameter

Parameter	Description
<i>router-id</i>	Means the identifier of the router, which is in the IPv4 address format.

Default value

If an IPv4 address has already configured on a router before OSPFv3 is enabled, the router will automatically choose an IPv4 address as its ID.

Command mode

Routing configuration mode

Usage guidelines

The router ID is the unique identifier of a OSPFv3-running router in the autonomous system, so the router IDs of two routers in the autonomous system are different. If a router has no router ID, the OSPFv3 process cannot go on.

Example

The following example shows how to set the router ID of OSPFv3 process 1 to 2.2.2.2:

```
router ospfv3 1
  router-id 2.2.2.2
```

1.1.32 show ipv6 ospf

Syntax

To display the main OSPFv3 information, run the following command:

show ipv6 ospf [*process-id*]

Parameter

Parameter	Description
<i>process-id</i>	Means the OSPF process ID.

Default value

None

Command mode

EXEC

Usage guidelines

The information exported by the command can help checking the OSPFv3 faults. If the **process-id** parameter follows the command, the information about the global configuration of the OSPFv3 process is displayed.

Example

The following example shows that the configuration information about all OSPFv3 processes will be displayed.

```
Switch#show ipv6 ospf 1
Routing Process "OSPFv3 (1)" with ID 1.1.1.1, 0x7266520
SPF schedule delay 5 secs, Hold time between SPFs 10 secs
Minimum LSA interval 5 secs, Minimum LSA arrival 1 secs
LSDB age interval 60 secs
Number of external LSA 0. (0x4d5d4e0). Checksum Sum 0x0000
Number of AS-Scoped Unknown LSA 0
Number of LSA originated 7
```

Number of LSA received 15
 Number of areas in this router is 2
 Number of transit areas in this router is 0
 Area BACKBONE(0), 0x71b7730
 Number of interfaces in this area is 1
 SPF algorithm executed 4 times
 Number of LSA 6. (0x4d5cfe0). Checksum Sum 0x40FB3
 Number of Unknown LSA 0
 Area 0.0.0.1, 0x71b6de8
 Number of interfaces in this area is 1
 SPF algorithm executed 1 times
 Number of LSA 3. (0x4d59278). Checksum Sum 0x191B6
 Number of Unknown LSA 0

Relative fields are explained in the following table:

Domain	Description
Routing Process "OSPFv3 1"	ID of the process
with ID 1.1.1.1	ID of the router
SPF schedule delay 5 secs, Hold time between SPFs 10 secs	Two timer values relative with OSPF
Number of areas in this router is 2	Number of the currently-configured fields, and parameters configured in each field
Number of LSA originated / received 7 /15	The number of received and generated quantity of LSAs is 7, 15 respectively.
Number of external LSA 0	Number of fifth type lsa in the database
SPF algorithm executed 4 times	SPF algorithm execution statistics

1.1.33 **show ipv6 ospf database**

Syntax

To display the database information about the OSPFv3 connection state, run the following command:

show ipv6 ospf database [router | network | inter-prefix | inter-router | external | nssa
| link | intra-prefix][adv-router router-id][database-summary]

Parameter

Parameter	Description
<i>router</i>	Means the LSA type is the router.
<i>network</i>	Means the LSA type is the network.
<i>inter-prefix</i>	Means the LSA type is the inter-domain route.
<i>inter-router</i>	Means the LSA type is the inter-domain router.
<i>external</i>	Means the LSA type is the exterior route.
<i>nssa</i>	Means the LSA type is the nssa exterior route.
<i>link</i>	Means the LSA type is the link.
<i>intra-prefix</i>	Means the LSA type is the inside-domain route.
<i>adv-router</i>	Means to declare the router ID.
<i>database-summary</i>	Means to show database summary.

Default value

None

Command mode

EXEC

Usage guidelines

The information exported by the command can help to check the database information about the OSPFv3 connection state and to find the reason of the faults.

Example

```
Switch#show ipv6 ospf data
```

```
OSPFv3 Router with ID (1.1.1.1) (Process 1)
```

```
Link-LSA (Interface VLAN1)
```

Link State ID	ADV Router	Age Seq#	CkSum	Prefix
0.0.0.26	1.1.1.1	396 0x80000001	0x6517	1
0.0.0.3	5.6.2.1	442 0x80000001	0xf2cb	1
0.0.0.6	11.1.1.1	433 0x80000001	0x4146	1

```
Router-LSA (Area 0.0.0.0)
```

Link State ID	ADV Router	Age Seq#	CkSum	Link
0.0.0.0	1.1.1.1	320 0x80000004	0x30b8	1

0.0.0.0	5.6.2.1	21 0x80000006 0x985a	1
0.0.0.0	11.1.1.1	388 0x80000004 0xb93a	1

Network-LSA (Area 0.0.0.0)

Link State ID	ADV Router	Age Seq#	CkSum
0.0.0.6	11.1.1.1	389 0x80000002 0xfb3	

Inter-Area-Prefix-LSA (Area 0.0.0.0)

Link State ID	ADV Router	Age Seq#	CkSum
0.0.0.1	1.1.1.1	315 0x80000002 0xe69c	

Intra-Area-Prefix-LSA (Area 0.0.0.0)

Link State ID	ADV Router	Age Seq#	CkSum	Prefix	Reference
0.0.0.2	11.1.1.1	387 0x80000001 0xaed1		1	Network-LSA

.....

Relative fields are explained in the following table:

Domain	Description
Area 0.0.0.0	Current area
Link-LSA	LSA type
Link State ID	LSA ID
ADV Router	Releases the router.
Age	Releases the age.
Seq #	Generates the sequence ID.
Checksum	Means the checksum.

1.1.34 **show** ipv6 ospf interface

Syntax

To display the information about the OSPFv3 interface, run the following command:

show ipv6 ospf interface [type] [index]

Parameter

Parameter	Description
<i>type</i>	Port type
<i>index</i>	Port number

Default value

None

Command mode

EXEC

Usage guidelines

According to the information displayed by the command, you can check the OSPFv3 configuration and its running state, which helps you to detect the OSPFv3 faults.

Example

Switch# **show ipv6 ospf interface**

VLAN1 is up, line protocol is up

Interface ID 26, Interface MTU 1500

Interface bandwidth 1000000

IPv6 Prefixes

2001::1/64

fe80::fefa:f7ff:fe2e:2b63/64 (Link-Local Address)

OSPFv3 Process (1), Area 0.0.0.0, Instance ID 0, 0x71b7520

Router ID 1.1.1.1, Network Type BROADCAST, Cost: 1

Transmit Delay is 1 sec, State DROther, Priority 1

Designated Router (ID) 11.1.1.1

Interface Address fe80::fefa:f7ff:fe81:139

Backup Designated Router (ID) 5.6.2.1

Interface Address fe80::2e0:fff:fe87:0

Timer interval configured, Hello 10, Dead 40, Wait 40, Retransmit 5

Hello due in 00:00:04

Neighbor Count is 2, Adjacent neighbor count is 2

Number of LSA 3. (0x4d5c7e8). Checksum Sum 0x19928

Number of Unknown LSA 0

.....

Switch#

Relative fields are explained in the following table:

Domain	Description
Link-Local Address	Address of port IPv6 link-local
Nettype	Network type of the OSPF interface
OSPFv3 Process (1)	ID of the OSPF process
Area 0.0.0.0	Current backbone domain
Router ID	ID of the router where the process belongs

Cost	Cost of the OSPF interface of the router
Transmit Delay is	Transmission delay
Priority	Priority for the interface of the router
Hello interval	Transmission interval of the Hello packet
Dead timer	Dead time
Retransmit	Retransmission interval
State	State of the OSPF port
Designated Router (ID)	ID of the designated router and the IP address of its port
Backup Designated Router (ID)	ID of the backup designated router and the IP address of its port
Neighbor Count is	Number of the neighboring routers
Adjacent neighbor count is	Number of neighbors that have established the neighborhood relation

1.1.35 **show** ipv6 ospf neighbor

Syntax

To display the information about OSPFv3 neighbor, run the following command.

show ipv6 ospf neighbor [*interface_type interface_number* | *router-id* | *detail*]

Parameter

Parameter	Description
interface_type	Port type
interface_number	Port number
<i>router-id</i>	Router ID
<i>detail</i>	Displays the detailed information.

Default value

None

Command mode

EXEC

Usage guidelines

The information displayed by the command can help you to check whether the OSPFv3 neighbor configuration is right and to detect the OSPFv3 faults.

Example

```
Switch#show ipv6 ospf neighbor
```

```
OSPFv3 Process (1)
```

Neighbor ID	Pri	State	Dead Time	Interface	Instance ID
5.6.2.1	1	Full/Backup	00:00:31	VLAN1	0
11.1.1.1	1	Full/DR	00:00:32	VLAN1	0

```
Switch#
```

Relative fields are explained in the following table:

Domain	Description
OSPFv3 process	ID of the OSPF process
Neighbor	ID of a neighbor
Pri	Priority of a neighbor
State	Connection state related with the neighbor
DeadTime	Time of neighbor invalidation
Interface	Interface used by a router to reach its neighbor
Instance ID	Instance ID number

1.1.36 **show ipv6 ospf route**

Syntax

To display the information about the OSPFv3 routing table, run the following command:

show ipv6 ospf route

Parameter

None

Default value

None

Command mode

EXEC

Usage guidelines

The information displayed by the command can help you browse the OSPFv3 routing table and confirm whether the OSPFv3 trouble diagnosis is correctly carried out.

Example

```
Switch#show ipv6 ospf route
OSPFv3 Process (1)
  Destination                                Metric
  Next-hop
C  23::1/128                                1
    directly connected, Loopback9
IA 52::1/128                                2
    via fe80::fefa:f7ff:fe81:139, VLAN1
E2 99::1/128                                1/150
    via fe80::2e0:fff:fe87:0, VLAN1
C  2001::/64                                1
    directly connected, VLAN1
Switch#
```

Relative fields are explained in the following table:

Domain	Description
Destination	Destination network segment
Metric	Cost of a route
Next-hop	Address of the next hop

1.1.37 show ipv6 ospf virtual-link

Syntax

To display the information about the OSPFv3 virtual link, run the following command:

show ipv6 ospf virtual-link

Parameter

None

Default value

None

Command mode

EXEC

Usage guidelines

According to the information exported by the command, you can check the state of the OSPFv3 virtual link.

You can run **show ipv6 ospf neighbor** to check the detailed information about the adjacent neighbor.

Example

Switch #show ipv6 ospf virtual-link

Virtual Link VLINK1 to router 5.6.7.8 is up

Transit area 0.0.0.1 via interface eth0, instance ID 0

Local address 3ffe:1234:1::1/128

Remote address 3ffe:5678:3::1/128

Transmit Delay is 1 sec, State Point-To-Point,

Timer intervals configured, Hello 10, Dead 40, Wait 40, Retransmit 5

Hello due in 00:00:01

Adjacency state Up

Relative fields are explained in the following table:

Domain	Description
neighbor ID	Neighbor ID of the peer
neighbor state	Neighborhood state for the neighbor
TransArea	Transmission area
cost	Minimum cost for reaching the peer in the transmission area If the value of the cost is 0, it means that the peer is unreachable.
Hello Interval	Current transmission interval for the Hello packet
DeadTime	Time of neighbor invalidation
Retrans	Retransmission interval
Adjacency state	State of the virtual link interface

Related command

area virtual-link

show ipv6 ospf neighbor

1.1.38 summary-prefix

Syntax

To configure the address for OSPFv3 to create the route aggregation, run **summary-prefix**. To cancel the address of route aggregation, run **no summary-prefix**.

summary-prefix *ipv6-prefix /prefix-length [not-advertise]*

no summary-prefix *ipv6-prefix /prefix-length [not-advertise]*

Parameter

Parameter	Description
<i>ipv6-prefix</i>	Aggregation address with the designated address range
<i>prefix-length</i>	Subnet mask of the aggregation route
<i>not-advertise</i>	<i>Do not post</i>

Default value

None

Command mode

Routing configuration mode

Usage guidelines

Multiple groups of addresses are summarized. Routes learned from other routing protocols can also be summarized. After the aggregation, all covered networks cannot be transmitted to other routing fields. The cost of the summary route is the minimum value among the cost values of all summary routes. The command cannot be used to reduce the size of the routing table.

The command is used by OSPFv3 to enable the ASBR to notify an external route of being an aggregation route to replace all external routes. The command is only used to aggregate the OSPFv3 routes of other routing protocols. You can run **area range** in OSPFv3 to summarize the routes.

Example

In the following example, the summary address 2001::/64 stands for addresses such as 2001::/80, 2001::1/64 and so on, and only address 2001::/64 is broadcasted.

```
summary-prefix 2001::/64
```

Related command

area range

1.1.39 **timers delay**

Syntax

To designate a delay interval between OSPF receiving a topology change and starting a shortest path priority calculation, run **timers delay *spf-delay***. To resume the default settings, run **no timers delay**.

timers delay *spf-delay*

no timers delay *spf-delay*

Parameter

Parameter	Description
<i>spf-delay</i>	Delay between the topology change and calculation start, ranges from 0 to 65535. Its default value is 5 seconds. If the value is 0, there is no delay. That is, the calculation will be promptly started if changes occur.

Default value

spf-delay: 5 seconds

Command mode

Routing configuration mode

Usage guidelines

The smaller value the delay is set to, the faster the network change is reflected. However, it will take the processor more time.

Example

The following example shows how to set the time for OSPF to start calculating the delay is 10 seconds.

```
timers delay 10
```

1.1.40 **timers hold**

Syntax

To set the interval between two continuous SPF calculations, run **timers hold**. To resume the default settings, run **no timers hold**.

timers hold *spf-holdtime*

no timers hold *spf-holdtime*

Parameter

Parameter	Description
<i>spf-holdtime</i>	Minimum value between two continuous calculations. It ranges between 0 to 65535 seconds. Its default value is 10 seconds; when it is 0, there is no interval between the two continuous calculations.

Default value

spf-holdtime: 10 seconds

Command mode

Routing configuration mode

Usage guidelines

The smaller value the delay is set to, the faster the network change is reflected. However, it will take the processor more time.

Example

The following example shows how to set the interval between two successive SPF calculations to 20 seconds:

```
timers hold 20
```

1.1.41 **timers age**

Syntax

To configure the time interval of OSPF checking LSA database aging, run the following command. To return to the default setting, use the no form of this command.

timers age *agetime*

no timers age *agetime*

Parameter

Parameter	Description
<i>agetime</i>	Check LSDB database every <i>agetime</i> second and delete aging lsa.

Default value

agetime: 60 seconds

Command mode

Routing configuration mode

Usage guidelines

The smaller the time interval, the faster the database reflects but with more time for the processor.

Example

The following example shows how to set the aging time of OSPF checking LSDB to 50 seconds.

```
timers age 50
```