HOW TO SECURE THE WIRELESS NETWORK ON DG-HR3420?

STEP 1: ACCESSING THE WEB CONFIGURATION PAGE OF THE ROUTER

Open the configuration page of the router by typing http://192.168.1.1 in a web browser. We recommend this one time configuration to be done using Internet Explorer.

Enter the username as admin and password as 1234 and click on Login



STEP 2: CONFIGURE WIRELESS SETTINGS

Click on Setup > Wireless> Basic

Under Wireless Basic Settings, change the SSID. It is your wireless network name.

Change Channel Number to any non-interfering one like 6, 9 or 11.

Click on Apply Changes.



STEP 3: CONFIGURE WIRELESS SECURITY

Click on **Security** on the left hand side.

Under SSID **TYPE**, select **Root**

Select **Encryption** as **WPA 2(AES)**



Under **Pre-Shared Key format** select **Passphrase**

In **Pre-Shared Key**, enter the new wireless password

Note: Make sure that the Pre-Shared Key is of minimum 8 characters which can be alphanumeric.

Click on **Apply Changes**.



Now scan for the wireless network on your wireless clients e.g. Laptops, smart phones etc. Connect to it using the pre-shared key configured on the router. (Eg. Digi1234 as above)

You will now be able to use internet on your laptop and smart phones using Digisol wireless network.