

**Digisol device is not showing any LEDs. What do I do?****Solution:**

1. Verify if the power LED is glowing or no
2. Check if the power adapter is secure on the power port
3. Check if the Power Button is turned On
4. Check if the device is connected to a UPS or a direct power socket
5. By pass the UPS and try connecting to a direct power socket
6. Try connecting to a different power socket
7. In case another power adapter is available of same ratings(volts, Amps), try to power ON the device
8. In case the device uses a power cable, try using a working cable.
9. If issue persists, visit the nearest service center at : <https://www.digisol.com/service-centers/>