

**How to hard reset a router?****Solution:**

1. Locate a small hole or a reset button on the device
2. Keep the device powered On and use a metal pin to press the reset button for around 10-25 seconds
3. Notice the change in the LED indications
4. Device will reboot and the LEDs will get stable again
5. Once the LEDs are stable again, access the device with default configuration