

USB device is not detected on the PC. What could be the problem?**Solution:**

1. These steps will be true for either 3G adapter or wireless micro-USB adapters
2. Check the Operating System compatibility
3. Note the LED status whether the hardware is detected on the PC
4. Check the notification area on a windows PC for any errors or warnings
5. Check Device Manager to see if the USB driver / network adapter drivers are installed properly
6. If yellow exclamation mark noticed on the network adapter driver then try installing the drivers provided with the device or else manually updating them from Digisol website
7. Disable anti-virus and firewall or windows defender on the system