

Q : How to Configure 3G in DG-BG4300NU

A : Kindly follow the steps given below to Configure for 3G:

Step1: Enter 192.168.1.1 on the address bar and log in with the username/ password as admin / admin

Step2: Go to Setup >> WAN >> 3G

Step3: Under APN type airtelgprs.com, Dial number as *99# and username and password should be blank (APN and dial numbers would be as per ISP)

Step4: Click on Apply Changes

Step5: Reboot the router

Step6: Check if the Internet LED is Green and try to access internet