

Q : How to Configure Static IP in DG-HR3400**A :** Configure Static IP:

Step1: Connect ISP to the WAN port, PC to the LAN port

Step2: Open a browser and type 192.168.2.1 in the address bar and press Enter. Enter username as admin and password as 1234

Step3: Go to Setup > Internet Setup

Step4: Select WAN access type as Static IP

Step5: Enter the ISP provided IP Address, Subnet Mask, Default Gateway, DNS1, DNS2 correctly

Step6: Select MAC from PC under MAC clone option

Step7: Apply Changes

Reboot the router and try to access internet.