

Q : How to Port forwarding in DG-HR3400**A :** Port forwarding on DG-HR3400:

Step1: Open the web browser and login to 192.168.1.1
(user:admin / password: 1234)

Step2: Go to Advanced > Virtual Server

Step3: Select User defined service name >> Give any name

Step4: Protocol: TCP, Wan Settings: Interface, Wan Interface: PPPoE1

Step5: WAN Port: Enter the port number to be opened (eg: 80)

Step6: LAN Port : Re-enter the same port number as in WAN port

Step7: LAN IP Address : Enter the LAN IP of the device for which you want to open ports

Step8: Click on Apply Changes

Try accessing the device over the internet using the WAN IP: port number