

**Q : How to Configure Wireless security in DG-HR1400**

**A :** Configure Wireless security:

Step1: Open a browser and type 192.168.2, enter username as admin and password as 1234

Step2: Go to Wireless > Wireless Basics

Step3: Select Mode > AP

Step4: Change the SSID name to your choice (This is wireless network name visible to all)

Step5: Select Security options as WPA-PSK (TKIP)

Step6: Enter password for wireless network in pre-shared key (minimum 8 alpha numeric characters)

Step7: Click on Apply changes

Scan for the wireless network (SSID) and connect with the password (pre-shared key) to go online wirelessly