



DG-GS1512HP

8 Port Giga PoE Ethernet WEB
Smart Switch with 4 SFP Ports

User Manual

V1.0

2018-05-31

As our products undergo continuous development the specifications are subject to change without prior notice

COPYRIGHT

Copyright 2018 by Digisol Systems Ltd. All rights reserved.

Company has an ongoing policy of upgrading its products and it may be possible that information in this document is not up-to-date.

Please check with your local distributors for latest information. No part of this document can be copied or reproduced in any form without written consent from the company.

TRADEMARK

DIGISOL™ is a trademark of Digisol Systems Ltd. All other trademarks are the property of the respective manufacturers.

Table of Contents

Safety and Regulatory	8
1. Introduction	9
1.1. Overview	9
1.2. Package contents.....	9
1.3. Features.....	9
1.4. Product Components	10
1.4.1. Ports	10
1.4.2. LED Indicators	11
2. Installation.....	13
2.1. Mounting the Switch	13
2.1.1. Placement Tips.....	13
2.1.2. Rack Mounting	15
3. Getting Started.....	17
3.1. Power	17
3.1.1. Connecting to Power	17
3.1.2. Connecting to the Network	18
3.1.3. Power over Ethernet (PoE) Considerations	19
3.1.4. Starting the Web-based Configuration Utility	20
3.1.5. Logging In	22
Logging Out	22
4. Web-based Switch Configuration	24
4.1. Status	25
4.1.1. System Information	25

4.1.2. Port	27
4.1.2.1. Statistics	27
4.1.2.2. Error Disabled	30
4.1.2.3. Bandwidth Utilization	31
4.1.3. Link Aggregation	32
4.1.4. MAC Address Table	33
4.2. Network	34
4.2.1. IP Address	34
4.2.2. System Time	36
4.3. Port	39
4.3.1. Port Setting	39
4.3.2. Error Disable	42
4.3.3. Link Aggregation	44
4.3.3.1. Group	44
4.3.3.2. Port Setting	46
4.3.3.3. LACP	48
4.3.4. EEE	50
4.3.5. Jumbo Frame	52
4.4. PoE	53
4.4.1. Global Setting	53
4.4.2. Priority Setting	54
4.4.3. Power Limit	55
4.4.4. Power show	56
4.5. VLAN	57
4.5.1. VLAN	57

4.5.1.1. Create VLAN.....	58
4.5.1.2. VLAN Configuration	59
4.5.1.3. Membership	61
4.5.1.4. Port Setting.....	63
4.5.2. Voice VLAN.....	65
4.5.2.1. Property	65
4.5.2.2. Voice OUI	67
4.5.4. MAC VLAN	69
4.5.4.1. MAC Group.....	69
4.5.4.2. Group Binding	70
4.6. MAC Address Table.....	72
4.6.1. Dynamic Address	72
4.6.2. Static Address	72
4.6.3. Filtering Address	73
4.7. Spanning Tree.....	74
4.7.1. Property.....	74
4.7.2. Port Setting	76
4.7.3. MST Instance.....	80
4.7.4. MST Port Setting	82
4.7.5. Statistics.....	84
4.8. Discovery.....	86
4.8.1. LLDP.....	86
4.8.1.1. Property	87
4.8.1.2. Port Setting.....	88
4.8.1.3. Packet View	90
4.8.1.4. Local Information.....	93

4.8.1.5. Neighbor.....	95
4.8.1.6. Statistics	97
4.9. Multicast	99
4.9.1. General.....	100
4.9.1.1. Property	100
4.9.1.2. Group Address.....	101
4.9.1.3. Router Port	103
4.9.2. IGMP Snooping	106
4.9.2.1. Property	106
4.9.2.2. Querier	110
4.9.2.3. Statistics	111
4.9.4 MVR	113
4.9.4.1. Property	113
4.9.4.2. Port Setting.....	115
4.9.4.3. Group Address.....	116
4.10. Security	118
4.10.1. RADIUS.....	118
4.10.2. Management Access	121
4.10.2.1. Management Service	121
4.10.2.2. Management ACL	123
4.10.2.3. Management ACE.....	124
4.10.3. Authentication Manager.....	126
4.10.3.1. Property.....	126
4.10.3.2. Port Setting	132
4.10.3.3. Sessions	137
4.10.4. Port Security.....	139

4.10.5. Protected Port	141
4.10.6. Storm Control	142
4.10.7. DoS	145
4.10.7.1. Property.....	145
4.10.7.2. Port Setting	147
4.10.8. DHCP Snooping	148
4.10.8.1. Property.....	148
4.10.8.2. Statistics.....	150
4.10.8.3. Option82 Property	151
4.10.8.4. Option82 Circuit ID	153
4.10.9. IP Source Guard	155
4.10.9.1. Port Setting	155
4.10.9.2. IMPV Binding	157
4.10.9.3. Save Database.....	159
4.11. ACL	161
4.11.1. MAC ACL	161
4.11.2. MAC ACE	162
4.11.3. IPv4 ACL	165
4.11.4. IPv4 ACE	165
4.11.5. ACL Binding	170
4.12. QoS	172
4.12.1. General	172
4.12.1.1. Property.....	172
4.12.1.2. Queue Scheduling	174
4.12.1.3. CoS Mapping	176
4.12.1.5. IP Precedence Mapping	177

4.12.2. Rate Limit.....	178
4.12.2.1. Ingress/Egress Port.....	178
4.13. Diagnostics	180
4.13.1. Logging.....	180
4.13.1.1. Property.....	180
4.13.1.2. Remote Server.....	182
4.13.2. Mirroring	183
4.13.3. Ping.....	185
4.13.4. Traceroute.....	186
4.14. Management	187
4.14.1. User Account	187
4.14.2. Firmware.....	189
4.14.2.1. Upgrade / Backup	189
4.14.2.2. Active Image	193
4.14.3. Configuration	194
4.14.3.1. Upgrade / Backup	194
4.14.3.2. Save Configuration.....	199
4.14.4. SNMP.....	200
4.14.4.1. View	200
4.14.4.2. Group.....	201
4.14.4.3. Community	204
4.14.4.4. User	206
4.14.4.5. Engine ID.....	209
4.14.4.6. Trap Event	212
4.14.4.7. Notification.....	212
4.14.5. RMON	217

4.14.5.1. Statistics.....	217
4.14.5.2. History.....	220
4.14.5.3. Event.....	223
4.14.5.4. Alarm	226

Safety and Regulatory

Audience

This guide is for the networking professional managing the standalone DG-GS1512HP switch series. It is recommended that only professionals with experience working with networking devices who are familiar with the Ethernet and local area networking terminology, should service the equipment.

Conventions

The following conventions are used in this manual to convey instructions and information:

Command descriptions use these conventions:

- Commands and keywords are in boldface text.
- Arguments for which you supply values are in italic.
- Square brackets ([]) mean optional elements.
- Braces ({ }) group required choices, and vertical bars (|) separate the alternative elements.
- Braces and vertical bars within square brackets ([{ | }]) mean a required choice within an optional element.

Interactive examples use these conventions:

- Non printing characters, such as passwords or tabs, are in angle brackets (< >). Notes and cautions use the following conventions and symbols:



Note

Means additional information. Notes contain additional useful information or references to material available outside of this document.



Caution

Indicates that the reader must be careful. In a situation where a Caution is listed, a user may cause equipment damage or loss of data.

1. Introduction

Thank you for choosing a Digisol (PoE) WEB Smart Ethernet Switch. This device is designed to be operational right out-of-the-box as a standard bridge. In the default configuration, it will forward packets between connecting devices after powered up.

Before you begin installing the switch, make sure you have all of the package contents available, and a PC with a web browser for using web-based system management tools.

1.1. Overview

The Digisol DG-GS1512HP is a WEB Smart PoE switch with 8 Gigabit PoE+ ports + 4 SFP Ports respectively.

1.2. Package contents

Before using the product, check that the items listed below are included and in good condition. If any item does not accord with the table, please contact your dealer immediately.

- Digisol DG-GS1512HP WEB Smart PoE Switch
- Power Cord
- Manual CD
- Rack Mount Kit
- Foot pads
- QIG

1.3. Features

- Supports up to 12 10/100/1000Mbps Gigabit Ethernet ports and 4 SFP slots
- IEEE 802.3af/at PoE compliant to simplify deployment and installation
- Supports PoE up to 30W per port with 140W total power budget
- Automatically detects powered devices (PD) and power consumption levels

- IEEE 802.1Q VLAN allows network segmentation to enhance performance and security
- Supports Access Control List (ACL)
- Switch capacity: DG-GS1512HP: 24Gbps, Forwarding rate: 41.6Mpps
- Supports IGMP Snooping V1 / V2 / V3
- 8K MAC address table and 10K jumbo frames
- 19-inch rack-mountable metal case

1.4. Product Components

1.4.1. Ports

The following view applies to DG-GS1512HP.




Figure 1 - Front View

No.	Name	Description
1	10/100/1000Mbps RJ-45 ports (1~12)	Designed to connect to network devices with a bandwidth of 10Mbps, 100Mbps or 1000Mbps. Each has a corresponding 10/100/1000Mbps LED.
2	SFP ports (SFP1, SFP2, SFP3, and SFP4)	Designed to install SFP modules and connect to network devices with a bandwidth of 1000Mbps. Each has a corresponding 1000Mbps LED.

The following view applies to DG-GS1512HP.



Figure 2 - Rear View

No.	Name	Description
1	AC power in	Supports AC 100 – 240V, 50-60Hz.

1.4.2. LED Indicators

The following view applies to DG-GS1512HP.



1 2

Figure 3 - Front View LED Indicators

No.	Name	Description
1	System	<ul style="list-style-type: none"> Off: system not ready On: system ready <p>Blinking: system boot-up</p>

2	Power	<ul style="list-style-type: none">• Off: power off• On: power on
3	Port LED	LINK/ACT bi-color LED: <ul style="list-style-type: none">• Off: port disconnected or link fail• Green on: 1000Mbps connected, PoE power output on• Amber on: 10/100Mbps connected• Blinking: sending or receiving data
4	SFP LED	<ul style="list-style-type: none">• Off: port disconnected or link fail• Green on: 1000Mbps connected

2. Installation

This chapter describes how to install and connect your DG-GS1512HP Switch. Read the following topics and perform the procedures in the correct order. Incorrect installation may cause damage to the product.

2.1. Mounting the Switch

There are two ways to physically set up the switch.

- Place the switch on a flat surface. To place the switch on a desktop, install the four rubber feet (included) on the bottom of the switch.
- Mount the switch in a standard rack (1 rack unit high).

2.1.1. Placement Tips

- Ambient Temperature—To prevent the switch from overheating, do not operate it in an area that exceeds an ambient temperature of 122°F (50°C).
- Air Flow—Be sure that there is adequate air flow around the switch.
- Mechanical Loading—Be sure that the switch is level and stable to avoid any hazardous conditions.
- Circuit Overloading—Adding the switch to the power outlet must not overload that circuit.

Follow these guidelines to install the switch securely.

1. Put the switch in a stable place such as a desktop, to avoid it falling.
2. Ensure the switch works in the proper AC input range and matches the voltage labeled.
3. Ensure there is proper heat dissipation from and adequate ventilation around the switch.
4. Ensure the switch's location can support the weight of the switch and its accessories.




Figure 4 - Desktop Installation

2.1.2. Rack Mounting

You can mount the switch in any standard size, 19-inch (about 48 cm) wide rack. The switch requires 1 rack unit (RU) of space, which is 1.75 inches (44.45 mm) high.



For stability, load the rack from the bottom to the top, with the heaviest devices on the bottom. A top-heavy rack is likely to be unstable and may tip over.

When mounting smaller switch products into a standard 19-inch rack, a pair of extension brackets (sometimes referred to as ears) are needed to adapt the switch to the rack size.

These extension brackets are mounted on the switch using the screws provided in the kit, and have two holes that are used to then screw the switch into the rack.

An example of one type of these extension brackets is shown in the following figure.

A common problem that occurs during rack mounting is the distance between the screw holes on the rack. Some racks are made with a uniform distance between all of the holes, and others have the holes organized into groups (see photo on the next page for an example).

When organized into groups, the switch must be placed in the rack so that the holes in the extension brackets line up correctly.

1. Align the mounting brackets with the mounting holes on the switch's side panels and secure the brackets with the screws provided.




Figure 5 - Bracket Installation

2. Secure the switch on the equipment rack with the screws provided.




Figure 6 - Rack Installation

3. Getting Started

This section provides an introduction to the web-based configuration utility, and covers the following topics:

- Powering on the device
- Connecting to the network
- Power over Ethernet (PoE) considerations
- Starting the web-based configuration utility

3.1. Power

3.1.1. Connecting to Power



Power down and disconnect the power cord before servicing or wiring a switch.



Do not disconnect modules or cabling unless the power is first switched off. The device only supports the voltage outlined in the type plate. Do not use any other power components except those specifically designated for the switch.



Disconnect the power cord before installation or cable wiring.

The switch is powered by the AC 100-240 V 50/60Hz internal high-performance power supply. It is recommended to connect the switch with a single-phase three-wire power source with a neutral outlet, or a multifunctional computer professional source.

Connect the AC power connector on the back panel of the switch to the external power source with the included power cord, and check the power LED is on.




Figure 7 - Rear View AC Power Socket

3.1.2. Connecting to the Network

To connect the switch to the network:

1. Connect an Ethernet cable to the Ethernet port of a computer
2. Connect the other end of the Ethernet cable to one of the numbered Ethernet ports of the switch. The LED of the port lights if the device connected is active.
3. Repeat Step 1 and Step 2 for each device to connect to the switch.



We strongly recommend using CAT-5E or better cable to connect network devices. When connecting network devices, do not exceed the maximum cabling distance of 100 meters (328 feet). It can take up to one minute for attached devices or the LAN to be operational after it is connected. This is normal behavior.

Connect the switch to end nodes using a standard Cat 5/5e Ethernet cable (UTP/STP) to connect the switch to end nodes as shown in the illustration below.

Switch ports will automatically adjust to the characteristics (MDI/MDI-X, speed, duplex) of the device to which the switch is connected.



Figure 8 - PC Connect

3.1.3. Power over Ethernet (PoE) Considerations

For PoE switch models, consider the following information:

Devices considered a Power Sourcing Equipment (PSE), can support up to 30 Watts per PoE port to a Powered Device (PD).

Model	Power Dedicated to	PoE Ports	PoE Standard Supported
DG-GS1512HP	140W	1 to 8	IEEE802.3at/af

Ports 1-8 provide PoE power supply functionality with a maximum output power up to 30W each port. This can supply power to PDs such as internet phones, network cameras, wireless access points. Connect the switch PoE port directly to the PD port using a network cable.



When connecting switches capable of supplying PoE, consider the following information:

- Switch models with PoE function are PSEs. These models are capable of supplying DC power to attached PDs, such as VoIP phones, IP cameras, and wireless access points (APs). PoE switches. Additionally, PoE switches are capable of detecting and supplying power to pre-standard legacy PoE Power Devices. Due to the support for legacy PoE, there is a possibility that PoE switches acting as a PSE may inadvertently detect and supply

power an attached PSE, including other PoE switches. This false detection may result in a PoE switch operating improperly and unable to supply power to attached PDs.

- The prevention of a false detection can be easily remedied by disabling PoE on the ports that are used to connect PSEs. Another simple practice to prevent a false detection is to first power up a PSE device before connecting it to a PoE switch.
- When a device is falsely detected as a PD, disconnect the device from the PoE port and power recycle the device with AC power before reconnecting it to the PoE port.

3.1.4. Starting the Web-based Configuration Utility

This section describes how to navigate the web-based switch configuration utility.

Be sure to disable any pop-up blocker.

Browser Restrictions

- If you are using older versions of Internet Explorer, you cannot directly use an IPv6 address to access the device. You can, however, use the DNS (Domain Name System) server to create a domain name that contains the IPv6 address, and then use that domain name in the address bar in place of the IPv6 address.
- If you have multiple IPv6 interfaces on your management station, use the IPv6 global address instead of the IPv6 link local address to access the device from your browser.

Launching the Configuration Utility

To open the web-based configuration utility:

1. Open a Web browser.
2. Enter the IP address of the device you are configuring in the address bar on the browser (factory default IP address is 192.168.1.10) and then press Enter.



When the device is using the factory default IP address, its power LED flashes continuously. When the device is using a DHCP assigned IP address

or an administrator-configured static IP address, the power LED is lit a solid color. Your computer's IP address must be in the same subnet as the switch. For example, if the switch is using the factory default IP address, your computer's IP address can be in the following range: 192.168.1.x (whereas x is a number from 2 to 254).

After a successful connection, the login window displays.

The image shows a web-based login interface for DIGISOL. It features a dark red header with the DIGISOL logo on the left and the text "User Login" on the right. Below the header is a light pink background. In the center, there are two input fields: the first is labeled "Username:" and the second is labeled "Password:". Below these fields is a blue button with the text "LOGIN" in white capital letters.

Figure 9 - Login Window

3.1.5. Logging In

The default username is admin and the default password is admin. The first time that you log in with the default username and password, you are required to enter a new password.

To log in to the device configuration utility:

1. Enter the default user ID (admin) and the default password (admin).
2. If this is the first time that you logged on with the default user ID (admin) and the default password (admin) it is recommended that you change your password immediately.

When the login attempt is successful, the **System Information** window displays.




Figure 10 - System Information

If you entered an incorrect username or password, an error message appears and the Login page remains displayed on the window. If you are having problems logging in, please see the Launching the Configuration Utility section in the Administration Guide for additional information.

Logging Out

By default, the application logs out after ten minutes of inactivity.

To logout, click Logout in the top right corner of any page. The system logs out of the device.

When a timeout occurs or you intentionally log out of the system, a message appears and the Login page appears, with a message indicating the logged-out state. After you log in, the application returns to the initial page.

4. Web-based Switch Configuration

The PoE smart switch software provides rich Layer 2 functionality for switches in your networks. This chapter describes how to use the web-based management interface (Web UI) to configure the switch's features.

For the purposes of this manual, the user interface is separated into four sections, as shown in the following figure:




Figure 11 - User Interface

No.	Name	Description
1	Configuration menu	Navigate to locate specific switch functions.
2	Configuration settings	Edit specific function settings.
3	Switch's current link status	Green squares indicate the port link is up, while black squares indicate the port link is down.
4	Common toolbar	Provides access to frequently used settings.

4.1. Status

Use the Status pages to view system information and status.

4.1.1. System Information

This page shows switch panel, CPU utilization, Memory utilization and other system current information. It also allows user to edit some system information.

To display the Device Information web page, click **Status > System Information**.




Figure 12 - Status > System Information

Item	Description
Model	Model name of the switch.
System Name	System name of the switch. This name will also use as CLI prefix of each line. (“Switch>” or “Switch#”).

System Location	Location information of the switch.
System Contact	Contact information of the switch.
MAC Address	Base MAC address of the switch.
IPv4 Address	Current system IPv4 address.
IPv6 Address	Current system IPv6 address.
System OID	SNMP system object ID.
System Uptime	Total elapsed time from booting.
Current Time	Current system time.
Loader Version	Boot loader image version.
Loader Date	Boot loader image build date.
Firmware Version	Current running firmware image version.
Firmware Date	Current running firmware image build date.
Telnet	Current Telnet service enable/disable state.
SSH	Current SSH service enable/disable state.
HTTP	Current HTTP service enable/disable state.
HTTPS	Current HTTPS service enable/disable state.
SNMP	Current SNMP service enable/disable state.

Click “Edit” button on the table title to edit following system information.




Figure 13 - Status > System Information > Edit System Information

Item	Description
System Name	System name of the switch. This name will also use as CLI prefix of each line. (“Switch>” or “Switch#”).
System Location	Location information of the switch.
System Contact	Contact information of the switch.

4.1.2. Port

The Port configuration page displays port summary and status information.

4.1.2.1. Statistics

This page displays standard counters on network traffic from the Interfaces, Ethernet -like and RMONMIB. Interfaces and Ethernet-like counters display errors on the traffic passing through each port. RMON counters provide a total count of different frame types and sizes passing through each port. The “Clear” button will clear MIB counter of current selected port.

To display the Port Flow Chart web page, click **Status > Port > Statistics**.

Port	GE1
MIB Counter	<input checked="" type="radio"/> All <input type="radio"/> Interface <input type="radio"/> Etherlike <input type="radio"/> RMON
Refresh Rate	<input type="radio"/> None <input type="radio"/> 5 sec <input checked="" type="radio"/> 10 sec <input type="radio"/> 30 sec

Clear

Interface	
ifInOctets	0
ifInUcastPkts	0
ifInNUcastPkts	0
ifInDiscards	0
ifOutOctets	0
ifOutUcastPkts	0
ifOutNUcastPkts	0
ifOutDiscards	0
ifInMulticastPkts	0
ifInBroadcastPkts	0
ifOutMulticastPkts	0
ifOutBroadcastPkts	0

Etherlike	
dot3StatsAlignmentErrors	0
dot3StatsFCSErrors	0
dot3StatsSingleCollisionFrames	0
dot3StatsMultipleCollisionFrames	0
dot3StatsDeferredTransmissions	0
dot3StatsLateCollisions	0
dot3StatsExcessiveCollisions	0

dot3StatsFrameTooLongs	0
dot3StatsSymbolErrors	0
dot3ControlInUnknownOpcodes	0
dot3InPauseFrames	0
dot3OutPauseFrames	0
RMON	
etherStatsDropEvents	0
etherStatsOctets	0
etherStatsPkts	0
etherStatsBroadcastPkts	0
etherStatsMulticastPkts	0
etherStatsCRCAlignErrors	0
etherStatsUnderSizePkts	0
etherStatsOverSizePkts	0
etherStatsFragments	0
etherStatsJabbers	0
etherStatsCollisions	0
etherStatsPkts64Octets	0
etherStatsPkts65to127Octets	0
etherStatsPkts128to255Octets	0
etherStatsPkts256to511Octets	0
etherStatsPkts512to1023Octets	0
etherStatsPkts1024to1518Octets	0


Figure 15 - Status > Port > Statistics

Item	Description
Port	Select one port to show counter statistics.
MIB Counter	Select the MIB counter to show different counter type <ul style="list-style-type: none"> All: All counters. Interface: Interface related MIB counters.

	<ul style="list-style-type: none"> • Etherlike: Ethernet-like related MIB counters. • RMON: RMON related MIB counters.
Refresh Rate	Refresh the web page every period of seconds to get new counter of specified port.

4.1.2.2. Error Disabled

To display the Error Disabled web page, click **Status > Port > Error Disabled**.



<input type="checkbox"/>	Port	Reason	Time Left (sec)
<input type="checkbox"/>	GE1	---	---
<input type="checkbox"/>	GE2	---	---
<input type="checkbox"/>	LAG7	---	---
<input type="checkbox"/>	LAG8	---	---

Refresh Recover

Figure 16 - Status > Port > Error Disabled

Item	Description
<input type="checkbox"/>	Select one or more port to operate.
Port	Interface or port number.
Reason	Port will be disabled by one of the following error reason: <ul style="list-style-type: none"> • BPDU Guard • UDLD • Self Loop • Broadcast Flood • Unknown Multicast Flood • Unicast Flood

	<ul style="list-style-type: none"> • ACL • Port Security Violation • DHCP rate limit • ARP rate limit
Time Left (sec)	The time left in second for the error recovery.
Refresh	Refresh the current page.
Recover	Recover the selected port status.

4.1.2.3. Bandwidth Utilization

This page allow user to browse ports' bandwidth utilization in real time. This page will refresh automatically in every refresh period.

To display Bandwidth Utilization web page, click **Status > Port > Bandwidth Utilization**.




Figure 17 - Status > Port > Bandwidth Utilization

Item	Description
Refresh Rate	Refresh the web page every period of seconds to get new bandwidth utilization data.

4.1.3. Link Aggregation

To display the Link Aggregation web page, click **Status > Link Aggregation**.

Link Aggregation Table

LAG	Name	Type	Link Status	Active Member	Inactive Member
LAG 1	---	---	---	---	---
LAG 2	---	---	---	---	---
LAG 3	---	---	---	---	---
LAG 4	---	---	---	---	---
LAG 5	---	---	---	---	---
LAG 6	---	---	---	---	---
LAG 7	---	---	---	---	---
LAG 8	---	---	---	---	---

Figure 18 - Status > Link Aggregation


Item	Description
LAG	LAG Name.
Name	LAG port description.
Type	<ul style="list-style-type: none"> The type of the LAG. Static: The group of ports assigned to a static LAG are always active members. LACP: The group of ports assigned to dynamic LAG are candidate ports. LACP determines which candidate ports are active member ports.

Link Status	LAG port link status.
Active Member	Active member ports of the LAG.
Inactive Member	Inactive member ports of the LAG.

4.1.4. MAC Address Table

The MAC address table page displays all MAC address entries on the switch including static MAC address created by administrator or auto learned from hardware. The “Clear” button will clear all dynamic entries and “Refresh” button will retrieve latest MAC address entries and show them on page.

To display the MAC Address Table web page, click **Status > MAC Address Table**.



VLAN	MAC Address	Type	Port
1	00:E0:4C:00:00:00	Management	CPU
1	6C:B3:11:50:25:0E	Dynamic	GE8

Figure 19 - Status > MAC Address Table

Item	Description
VLAN	VLAN ID of the mac address.
MAC Address	MAC address.
Type	<p>The type of MAC address</p> <ul style="list-style-type: none"> • Management: DUT’ s base mac address for management Purpose. • Static: Manually configured by administrator • Dynamic: Auto learned by hardware.

Port	<p>The type of Port</p> <ul style="list-style-type: none">• CPU: DUT' s CPU port for management purpose.• Other: Normal switch port.
------	---

4.2. Network

Use the Network pages to configure settings for the switch network interface and how the switch connects to a remote server to get services.

4.2.1. IP Address

This section allows you to edit the IP address, Netmask, Gateway and DNS server of the switch.

To view the IP Address menu, navigate to **Network > IP Address**.

IPv4 Address	
Address Type	<input checked="" type="radio"/> Static <input type="radio"/> Dynamic
IP Address	192.168.169.1
Subnet Mask	255.255.255.0
Default Gateway	192.168.169.254
DNS Server 1	168.95.1.1
DNS Server 2	168.95.192.1

IPv6 Address	
Auto Configuration	<input checked="" type="checkbox"/> Enable
DHCPv6 Client	<input type="checkbox"/> Enable
IPv6 Address	
Prefix Length	0 (0 - 128)
IPv6 Gateway	
DNS Server 1	
DNS Server 2	

Operational Status	
IPv4 Address	192.168.169.1
IPv4 Default Gateway	192.168.169.254
IPv6 Address	fe80::2e0:4cff:fe00:0/64
IPv6 Gateway	::
Link Local Address	fe80::2e0:4cff:fe00:0/64

Apply

Figure 20 - Network > IP Address

Item	Description
Address Type	The address type of switch IP configuration including <ul style="list-style-type: none"> • Static: Static IP configured by users will be used. • Dynamic: Enable the DHCP to obtain the IP address from a DHCP server.
IP Address	Specify the switch static IP address on the static configuration.
Subnet Mask	Specify the switch subnet mask on the static configuration.
Default Gateway	Specify the default gateway on the static configuration. The default gateway must be in the same subnet with switch IP address configuration.
DNS Server 1	Specify the primary user-defined IPv4 DNS server configuration.
DNS Server 2	Specify the secondary user-defined IPv4 DNS server configuration.
Table 3-2: IPv6 Address fields	
IPv4 Address	The operational IPv4 address of the switch.
IPv4 Default Gateway	The operational IPv4 gateway of the switch.
IPv6 Address v6	The operational IPv6 address of the switch.
IPv6 Gateway	The operational IPv6 gateway of the switch.
Link Local Address	The IPv6 link local address for the switch.

4.2.2. System Time

This page allow user to set time source, static time, time zone and daylight saving settings. Time zone and daylight saving takes effect both static time or time from

SNTP server.

To display System Time page, click **Network > System Time**

Source	<input type="radio"/> SNTP <input type="radio"/> From Computer <input checked="" type="radio"/> Manual Time	
Time Zone	UTC +8:00 ▼	
SNTP		
Address Type	<input checked="" type="radio"/> Hostname <input type="radio"/> IPv4	
Server Address	<input type="text"/>	
Server Port	123 (1 - 65535, default 123)	
Manual Time		
Date	2000-01-01 YYYY-MM-DD	
Time	00:17:39 HH:MM:SS	
Daylight Saving Time		
Type	<input checked="" type="radio"/> None <input type="radio"/> Recurring <input type="radio"/> Non-recurring <input type="radio"/> USA <input type="radio"/> European	
Offset	60 Min (1 - 1440, default 60)	
Recurring	From: Day <input type="text" value="Sun"/> Week <input type="text" value="First"/> Month <input type="text" value="Jan"/> Time <input type="text"/> To: Day <input type="text" value="Sun"/> Week <input type="text" value="First"/> Month <input type="text" value="Jan"/> Time <input type="text"/>	
Non-recurring	From: <input type="text"/> YYYY-MM-DD <input type="text"/> HH:MM To: <input type="text"/> YYYY-MM-DD <input type="text"/> HH:MM	
Operational Status		
Current Time	2000-01-01 00:17:39 UTC+8	
<input type="button" value="Apply"/>		

Figure 21 - Network > System Time

Item	Description
Source	<p>Select the time source.</p> <ul style="list-style-type: none"> • SNTP: Time sync from NTP server. • From Computer: Time set from browser host. • Manual Time: Time set by manually configure.
Time Zone	Select a time zone difference from listing district.
SNTP	
Address Type	Select the address type of NTP server. This is enabled when time source is SNTP.
Server Address	Input IPv4 address or hostname for NTP server. This is enabled when time source is SNTP.
Server Port	Input NTP port for NTP server. Default is 123. This is enabled when time source is SNTP.
Manual Time	
Date	Input manual date. This is enabled when time source is manual.
Time	Input manual time. This is enabled when time source is manual.
Daylight Saving Time	
Type	<p>Select the mode of daylight saving time.</p> <ul style="list-style-type: none"> • Disable: Disable daylight saving time. • Recurring: Using recurring mode of daylight saving time. • Non-Recurring: Using non-recurring mode of daylight saving time.

	<ul style="list-style-type: none"> • USA: Using daylight saving time in the United States that starts on the second Sunday of March and ends on the first Sunday of November. • European: Using daylight saving time in the Europe that starts on the last Sunday in March and ending on the last Sunday in October.
Offset	Specify the adjust offset of daylight saving time.
Recurring From	Specify the starting time of recurring daylight saving time. This field available when selecting “Recurring” mode.
Recurring To	Specify the ending time of recurring daylight saving time. This field available when selecting “Recurring” mode.
Non-recurring From	Specify the starting time of non-recurring daylight saving time. This field available when selecting “Non-Recurring” mode.
Non-recurring To	Specify the ending time of recurring daylight saving time. This field available when selecting “Non-Recurring” mode.
Non-recurring From	Specify the starting time of non-recurring daylight saving time. This field available when selecting “Non-Recurring” mode.
Non recurring To	Specify the ending time of recurring daylight saving time. This field available when selecting “Non-Recurring” mode.

4.3. Port

Use the Port pages to configure settings for switch port related features.

4.3.1. Port Setting

This page shows port current status and allow user to edit port configurations. Select port entry and click “Edit” button to edit port configurations.

To display Port Setting web page, click **Port > Port Setting**

Port Setting Table

<input type="checkbox"/>	Entry	Port	Type	Description	State	Link Status	Speed	Duplex	Flow Control
<input type="checkbox"/>	1	GE1	1000M Copper		Enabled	Down	Auto	Auto	Disabled
<input type="checkbox"/>	2	GE2	1000M Copper		Enabled	Down	Auto	Auto	Disabled
<input type="checkbox"/>	3	GE3	1000M Copper		Enabled	Down	Auto	Auto	Disabled
<input type="checkbox"/>	4	GE4	1000M Copper		Enabled	Down	Auto	Auto	Disabled
<input type="checkbox"/>	5	GE5	1000M Copper		Enabled	Down	Auto	Auto	Disabled
<input type="checkbox"/>	6	GE6	1000M Copper		Enabled	Down	Auto	Auto	Disabled
<input type="checkbox"/>	7	GE7	1000M Copper		Enabled	Down	Auto	Auto	Disabled
<input type="checkbox"/>	8	GE8	1000M Copper		Enabled	Up	Auto (1000M)	Auto (Full)	Disabled (Disabled)
<input type="checkbox"/>	9	GE9	1000M Combo Copper		Enabled	Down	Auto	Auto	Disabled
<input type="checkbox"/>	10	GE10	1000M Combo Copper		Enabled	Down	Auto	Auto	Disabled
<input type="checkbox"/>	11	GE11	1000M Combo Copper		Enabled	Down	Auto	Auto	Disabled
<input type="checkbox"/>	12	GE12	1000M Combo Copper		Enabled	Down	Auto	Auto	Disabled

Figure 22 - Port > Port Setting

Item	Description
Port	Port Name.
Type	Port media type.
Description	Port Description.
State	Port admin state <ul style="list-style-type: none"> Enabled: Enable the port. Disabled: Disable the port.
Link Status	Current port link status <ul style="list-style-type: none"> Up: Port is link up. Down: Port is link down.
Speed	Current port speed configuration and link speed status.

Duplex	Current port duplex configuration and link duplex status.
Flow Control	Current port flow control configuration and link flow control status.

Click "Edit" button to edit Port Setting menu,




Figure 23 - Port > Port Setting > Port Setting

Item	Description
Port	Selected Port list.
Description	Port media type.
State	Port admin state. <ul style="list-style-type: none"> Enabled: Enable the port. Disabled: Disable the port.
Speed	Port speed capabilities. <ul style="list-style-type: none"> Auto: Auto speed with all capabilities. Auto-10M: Auto speed with 10M ability only. Auto-100M: Auto speed with 100M ability only.

	<ul style="list-style-type: none"> • Auto-1000M: Auto speed with 1000M ability only. • Auto-10M/100M: Auto speed with 10M/100M abilities. • 10M: Force speed with 10M ability. • 100M: Force speed with 100M ability. • 1000M: Force speed with 1000M ability.
Duplex	Port duplex capabilities. <ul style="list-style-type: none"> • Auto: Auto duplex with all capabilities. • Half: Auto speed with 10M and 100M ability only. • Full: Auto speed with 10M/100M/1000M ability only.
Flow Control	Port flow control. <ul style="list-style-type: none"> • Auto: Auto flow control by negotiation. • Enabled: Enable flow control ability. • Disabled: Disable flow control ability.

4.3.2. Error Disable

To display Error Disabled web page, click **Port > Error Disabled**

Recovery Interval	<input type="text" value="300"/> Sec (30 - 86400)
BPDU Guard	<input type="checkbox"/> Enable
UDLD	<input type="checkbox"/> Enable
Self Loop	<input type="checkbox"/> Enable
Broadcast Flood	<input type="checkbox"/> Enable
Unknown Multicast Flood	<input type="checkbox"/> Enable
Unicast Flood	<input type="checkbox"/> Enable
ACL	<input type="checkbox"/> Enable
Port Security	<input type="checkbox"/> Enable
DHCP Rate Limit	<input type="checkbox"/> Enable
ARP Rate Limit	<input type="checkbox"/> Enable

Figure 24 - Port > Error disable

Item	Description
Recover Interval	Auto recovery after this interval for error disabled port.
BPDU Guard	Enabled to auto shutdown port when BPDU Guard reason occur. This reason caused by STP BPDU Guard mechanism.
UDLD	Enabled to auto shutdown port when UDLD violation occur.
Self Loop	Enabled to auto shutdown port when Self Loop reason occur.
Broadcast Flood	Enabled to auto shutdown port when Broadcast Flood reason occur. This reason caused by broadcast rate exceed broadcast storm control rate.
Unknown Multicast Flood	Enabled to auto shutdown port when Unknown Multicast Flood reason occur. This reason caused by unknown multicast rate exceed unknown multicast storm control rate.
Unicast Flood	Enabled to auto shutdown port when Unicast Flood reason occur. This reason caused by unicast rate exceed unicast storm control rate.
ACL	Enabled to auto shutdown port when ACL shutdown port reason occur. This reason caused packet match the ACL shutdown port action.
Port Security	Enabled to auto shutdown port when Port Security Violation reason occur. This reason caused by violation port security rules.
DHCP rate limit	Enabled to auto shutdown port when DHCP rate limit reason occur. This reason caused by DHCP packet rate exceed DHCP rate limit.
ARP rate limit	Enabled to auto shutdown port when ARP rate limit reason occur. This reason caused by DHCP packet rate exceed ARP rate limit.

4.3.3. Link Aggregation

4.3.3.1. Group

This page allow user to configure link aggregation group load balance algorithm and group member.

To view the Group menu, navigate to **Port > Link Aggregation > Group**.




Figure 25 - Port > Link Aggregation > Group

Item	Description
Load Balance Algorithm	LAG load balance distribution algorithm <ul style="list-style-type: none"> src-dst-mac: Based on MAC address. src-dst-mac-ip: Based on MAC address and IP address.
LAG	LAG Name.
Name	LAG port description.
Type	The type of the LAG <ul style="list-style-type: none"> Static: The group of ports assigned to a static LAG are always active members. LACP: The group of ports assigned to dynamic LAG are

	candidate ports. LACP determines which candidate ports are active member ports.
Link Status	LAG port link status
Active Member	Active member ports of the LAG.
Inactive Member	Inactive member ports of the LAG.

Click "Edit" to edit Link Aggregation Group menu.




Figure 26 - Port > Link Aggregation > Group > Edit Link Aggregation Group

Item	Description
LAG	Selected LAG group ID.
Name	LAG port description.
Type	<p>The type of the LAG</p> <ul style="list-style-type: none"> Static: The group of ports assigned to a static LAG are always active members. LACP: The group of ports assigned to dynamic LAG are candidate ports. LACP determines which candidate ports are active member ports.
Member	Select available port to be LAG group member port.

4.3.3.2. Port Setting

This page shows LAG port current status and allow user to edit LAG port configurations. Select LAG entry and click “Edit” button to edit LAG port configurations.

To display LAG Port Setting web page, click **Port > Link Aggregation > Port Setting**.

Port Setting Table

<input type="checkbox"/>	LAG	Type	Description	State	Link Status	Speed	Duplex	Flow Control
<input type="checkbox"/>	LAG 1			Enabled	Down	Auto	Auto	Disabled
<input type="checkbox"/>	LAG 2			Enabled	Down	Auto	Auto	Disabled
<input type="checkbox"/>	LAG 3			Enabled	Down	Auto	Auto	Disabled
<input type="checkbox"/>	LAG 4			Enabled	Down	Auto	Auto	Disabled
<input type="checkbox"/>	LAG 5			Enabled	Down	Auto	Auto	Disabled
<input type="checkbox"/>	LAG 6			Enabled	Down	Auto	Auto	Disabled
<input type="checkbox"/>	LAG 7			Enabled	Down	Auto	Auto	Disabled
<input type="checkbox"/>	LAG 8			Enabled	Down	Auto	Auto	Disabled

Edit

Figure 27 - Port > Link Aggregation > Port Setting

Item	Description
LAG	LAG Port Name.
Type	LAG Port media type.
Description	LAG Port description.
State	LAG Port admin state <ul style="list-style-type: none"> Enabled: Enable the port. Disabled: Disable the port.
Link Status	Current LAG port link status <ul style="list-style-type: none"> Up: Port is link up. Down: Port is link down.

Speed	Current LAG port speed configuration and link speed status.
Duplex	Current LAG port duplex configuration and link duplex status.
Flow Control	Current LAG port flow control configuration and link flow control status.

Click "Edit" to view Edit Port Setting menu.




Figure 28 - Port > Link Aggregation > Port Setting > Edit Port Setting

Item	Description
Port	Selected Port list.
Description	Port description.
State	Port admin state

	<ul style="list-style-type: none">• Enabled: Enable the port.• Disabled: Disable the port.
Speed	<p>Port speed capabilities</p> <ul style="list-style-type: none">• Auto: Auto speed with all capabilities.• Auto-10M: Auto speed with 10M ability only.• Auto-100M: Auto speed with 100M ability only.• Auto-1000M: Auto speed with 1000M ability only.• Auto-10M/100M: Auto speed with 10M/100M abilities.• 10M: Force speed with 10M ability.• 100M: Force speed with 100M ability.• 1000M: Force speed with 1000M ability.
Flow Control	<p>Port flow control</p> <ul style="list-style-type: none">• Auto: Auto flow control by negotiation.• Enabled: Enable flow control ability.• Disabled: Disable flow control ability.

4.3.3.3. LACP

This page allow user to configure LACP global and port configurations. Select ports and click “Edit” button to edit port configuration.

To display the LACP Setting web page , click **Port > Link Aggregation > LACP**.

System Priority

32768

(1 - 65535, default 32768)

LACP Port Setting Table

<input type="checkbox"/>	Entry	Port	Port Priority	Timeout
<input type="checkbox"/>	1	GE1	1	Long
<input type="checkbox"/>	2	GE2	1	Long
<input type="checkbox"/>	3	GE3	1	Long
<input type="checkbox"/>	4	GE4	1	Long
<input type="checkbox"/>	5	GE5	1	Long
<input type="checkbox"/>	6	GE6	1	Long
<input type="checkbox"/>	7	GE7	1	Long
<input type="checkbox"/>	8	GE8	1	Long
<input type="checkbox"/>	9	GE9	1	Long
<input type="checkbox"/>	10	GE10	1	Long
<input type="checkbox"/>	11	GE11	1	Long
<input type="checkbox"/>	12	GE12	1	Long

Figure 29 - Port > Link Aggregation > LACP

Item	Description
System Priority	Configure the system priority of LACP. This decides the system priority field in LACP PDU.
Port	Port Name.
Port Priority	LACP priority value of the port.
Timeout	The periodic transmissions type of LACP PDUs. <ul style="list-style-type: none"> Long: Transmit LACP PDU with slow periodic (30s). Short: Transmit LACPP DU with fast periodic (1s).

Click "Edit" button to view Edit LACP Port Setting menu.




Figure 30 - Port > Link Aggregation > LACP > Edit LACP Port Setting

Item	Description
Port	Selected port list.
Port Priority	Enter the LACP priority value of the port
Timeout	<p>The periodic transmissions type of LACP PDUs.</p> <ul style="list-style-type: none"> • Long: Transmit LACP PDU with slow periodic (30s). • Short: Transmit LACPP DU with fast periodic (1s).

4.3.4. EEE

This page allow user to configure Energy Efficient Ethernet settings.

To display the EEE web page, click **Port > EEE**.

EEE Setting Table

<input type="checkbox"/>	Entry	Port	State	Operational Status
<input type="checkbox"/>	1	GE1	Disabled	Disabled
<input type="checkbox"/>	2	GE2	Disabled	Disabled
<input type="checkbox"/>	3	GE3	Disabled	Disabled
<input type="checkbox"/>	4	GE4	Disabled	Disabled
<input type="checkbox"/>	5	GE5	Disabled	Disabled
<input type="checkbox"/>	6	GE6	Disabled	Disabled
<input type="checkbox"/>	7	GE7	Disabled	Disabled
<input type="checkbox"/>	8	GE8	Disabled	Disabled
<input type="checkbox"/>	9	GE9	Disabled	Disabled
<input type="checkbox"/>	10	GE10	Disabled	Disabled
<input type="checkbox"/>	11	GE11	Disabled	Disabled
<input type="checkbox"/>	12	GE12	Disabled	Disabled

Figure 31 - Port > EEE

Item	Description
Port	Port Name.
State	Port EEE admin state <ul style="list-style-type: none"> Enabled: EEE is enabled. Disabled: EEE is disabled.
Operational Status	Port EEE operational status <ul style="list-style-type: none"> Enabled: EEE is operating. Disabled: EEE is no operating.

Click "**Edit**" to edit the EEE menu.




Figure 32 - Port > EEE > Edit EEE Setting

Item	Description
Port	Port Name
State	Port EEE admin state <ul style="list-style-type: none"> Enabled: EEE is enabled. Disabled: EEE is disabled.

4.3.5. Jumbo Frame

This page allow user to configure switch jumbo frame size.

To display Jumbo Frame web page, click **Port > Jumbo Frame**




Figure 33 - Port > Jumbo Frame

Item	Description
Jumbo Frame	Enable or disable jumbo frame. When jumbo frame is enabled, switch max frame size is allowed to configure. When


jumbo frame is disabled, default frame size 1522 will be used.

4.4. PoE

PoE lets Ethernet cables supply power to network devices over the existing data connection.

4.4.1. Global Setting

To display the Global web page, click **PoE > Global Setting**.



Nominal Power	140 W
Consuming Power	0 W
Remaining Power	140 W
Schedule Status	Disable

Apply

PoE Schedule Table

Index	Name	Port List	Schedule Status
1	Index_01		Disable
2	Index_02		Disable
3	Index_03		Disable
23	Index_23		Disable
24	Index_24		Disable


Edit

Figure 34 - PoE > Global Setting

Item	Description
Nominal Power	Maximum supply power.
Consuming Power	Current consumed power.
Remaining Power	Remaining available power.
Schedule Status	Schedule status global switch.
Name	PoE Schedule Name.

Port List	The ports provide power in designated schedule index.
Schedule Status	The current schedule status.

Click "Edit" to view PoE Schedule List menu.



The image shows a web-based configuration window titled "PoE Schedule Edit". It contains several fields: "Index" with a dropdown menu showing "10", "Schedule Status" with an unchecked "Enable" checkbox, and "Name" with a dropdown menu showing "None". Below these is a "Port List" section featuring a 2x4 grid of port icons numbered 1 through 8. Below the grid are two buttons labeled "Enable" and "Disable". To the right of the port grid is a legend with two items: "Port No Select" (represented by a grey icon) and "Port Select" (represented by a yellow icon with a checkmark). At the bottom of the window are "Apply" and "Close" buttons.

Figure 35 - PoE > Priority Setting > Edit PoE Schedule Edit

Item	Description
Index	The serial number of schedule list.
Schedule Status	<p>Schedule Status</p> <ul style="list-style-type: none"> • Checked: Schedule status is enabled. • Unchecked: Schedule status is disabled.
Name	Enter the PoE schedule name.
Date	Select a valid time for this schedule.
Port List	Select the port provide power.

4.4.2. Priority Setting

Use this section to set the power supply priority of PoE ports. Individual ports can be assigned critical, high, or low power supply priority.

To display the Priority Setting web page, click **PoE > Priority Setting**.




Figure 36 - PoE > Priority Setting

Item	Description
<p>"L" is lower priority, "H" is high priority and "C" is Critical priority.</p> <p>Click the port to change its priority status.</p>	

4.4.3. Power Limit

To display the Power Limit web page, click **PoE > Power Limit**.


Power Limit Setting Table

<input type="checkbox"/>	Entry	Port	Power Limit
<input type="checkbox"/>	1	GE1	30000mW
<input type="checkbox"/>	2	GE2	30000mW
<input type="checkbox"/>	3	GE3	30000mW
<input type="checkbox"/>	4	GE4	30000mW
<input type="checkbox"/>	5	GE5	30000mW
<input type="checkbox"/>	6	GE6	30000mW
<input type="checkbox"/>	7	GE7	30000mW
<input type="checkbox"/>	8	GE8	30000mW

Figure 37 - PoE > Power Limit

Item	Description
Port	Port name.
Power Limit	The max supply power for this port.

Click "Edit" to view Power Limit Setting menu.



The screenshot shows a web interface titled "Power Limit Setting Table". It contains a table with two rows: "Port List" with the value "GE8" and "Power Limit" with a text input field containing "30000" and a unit label "mW". Below the table are two buttons: "Apply" and "Close".

Power Limit Setting Table	
Port List	GE8
Power Limit	30000 mW

Apply Close

Figure 38 - PoE > Power Setting > Power Limit Setting Table

Item	Description
Port List	Selected port list.
Power Limit	Enter max supply power value for the selected port list.

4.4.4. Power show

To display the Power Show web page, click **PoE > Power Show**.




Figure 39 - PoE > Power Show

Item	Description
Per Port PoE Status	<ul style="list-style-type: none"> • Checked: Port PoE status is enabled. • Unchecked: Port PoE status is disabled.

4.5. VLAN

A virtual local area network, virtual LAN or VLAN, is a group of hosts with a common set of requirements that communicate as if they were attached to the same broadcast domain, regardless of their physical location. A VLAN has the same attributes as a physical local area network (LAN), but it allows for end stations to be grouped together even if they are not located on the same network switch. VLAN membership can be configured through software instead of physically relocating devices or connections.


4.5.1. VLAN

Use the VLAN pages to configure settings of VLAN.

4.5.1.1. Create VLAN

This page allows user to add or delete VLAN ID entries and browser all VLAN entries that add statically or dynamic learned by GVRP. Each VLAN entry has a unique name, user can edit VLAN name in edit page.

To display Create VLAN page, click **VLAN > VLAN > Create VLAN**



VLAN

Available VLAN

Created VLAN

VLAN 2
VLAN 3
VLAN 4
VLAN 5
VLAN 6
VLAN 7
VLAN 8
VLAN 9

VLAN 1

Apply

VLAN Table

Showing All entries Showing 1 to 1 of 1 entries

<input type="checkbox"/>	VLAN	Name	Type
<input type="checkbox"/>	1	default	Default

Edit Delete

First Previous 1 Next Last

Figure 40 - VLAN > VLAN > Create VLAN

Item	Description
Available VLAN	VLAN has not created yet. Select available VLANs from left box then move to right box to add.
Created VLAN	VLAN had been created. Select created VLANs from right box then move to left box to delete

VLAN	The VLAN ID.
Name	The VLAN Name.
Type	The VLAN Type. Static: Port base VLAN. Dynamic:802.1q VLAN.

Click "Edit" button to view Edit VLAN Name menu.




Figure 41 - VLAN > VLAN > Create VLAN > Edit VLAN Name

Item	Description
Name	Input VLAN name.

4.5.1.2. VLAN Configuration

This page allow user to configure the membership for each port of selected VLAN.

To display VLAN Configuration page, click **VLAN > VLAN > VLAN Configuration**.

VLAN Configuration Table

VLAN default


Entry	Port	Mode	Membership				PVID
1	GE1	Trunk	<input type="radio"/> Excluded	<input type="radio"/> Forbidden	<input type="radio"/> Tagged	<input checked="" type="radio"/> Untagged	<input checked="" type="checkbox"/>
2	GE2	Trunk	<input type="radio"/> Excluded	<input type="radio"/> Forbidden	<input type="radio"/> Tagged	<input checked="" type="radio"/> Untagged	<input checked="" type="checkbox"/>
3	GE3	Trunk	<input type="radio"/> Excluded	<input type="radio"/> Forbidden	<input type="radio"/> Tagged	<input checked="" type="radio"/> Untagged	<input checked="" type="checkbox"/>
18	LAG6	Trunk	<input type="radio"/> Excluded	<input type="radio"/> Forbidden	<input type="radio"/> Tagged	<input checked="" type="radio"/> Untagged	<input checked="" type="checkbox"/>
19	LAG7	Trunk	<input type="radio"/> Excluded	<input type="radio"/> Forbidden	<input type="radio"/> Tagged	<input checked="" type="radio"/> Untagged	<input checked="" type="checkbox"/>
20	LAG8	Trunk	<input type="radio"/> Excluded	<input type="radio"/> Forbidden	<input type="radio"/> Tagged	<input checked="" type="radio"/> Untagged	<input checked="" type="checkbox"/>

Apply

Figure 42 - VLAN > VLAN > VLAN Configuration

Item	Description
VLAN	Select specified VLAN ID to configure VLAN configuration.
Port	Display the interface of port entry.
Mode	Display the interface VLAN mode of port.
Membership	<p>Select the membership for this port of the specified VLAN ID.</p> <ul style="list-style-type: none"> Forbidden: Specify the port is forbidden in the VLAN. Excluded: Specify the port is excluded in the VLAN. Tagged: Specify the port is tagged member in the VLAN. Untagged: Specify the port is untagged member in the VLAN.
PVID	Display if it is PVID of interface.

4.5.1.3. Membership

This page allow user to view membership information for each port and edit membership for specified interface.

To display Membership page, click **VLAN > VLAN > Membership**

Membership Table

	Entry	Port	Mode	Administrative VLAN	Operational VLAN
<input type="radio"/>	1	GE1	Trunk	1UP	1UP
<input type="radio"/>	2	GE2	Trunk	1UP	1UP
<input type="radio"/>	3	GE3	Trunk	1UP	1UP
<input type="radio"/>	18	LAG6	Trunk	1UP	1UP
<input type="radio"/>	19	LAG7	Trunk	1UP	1UP
<input type="radio"/>	20	LAG8	Trunk	1UP	1UP

Figure 43 - VLAN > VLAN > Membership

Item	Description
Port	Display the interface of port entry.
Mode	Display the interface VLAN mode of port.
Administrative VLAN	Display the administrative VLAN list of this port.
Operational VLAN	Display the operational VLAN list of this port. Operational VLAN means the VLAN status that really runs in device. It may different to administrative VLAN.

Click "Edit" button to view the Edit Port Setting menu




Figure 44 - VLAN > VLAN > Membership > Edit Port Setting

Item	Description
Port	Display the interface.
Mode	Display the VLAN mode of interface.
Membership	<p>Select VLANs of left box and select one of following membership then move to right box to add membership. Select VLANs of right box then move to left box to remove membership. Tagging membership may not choose in differ VLAN port mode. Select the time source.</p> <ul style="list-style-type: none"> Forbidden: Set VLAN as forbidden VLAN. Excluded: This option is always disabled. Tagged: Set VLAN as tagged VLAN. Untagged: Set VLAN as untagged VLAN. PVID: Check this checkbox to select the VLAN ID to be the port-based VLAN ID for this port. PVID may auto select or can' t select in differ settings.

4.5.1.4. Port Setting

This page allow user to configure ports VLAN settings such as VLAN port mode, PVID etc...The attributes depend on different VLAN port mode.

To display Port Setting page, click **VLAN > VLAN > Port Setting**

Port Setting Table

<input type="checkbox"/>	Entry	Port	Mode	PVID	Accept Frame Type	Ingress Filtering	Uplink	TPID
<input type="checkbox"/>	1	GE1	Trunk	1	All	Enabled	Disabled	0x8100
<input type="checkbox"/>	2	GE2	Trunk	1	All	Enabled	Disabled	0x8100
<input type="checkbox"/>	3	GE3	Trunk	1	All	Enabled	Disabled	0x8100
<input type="checkbox"/>	18	LAG6	Trunk	1	All	Enabled	Disabled	0x8100
<input type="checkbox"/>	19	LAG7	Trunk	1	All	Enabled	Disabled	0x8100
<input type="checkbox"/>	20	LAG8	Trunk	1	All	Enabled	Disabled	0x8100

Edit

Figure 45 - VLAN > VLAN > Port Setting

Item	Description
Port	Display the interface.
Mode	Display the VLAN mode of interface.
PVID	Display the Port-based VLAN ID of port.
Accept Frame Type	Display accept frame type of port.
Ingress Filtering	Display ingress filter status of port.
Uplink	Display uplink status.
TPID	Display TPID used of interface.

Click "Edit" button to Edit Port Setting menu.

Edit Port Setting

Port	GE2
Mode	<input type="radio"/> Hybrid <input type="radio"/> Access <input checked="" type="radio"/> Trunk
PVID	<input style="width: 100px;" type="text" value="1"/> (1 - 4094)
Accept Frame Type	<input checked="" type="radio"/> All <input type="radio"/> Tag Only <input type="radio"/> Untag Only
Ingress Filtering	<input checked="" type="checkbox"/> Enable

Apply
Close

Figure 46 - VLAN > VLAN > Port Setting > Edit Port Setting

Item	Description
Port	Display selected port to be edited.
Mode	Select the VLAN mode of the interface. <ul style="list-style-type: none"> Forbidden: Set VLAN as forbidden VLAN. Hybrid: Support all functions as defined in IEEE 802.1Q specification. Access: Accepts only untagged frames and join an untagged VLAN. Trunk: An untagged member of one VLAN at most, and is a tagged member of zero or more VLANs.
PVID	Specify the port-based VLAN ID (1-4094). It' s only available with Hybrid and Trunk mode.
Accepted Type	Specify the acceptable-frame-type of the specified interfaces. It' s only available with Hybrid mode.
Ingress Filtering	Set checkbox to enable/disable ingress filtering. It' s only available with Hybrid mode.


4.5.2. Voice VLAN

Use the Voice VLAN pages to configure settings of Voice VLAN.

4.5.2.1. Property

This page allow user to configure global and per interface settings of voice VLAN.

To display Property Web page, click **VLAN> Voice VLAN> Property**



Entry	Port	State	Mode	QoS Policy
1	GE1	Disabled	Auto	Voice Packet
2	GE2	Disabled	Auto	Voice Packet
3	GE3	Disabled	Auto	Voice Packet
19	LAG7	Disabled	Auto	Voice Packet
20	LAG8	Disabled	Auto	Voice Packet

Figure 47 - VLAN > Voice VLAN > Property

Item	Description
State	Set checkbox to enable or disable voice VLAN function.
VLAN	Select Voice VLAN ID. Voice VLAN ID cannot be default VLAN.
Cos/802.1p	Select a value of VPT. Qualified packets will use this VPT value as inner priority.

Remarking	Set checkbox to enable or disable 1p remarking. If enabled, qualified packets will be remark by this value.
Aging Time	Input value of aging time. Default is 1440 minutes. A voice VLAN entry will be age out after this time if without any packet pass through.
Port Setting Table	
Port	Display port entry.
State	Display enable/disabled status of interface.
Mode	Display voice VLAN mode.
QoS Policy	Display voice VLAN remark will effect which kind of packet.

Click "Edit" button to view Edit Port Setting menu.




Figure 48 - VLAN > Voice VLAN > Property > Edit Port Setting


Item	Description
Port	Display selected port to be edited.
State	Set checkbox to enable/disabled voice VLAN function of

	interface.
Mode	Select port voice VLAN mode <ul style="list-style-type: none"> • Auto: Voice VLAN auto detect packets that match OUI table and add received port into voice VLAN ID tagged member. • Manual: User need add interface to VLAN ID tagged member manually.
QoS Policy	Select port QoS Policy mode <ul style="list-style-type: none"> • Voice Packet: QoS attributes are applied to packets with OUIs in the source MAC address. • All: QoS attributes are applied to packets that are classified to the Voice VLAN.

4.5.2.2. Voice OUI

This page allow user to add, edit or delete OUI MAC addresses. Default has 8 pre-defined OUI MAC.

To display the Voice OUI Web page, click **VLAN > Voice VLAN > Voice OUI**.



Showing	All	entries	Showing 1 to 8 of 8 entries	<input type="text"/>
<input type="checkbox"/>	OUI	Description		
<input type="checkbox"/>	00:E0:BB	3COM		
<input type="checkbox"/>	00:03:6B	Cisco		
<input type="checkbox"/>	00:E0:75	Veritel		
<input type="checkbox"/>	00:D0:1E	Pingtel		
<input type="checkbox"/>	00:01:E3	Siemens		
<input type="checkbox"/>	00:60:B9	NEC/Philips		
<input type="checkbox"/>	00:0F:E2	H3C		
<input type="checkbox"/>	00:09:6E	Avaya		
<input type="button" value="Add"/> <input type="button" value="Edit"/> <input type="button" value="Delete"/>			<input type="button" value="First"/> <input type="button" value="Previous"/> <input type="button" value="1"/> <input type="button" value="Next"/> <input type="button" value="Last"/>	

Figure 49 - VLAN > Voice VLAN > Voice OUI

Item	Description
OUI	Display OUI MAC address.
Description	Display description of OUI entry.

Click “Add” or “Edit” button to Add/Edit Voice OUI menu.

Add Voice OUI

OUI

Description

Apply
Close

Edit Voice OUI

OUI

Description

Apply
Close

Figure 50 - VLAN > Voice VLAN > Voice OUI > Add/Edit Voice OUI

Item	Description
OUI	Input OUI MAC address. Can’ t be edited in edit dialog.
Description	Input description of the specified MAC address to the voice VLAN OUI table.

4.5.4. MAC VLAN

Use the MAC VLAN pages to configure settings of MAC VLAN.

4.5.4.1. MAC Group

This page allow user to add or edit groups settings of MAC VLAN.

To display the MAC page , click **VLAN > MAC VLAN > MAC Group**.





Figure 51 - VLAN > MAC VLAN > MAC Group

Item	Description
Group ID	Display group ID of entry.
MAC Address	Display mac address of entry.
Mask	Display mask of mac address for classified packet.

Click "Add" button or "Edit" button to view Add/Edit MAC menu.






Figure 52 - VLAN > MAC VLAN > MAC Group > Add/Edit MAC

Item	Description
Group ID	Input group ID that is a unique ID of mac group entry. The range from 1 to 2147483647. Only available on Add Dialog.
MAC Address	Input mac address for classifying packets.
Mask	Input mask of mac address.

4.5.4.2. Group Binding

This page allow user to bind MAC VLAN group to each port with VLAN ID.

To display Group Binding page, click **VLAN> MAC VLAN > Group Binding**





Figure 53 - VLAN > MAC VLAN > Group Binding

Item	Description
Port	Display port ID that binding with MAC group entry.

Group ID	Display group ID that port binding with.
VLAN	Display VLAN ID that assign to packets which match MAC group.

Click "Add" button to view the Add Group Binding menu.



Add Group Binding

Port

Available Port **Selected Port**

Note: Only VLAN Hybrid port can be set MAC VLAN

Group ID

VLAN

Apply **Close**

Figure 54 - VLAN > MAC VLAN > Group Binding

Item	Description
Port	Select ports in left box then move to right to binding with MAC group. Or select ports in right box then move to left to unbind with MAC group. Only interface has hybrid VLAN mode can be selected and bound with protocol group. Only available on Add dialog.
Group ID	Select a Group ID to associate with port. Only available on Add dialog.
VLAN	Input VLAN ID that will assign to packets which match MAC group.

4.6. MAC Address Table

Use the MAC Address Table pages to show dynamic MAC table and configure settings for static MAC entries.

4.6.1. Dynamic Address

To display the Dynamic Address web page, click **MAC Address Table > Dynamic Address**.




Figure 55 - MAC Address Table > Dynamic Address

Item	Description
Aging Time	The time in seconds that an entry remains in the MAC address table. Its valid range is from 10 to 630 seconds, and the default value is 300 seconds.

4.6.2. Static Address

To display the Static Address web page, click **MAC Address Table > Static Address**.




Figure 56 - MAC Address Table > Static Address.

Item	Description
MAC Address	The MAC address to which packets will be statically forwarded.
VLAN	Specify the VLAN to show or clear MAC entries.
Port	Interface or port number.

4.6.3. Filtering Address

To display the Filtering Address web page, click **MAC Address Table > Filtering Address**.




Figure 57 - MAC Address Table > Filtering Address.

Item	Description
MAC Address	Specify unicast MAC address in the packets to be dropped.
VLAN	Specify the VLAN to show or clear MAC entries.

4.7. Spanning Tree

The Spanning Tree Protocol (STP) is a network protocol that ensures a loop-free topology for any bridged Ethernet local area network.

4.7.1. Property

To display the Property web page, click **Spanning Tree > Property**.

State	<input type="checkbox"/> Enable	
Operation Mode	<input type="radio"/> STP <input checked="" type="radio"/> RSTP <input type="radio"/> MSTP	
Path Cost	<input checked="" type="radio"/> Long <input type="radio"/> Short	
BPDU Handling	<input type="radio"/> Filtering <input checked="" type="radio"/> Flooding	
Priority	<input type="text" value="32768"/>	(0 - 61440, default 32768)
Hello Time	<input type="text" value="2"/>	Sec (1 - 10, default 2)
Max Age	<input type="text" value="20"/>	Sec (6 - 40, default 20)
Forward Delay	<input type="text" value="15"/>	Sec (4 - 30, default 15)
Tx Hold Count	<input type="text" value="6"/>	(1 - 10, default 6)
Region Name	<input type="text" value="00:E0:4C:00:00:00"/>	
Revision	<input type="text" value="0"/>	(0 - 65535, default 0)
Max Hop	<input type="text" value="20"/>	(1 - 40, default 20)
Operational Status		
Bridge Identifier	32768-00:E0:4C:00:00:00	
Designated Root Bridge	0-00:00:00:00:00:00	
Root Port	N/A	
Root Path Cost	0	
Topology Change Count	0	
Last Topology Change	0D/0H/0M/0S	
<input type="button" value="Apply"/>		

Figure 58 - Spanning Tree > Property

Item	Description
State	Enable/disable the STP on the switch.
Operation Mode	Specify the STP operation mode. <ul style="list-style-type: none"> • STP: Enable the Spanning Tree (STP) operation. • RSTP: Enable the Rapid Spanning Tree (RSTP) operation. • MSTP: Enable the Multiple Spanning Tree (MSTP) operation.
Path Cost	Specify the path cost method. <ul style="list-style-type: none"> • Long: Specifies that the default port path costs are within the range:1-200,000,000. • Short: Specifies that the default port path costs are within the range:1-65,535.
BPDU Handling	Specify the BPDU forward method when the STP is disabled. <ul style="list-style-type: none"> • Filtering: Filter the BPDU when STP is disabled. • Flooding: Flood the BPDU when STP is disabled.
Priority	Specify the bridge priority. The valid range is from 0 to 61440, and the value should be the multiple of 4096. It ensures the probability that the switch is selected as the root bridge, and the lower value has the higher priority for the switch to be selected as the root bridge of the topology.
Hello Time	Specify the STP hello time in second to broadcast its hello message to other bridges by Designated Ports. Its valid range is from 1 to 10 seconds.
Max Age	Specify the time interval in seconds for a switch to wait the configuration messages, without attempting to redefine its own configuration.
Forward Delay	Specify the STP forward delay time, which is the amount of time that a port remains in the Listening and Learning

	states before it enters the Forwarding state. Its valid range is from 4 to 10 seconds.
TX Hold Count	Specify the tx-hold-count used to limit the maximum numbers of packets transmission per second. The valid range is from 1 to 10.
Region Name	The MSTP instance name. Its maximum length is 32 characters. The default value is the MAC address of the switch.
Revision	The MSTP revision number. Its valid range is from 0 to 65535.
Max Hop	Specify the number of hops in an MSTP region before the BPDU is discarded. The valid range is 1 to 40.
Operational Status	
Bridge Identifier	Bridge identifier of the switch.
Designated Root Identifier	Bridge identifier of the designated root bridge.
Root Port	Operational root port of the switch.
Root Path Cost	Operational root path cost.
Topology Change Count	Numbers of the topology changes.
Last Topology Change	The last time for the topology change.

4.7.2. Port Setting

To configure and display the STP port settings, click **STP > Port Setting**.

Port Setting Table









																<input type="text"/>
	Entry	Port	State	Path Cost	Priority	BPDU Filter	BPDU Guard	Operational Edge	Operational Point-to-Point	Port Role	Port State	Designated Bridge	Designated Port ID	Designated Cost		
	1	GE1	Enabled	20000	128	Disabled	Disabled	Disabled	Disabled	Disabled	Disabled	0-00:00:00:00:00:00	128-1	20000		
	2	GE2	Enabled	20000	128	Disabled	Disabled	Disabled	Disabled	Disabled	Disabled	0-00:00:00:00:00:00	128-2	20000		
	3	GE3	Enabled	20000	128	Disabled	Disabled	Disabled	Disabled	Disabled	Disabled	0-00:00:00:00:00:00	128-3	20000		
	18	LAG6	Enabled	20000	128	Disabled	Disabled	Disabled	Disabled	Disabled	Disabled	0-00:00:00:00:00:00	128-18	20000		
	19	LAG7	Enabled	20000	128	Disabled	Disabled	Disabled	Disabled	Disabled	Disabled	0-00:00:00:00:00:00	128-19	20000		
	20	LAG8	Enabled	20000	128	Disabled	Disabled	Disabled	Disabled	Disabled	Disabled	0-00:00:00:00:00:00	128-20	20000		
<div>Edit</div>		<div>Protocol Migration Check</div>														

Figure 59 - Spanning Tree > Port Setting

Item	Description
Port	Specify the interface ID or the list of interface IDs.
State	The operational state on the specified port.
Path Cost	STP path cost on the specified port.
Priority	STP priority on the specified port.
BPDU Filter	The states of BPDU filter on the specified port.
BPDU Guard	The states of BPDU guard on the specified port.
Operational Edge	The operational edge port status on the specified port.
Operational Point-to-Point	The operational point-to-point status on the specified port.
Port Role	The current port role on the specified port. The possible values are: “Disabled” , “Master” , “Root” , “Designated” , “Alternative” , and “Backup” .
Port State	The current port state on the specified port. The possible values are: “Disabled” , “Discarding” , “Learning” , and “Forwarding” .

Designated Bridge	The bridge ID of the designated bridge.
Designated Port ID	The designated port ID on the switch.
Designated Cost	The path cost of the designated port on the switch.
Protocol Migration Check	Restart the Spanning Tree Protocol (STP) migration process (re-negotiate with its neighborhood) on the specific interface.

Click "Edit" button to view Edit Port Setting menu.

Edit Port Setting

Port	GE1
State	<input checked="" type="checkbox"/> Enable
Path Cost	0 (0 - 200000000) (0 = Auto)
Priority	128
Edge Port	<input type="checkbox"/> Enable
BPDU Filter	<input type="checkbox"/> Enable
BPDU Guard	<input type="checkbox"/> Enable
Point-to-Point	<input checked="" type="radio"/> Auto <input type="radio"/> Enable <input type="radio"/> Disable
Port State	Disabled
Designated Bridge	0-00:00:00:00:00:00
Designated Port ID	128-1
Designated Cost	20000
Operational Edge	False
Operational Point-to-Point	False

Apply
Close

Figure 60 - Spanning Tree > Port Setting > Edit Port Setting

Item	Description
Port	Selected port ID.
State	Enable/Disable the STP on the specified port.
Path Cost	Specify the STP path cost on the specified port.
Priority	Specify the STP path cost on the specified port.
Edge Port	<p>Specify the edge mode.</p> <ul style="list-style-type: none"> • Enable: Force to true state (as link to a host). • Disable: Force to false state (as link to a bridge). <p>In the edge mode, the interface would be put into the Forwarding state immediately upon link up. If the edge mode is enabled for the interface and there are BPDUs received on the interface, the loop might be occurred in the short time before the STP state change.</p>
BPDU Filter	<p>The BPDU Filter configuration avoids receiving / transmitting BPDUs from the specified ports.</p> <ul style="list-style-type: none"> • Enable: Enable BPDUs filter function. • Disable: Disable BPDUs filter function.
BPDUs Guard	<p>The BPDUs Guard configuration to drop the received BPDUs directly.</p> <ul style="list-style-type: none"> • Enable: Enable BPDUs guard function. • Disable: Disable BPDUs guard function.
Point-to-Point	<p>Specify the Point-to-Point port configuration:</p> <ul style="list-style-type: none"> • Auto: The state is depended on the duplex setting of the port • Enable: Force to true state. • Disable: Force to false state

4.7.3. MST Instance

To configure MST instance setting, click **STP > MST Instance**.

MST Instance Table

	MSTI	Priority	Bridge Identifier	Designated Root Bridge	Root Port	Root Path Cost	Remaining Hop	VLAN
<input type="radio"/>	0	32768	32768-00:E0:4C:00:00:00	0-00:00:00:00:00:00	N/A	0	0	1-4094
<input type="radio"/>	1	32768	32768-00:E0:4C:00:00:00	0-00:00:00:00:00:00	N/A	0	0	
<input type="radio"/>	2	32768	32768-00:E0:4C:00:00:00	0-00:00:00:00:00:00	N/A	0	0	
<input type="radio"/>	3	32768	32768-00:E0:4C:00:00:00	0-00:00:00:00:00:00	N/A	0	0	
<input type="radio"/>	4	32768	32768-00:E0:4C:00:00:00	0-00:00:00:00:00:00	N/A	0	0	
<input type="radio"/>	5	32768	32768-00:E0:4C:00:00:00	0-00:00:00:00:00:00	N/A	0	0	
<input type="radio"/>	6	32768	32768-00:E0:4C:00:00:00	0-00:00:00:00:00:00	N/A	0	0	
<input type="radio"/>	7	32768	32768-00:E0:4C:00:00:00	0-00:00:00:00:00:00	N/A	0	0	
<input type="radio"/>	8	32768	32768-00:E0:4C:00:00:00	0-00:00:00:00:00:00	N/A	0	0	
<input type="radio"/>	9	32768	32768-00:E0:4C:00:00:00	0-00:00:00:00:00:00	N/A	0	0	
<input type="radio"/>	10	32768	32768-00:E0:4C:00:00:00	0-00:00:00:00:00:00	N/A	0	0	
<input type="radio"/>	11	32768	32768-00:E0:4C:00:00:00	0-00:00:00:00:00:00	N/A	0	0	
<input type="radio"/>	12	32768	32768-00:E0:4C:00:00:00	0-00:00:00:00:00:00	N/A	0	0	
<input type="radio"/>	13	32768	32768-00:E0:4C:00:00:00	0-00:00:00:00:00:00	N/A	0	0	
<input type="radio"/>	14	32768	32768-00:E0:4C:00:00:00	0-00:00:00:00:00:00	N/A	0	0	
<input type="radio"/>	15	32768	32768-00:E0:4C:00:00:00	0-00:00:00:00:00:00	N/A	0	0	

Figure 61 - Spanning Tree > MST Instance

Item	Description
MSTI	Designated port number.
Priority	The bridge priority on the specified MSTI.
Bridge Identifier	The bridge identifier on the specified MSTI.
Designated Root Bridge	The designated root bridge identifier on the specified MSTI.
Root Port	The designated root port on the specified MSTI.
Root Path Cost	The designated root path cost on the specified MSTI.

Remaining Hop	The configuration of remaining hop on the specified MSTI.
VLAN	The VLAN configuration on the specified MSTI.

Click "Edit" button to view Edit MST Instance menu.




Figure 62 - Spanning Tree > MST Instance > Edit MST Instance Setting

Item	Description
VLAN	Select the VLAN list for the specified MSTI.
Priority	Specify the bridge priority on the specified MSTI. The valid range is from 0 to 61440, and the value must be the multiple of 4096. It ensures the probability that the switch is selected as the root bridge, and the lower values has the higher priority for the switch to be selected as the root bridge of the STP topology.

4.7.4. MST Port Setting

To configure and display MST port setting, click **STP > MST Port Setting**.

MST Port Setting Table

MSTI

Entry	Port	Path Cost	Priority	Port Role	Port State	Mode	Type	Designated Bridge	Designated Port ID	Designated Cost	Remaining Hop
1	GE1	20000	128	Disabled	Disabled	RSTP	Boundary	0-00:00:00:00:00:00	128-1	20000	20
2	GE2	20000	128	Disabled	Disabled	RSTP	Boundary	0-00:00:00:00:00:00	128-2	20000	20
3	GE3	20000	128	Disabled	Disabled	RSTP	Boundary	0-00:00:00:00:00:00	128-3	20000	20
18	LAG6	20000	128	Disabled	Disabled	RSTP	Boundary	0-00:00:00:00:00:00	128-18	20000	20
19	LAG7	20000	128	Disabled	Disabled	RSTP	Boundary	0-00:00:00:00:00:00	128-19	20000	20
20	LAG8	20000	128	Disabled	Disabled	RSTP	Boundary	0-00:00:00:00:00:00	128-20	20000	20

Figure 63 - Spanning Tree > MST Port Setting

Item	Description
MSTI	Specify the port setting on the specified MSTI.
Port	Specify the interface ID or the list of interface IDs.
Path Cost	The port path cost on the specified MSTI.
Priority	The port priority on the specified MSTI.
Port Role	The current port role on the specified port. The possible values are: “Disabled” , “Master” , “Root” , “Designated” , “Alternative” , and “Backup” .
Port State	The current port state on the specified port. The possible values are: “Disabled” , “Discarding” , “Learning” , and “Forwarding” .
Mode	The operational STP mode on the specified port.

Type	<p>The possible value for the port type are:</p> <ul style="list-style-type: none"> Boundary: The port attaching an MST Bridge to a LAN that is not in the same region. Internal: The port attaching an MST Bridge to a LAN that is not in the same region.
Designated Bridge	The bridge ID of the designated bridge.
Designated Port ID	The designated port ID on the switch.
Designated Cost	The path cost of the designated port on the switch.
Remaining Hop	The remaining hops count on the specified port.

Click "Edit" button to view Edit MST Port Setting menu.

Edit MST Port Setting

MSTI	0
Port	GE12
Path Cost	<input type="text" value="0"/> (0 - 2000000000) (0 = Auto)
Priority	<input type="text" value="128"/>
Port Role	Disabled
Port State	Disabled
Mode	RSTP
Type	Boundary
Designated Bridge	0-00:00:00:00:00:00
Designated Port ID	128-12
Designated Cost	20000
Remaining Hop	20

Apply
Close

Figure 64 - Spanning Tree > MST Port Setting > Edit MST Port Setting

Item	Description
Path Cost	Specify the STP port path cost on the specified MSTI.
Priority	Specify the STP port priority on the specified MSTI.

4.7.5. Statistics

To display the STP statistics, click **STP > Statistics**.

Statistics Table

Refresh Rate sec

<input type="checkbox"/>	Entry	Port	Receive BPDU			Transmit BPDU			
			Config	TCN	MSTP	Config	TCN	MSTP	
<input type="checkbox"/>	1	GE1	0	0	0	0	0	0	
<input type="checkbox"/>	2	GE2	0	0	0	0	0	0	
<input type="checkbox"/>	3	GE3	0	0	0	0	0	0	
<input type="checkbox"/>	18	LAG6	0	0	0	0	0	0	
<input type="checkbox"/>	19	LAG7	0	0	0	0	0	0	
<input type="checkbox"/>	20	LAG8	0	0	0	0	0	0	

Figure 65 - Spanning Tree > Statistics

Item	Description
Refresh Rate	The option to refresh the statistics automatically.
Receive BPDU (Config)	The counts of the received CONFIG BPDU.

Receive BPD (TCN)	The counts of the received TCN BPD.
Receive BPD (MSTP)	The counts of the received MSTP BPD.
Transmit BPD (Config)	The counts of the transmitted CONFIG BPD.
Transmit BPD (TCN)	The counts of the transmitted TCN BPD.
Transmit BPD (MSTP)	The counts of the transmitted MSTP BPD.
Clear	Clear the statistics for the selected interfaces
View	View the statistics for the interface.

Click "View" button to view the STP Port Statistic menu.

STP Port Statistic

Port
GE10

Refresh Rate

☒ None
☐ 5 sec
☐ 10 sec
☐ 30 sec

Receive BPDU

Config

0

TCN

0

MSTP

0

Transmit BPDU

Config

0

TCN

0

MSTP

0

Refresh
Clear
Close

Figure 66 - Spanning Tree > Statistics > STP Port Statistic

Item	Description
Refresh Rate	The option to refresh the statistics automatically.
Clear	Clear the statistics for the selected interfaces.

4.8. Discovery

Use this section to configure LLDP.

4.8.1. LLDP

LLDP is a one-way protocol; there are no request/response sequences. Information is advertised by stations implementing the transmit function, and is received and processed by stations implementing the receive function. The LLDP category contains LLDP and LLDP-MED pages.

4.8.1.1. Property

To display LLDP Property Setting web page, click **Discovery > LLDP > Property**.




Figure 67 - Discovery > LLDP > Property

Item	Description
State	Enable/ Disable LLDP protocol on this switch.
LLDP Handling	<p>Select LLDP PDU handling action to be filtered, bridging or flooded when LLDP is globally disabled.</p> <ul style="list-style-type: none"> Filtering: Deletes the packet. Bridging: (VLAN-aware flooding) Forwards the packet to all VLAN members. Flooding: Forwards the packet to all ports
TLV Advertise Interval	Select the interval at which frames are transmitted. The default is 30 seconds, and the valid range is 5-32767 seconds.

Holdtime Multiplier	Select the multiplier on the transmit interval to assign to TTL (range 2-10, default = 4).
Reinitialization Delay	Select the delay before a re-initialization (range 1-10 seconds, default = 2).
Transmit Delay	Select the delay after an LLDP frame is sent (range 1-8191 seconds, default = 3).
Fast Start Repeat Count	Select fast start repeat count when port link up (range 1-10, default = 3).

4.8.1.2. Port Setting

To display LLDP Port Setting, click **Discovery > LLDP > Port Setting**.

Port Setting Table

<input type="checkbox"/>	Entry	Port	Mode	Selected TLV
<input type="checkbox"/>	1	GE1	Normal	802.1 PVID
<input type="checkbox"/>	2	GE2	Normal	802.1 PVID
<input type="checkbox"/>	3	GE3	Normal	802.1 PVID
<input type="checkbox"/>	4	GE4	Normal	802.1 PVID
<input type="checkbox"/>	5	GE5	Normal	802.1 PVID
<input type="checkbox"/>	6	GE6	Normal	802.1 PVID
<input type="checkbox"/>	7	GE7	Normal	802.1 PVID
<input type="checkbox"/>	8	GE8	Normal	802.1 PVID
<input type="checkbox"/>	9	GE9	Normal	802.1 PVID
<input type="checkbox"/>	10	GE10	Normal	802.1 PVID
<input type="checkbox"/>	11	GE11	Normal	802.1 PVID
<input type="checkbox"/>	12	GE12	Normal	802.1 PVID

Figure 68 - Discovery > LLDP > Port Setting

Item	Description
Port	Port Name.
Mode	The port LLDP mode.
Selected TLV	The Selected LLDP TLV.

Click "Edit" button to view Edit Port Setting menu.




Figure 69 - Discovery > LLDP > Port Setting > Edit Port Setting

Item	Description
Port	Select specified port or all ports to configure LLDP state.
Mode	Select the transmission state of LLDP port interface. <ul style="list-style-type: none"> Disable: Disable the transmission of LLDP PDUs.

	<ul style="list-style-type: none"> • RX Only: Receive LLDP PDUs only. • TX Only: Transmit LLDP PDUs only. • TX And RX: Transmit and receive LLDP PDUs both.
Optional TLV	<p>Select the LLDP optional TLVs to be carried (multiple selection is allowed).</p> <ul style="list-style-type: none"> • System Name • Port Description • System Description • System Capability • 802.3 MAC-PHY • 802.3 Link Aggregation • 802.3 Maximum Frame Size • Management Address • 802.1 PVID.
802.1 VLAN Name	<p>Select the VLAN Name ID to be carried (multiple selection is allowed).</p>

4.8.1.3. Packet View

To display LLDP Overloading, click **Discovery > LLDP > Packet View**.

Packet View Table

	Entry	Port	In-Use (Bytes)	Available (Bytes)	Operational Status	
<input type="radio"/>	1	GE1	48	1440	Not Overloading	
<input type="radio"/>	2	GE2	48	1440	Not Overloading	
<input type="radio"/>	3	GE3	48	1440	Not Overloading	
<input type="radio"/>	4	GE4	48	1440	Not Overloading	
<input type="radio"/>	5	GE5	48	1440	Not Overloading	
<input type="radio"/>	6	GE6	48	1440	Not Overloading	
<input type="radio"/>	7	GE7	48	1440	Not Overloading	
<input type="radio"/>	8	GE8	48	1440	Not Overloading	
<input type="radio"/>	9	GE9	48	1440	Not Overloading	
<input type="radio"/>	10	GE10	49	1439	Not Overloading	
<input type="radio"/>	11	GE11	49	1439	Not Overloading	
<input type="radio"/>	12	GE12	49	1439	Not Overloading	

Detail

Figure 70 - Discovery > LLDP > Packet View

Item	Description
Port	Port Name.
In-Use (Bytes)	Total number of bytes of LLDP information in each packet.
Available (Bytes)	Total number of available bytes left for additional LLDP information in each packet.
Operational Status	Overloading or not.

Click "Detail" button to view Packet View Detail menu.

Packet View Detail

Port	GE2
Mandatory TLVs	
Size (Bytes)	21
Operational Status	Transmitted
802.3 TLVs	
Size (Bytes)	0
Operational Status	Transmitted
Optional TLVs	
Size (Bytes)	0
Operational Status	Transmitted
802.1 TLVs	
Size (Bytes)	8
Operational Status	Transmitted
Total	
In-Use (Bytes)	48
Available (Bytes)	1440

Close


Figure 71 - Discovery > LLDP > Packet View > Packet View Detail

Item	Description
Port	Port Name.
Mandatory TLVs	Total mandatory TLV byte size. Status is sent or overloading.
802.3 TLVs	Total 802.3 TLVs byte size. Status is sent or overloading.
Optional TLVs	Total Optional TLV byte size. Status is sent or overloading.
802.1 TLVs	Total 802.1 TLVs byte size. Status is sent or overloading.
Total	Total number of bytes of LLDP information in each packet.

4.8.1.4. Local Information

Use the LLDP Local Information to view LLDP local device information.

To display LLDP Local Device, click **Discovery > LLDP > Local Information**.



Device Summary

Chassis ID Subtype	MAC address
Chassis ID	00:E0:4C:00:00:00
System Name	Switch
System Description	8-Port PoE Gigabit WEB Smart Switch with 4 Gigabit Combo Port
Supported Capabilities	Bridge
Enabled Capabilities	Bridge
Port ID Subtype	Local

Port Status Table

Entry	Port	LLDP State	LLDP-MED State
<input type="radio"/> 1	GE1	Normal	Enabled
<input type="radio"/> 2	GE2	Normal	Enabled
<input type="radio"/> 3	GE3	Normal	Enabled
<input type="radio"/> 4	GE4	Normal	Enabled
<input type="radio"/> 5	GE5	Normal	Enabled
<input type="radio"/> 6	GE6	Normal	Enabled
<input type="radio"/> 7	GE7	Normal	Enabled
<input type="radio"/> 8	GE8	Normal	Enabled
<input type="radio"/> 9	GE9	Normal	Enabled
<input type="radio"/> 10	GE10	Normal	Enabled
<input type="radio"/> 11	GE11	Normal	Enabled
<input type="radio"/> 12	GE12	Normal	Enabled

[Detail](#)

Figure 72 - Discovery > LLDP > Local Information

Item	Description
Chassis ID Subtype	Type of chassis ID, such as the MAC address.
Chassis ID	Identifier of chassis. Where the chassis ID subtype is a MAC address, the MAC address of the switch is displayed.

System Name	Name of switch.
System Description	Description of the switch.
Capabilities Supported	Primary functions of the device, such as Bridge, WLAN AP, or Router.
Capabilities Enabled	Primary enabled functions of the device.
Port ID Subtype	Type of the port identifier that is shown.
LLDP Status	LLDP Tx and Rx abilities.
LLDP Med Status	LLDP MED enable state.

Click “Detail” button on the page to view detail information of the selected port.

Local Information Detail

Chassis ID Subtype	MAC address
Chassis ID	00:E0:4C:00:00:00
System Name	Switch
System Description	8-Port PoE Gigabit WEB Smart Switch with 4 Gigabit Combo Port
Supported Capabilities	Bridge
Enabled Capabilities	Bridge
Port ID	GE2
Port ID Subtype	Local
Port Description	

Management Address Table

Address Subtype	Address	Interface Subtype	Interface Number
0 results found.			

MAC/PHY Detail

Auto-Negotiation Supported	N/A
Auto-Negotiation Enabled	N/A
Auto-Negotiation Advertised Capabilities	N/A
Operational MAU Type	N/A

802.3 Detail

802.3 Maximum Frame Size	N/A
--------------------------	-----

802.3 Link Aggregation

Aggregation Capability	N/A
Aggregation Status	N/A
Aggregation Port ID	N/A

Close

Figure 73 - Discovery > LLDP > Local Information > Detail

4.8.1.5. Neighbor

Use the LLDP Neighbor page to view LLDP neighbors information.

To display LLDP Remote Device, click **Discovery > LLDP > Neighbor**.

Neighbor Table

Showing All entries
Showing 0 to 0 of 0 entries

<input type="checkbox"/>	Local Port	Chassis ID Subtype	Chassis ID	Port ID Subtype	Port ID	System Name	Time to Live
0 results found.							

First
Previous
1
Next
Last

Clear
Refresh
Detail

Figure 74 - Discovery > LLDP > Neighbor

Item	Description
Local Port	Number of the local port to which the neighbor is connected.
Chassis ID Subtype	Type of chassis ID (for example, MAC address).
Port ID Subtype	Type of the port identifier that is shown.
Port ID	Identifier of port.
System Name	Published name of the switch.
Time to Live	Time interval in seconds after which the information for this neighbor is deleted.

Click “detail” to view selected neighbor detail information

Neighbor Information Detail			
Local Port		GE4	
Basic Detail			
Chassis ID Subtype		MAC address	
Chassis ID		00:E0:4C:00:00:00	
Port ID Subtype		Local	
Port ID		gi18	
Port Description			
System Name			
System Description			
Supported Capabilities		N/A	
Enabled Capabilities		N/A	
Management Address Table			
Address Subtype	Address	Interface Subtype	Interface Number
0 results found.			
MAC/PHY Detail			
Auto-Negotiation Supported		N/A	
Auto-Negotiation Enabled		N/A	
Auto-Negotiation Advertised Capabilities		N/A	
Operational MAU Type		N/A	
802.3 Power via MDI			
MDI Power Support Port Class		N/A	
PSE MDI Power Support		N/A	
PSE MDI Power State		N/A	
PSE Power Pair Control Ability		N/A	
PSE Power Pair		N/A	
PSE Power Class		N/A	
Power Type		N/A	
Power Source		N/A	
Power Priority		N/A	
PD Request Power Value		N/A	
PSE Allocated Power Value		N/A	
802.3 Detail			
802.3 Maximum Frame Size		N/A	
802.3 Link Aggregation			
Aggregation Capability		N/A	
Aggregation Status		N/A	
Aggregation Port ID		N/A	
802.1 VLAN and Protocol			
PVID		1	
VLAN Name		N/A	
<input type="button" value="Close"/>			

Figure 75 LLDP Neighbor Detail Page

4.8.1.6. Statistics

The Link Layer Discovery Protocol (LLDP) Statistics page displays summary and per-port information for LLDP frames transmitted and received on the switch.

To display LLDP Statistics status, click **Discovery > LLDP > Statistics**.




Figure 76 - Discovery > LLDP > Statistics

Item	Description
Insertions	The number of times the complete set of information advertised by a particular MAC Service Access Point (MSAP) has been inserted into tables associated with the remote systems.
Deletions	The number of times the complete set of information advertised by MSAP has been deleted from tables associated with the remote systems.
Drops	The number of times the complete set of information advertised by MSAP could not be entered into tables associated with the remote systems because of insufficient

	resources.
Age Outs	The number of times the complete set of information advertised by MSAP has been deleted from tables associated with the remote systems because the information timeliness interval has expired.
Statistics Table	
Port	Interface or port number.
Transmit Frame Total	Number of LLDP frames transmitted on the corresponding port.
Receive Frame Total	Number of LLDP frames received by this LLDP agent on the corresponding port, while the LLDP agent is enabled.
Receive Frame Discard	Number of LLDP frames discarded for any reason by the LLDP agent on the corresponding port.
Receive Frame Error	Number of invalid LLDP frames received by the LLDP agent on the corresponding port, while the LLDP agent is enabled.
Receive TLV Discard	Number of TLVs of LLDP frames discarded for any reason by the LLDP agent on the corresponding port.
Receive TLV Unrecognized	Number of TLVs of LLDP frames that are unrecognized while the LLDP agent is enabled.
Neighbor Timeout	Number of age out LLDP frames.

4.9. Multicast

Use this section to configure Multicast.

4.9.1. General

Use the General pages to configure settings of IGMP and MLD common function.

4.9.1.1. Property

To display multicast general property Setting web page, click **Multicast> General> Property**




Figure 77 - Multicast > General > Property

Item	Description
Unknown Multicast Action	Set the unknown multicast action <ul style="list-style-type: none"> Flood: flood the unknown multicast data. Drop: drop the unknown multicast data. Router port: forward the unknown multicast data to router port.
IPv4	Set the ipv4 multicast forward method. <ul style="list-style-type: none"> MAC-VID: forward method dmac+vid. DIP-VID: forward method dip+vid.

IPv6	Set the ipv6 multicast forward method. • • MAC-VID: forward method dmac+vid. • • DIP-VID: forward method dip+vid(dip is ipv6 low 32 bit).
------	---

4.9.1.2. Group Address

This page allow user to browse all multicast groups that dynamic learned or statically added.

To display Multicast General Group web page, click **Multicast> General> Group Address**




Figure 78 - Multicast > General > Group Address

Item	Description
IP Version	IP Version • IPv4: ipv4 multicast group • IPv6: ipv6 multicast group
VLAN	The VLAN ID of group.
Group Address	The group IP address.

Member	The member ports of group.
Type	The type of group. Static or Dynamic.
Life(Sec)	The life time of this dynamic group.

Click "Add" or "Edit" button to view Add or Edit Group Address menu.

Add Group Address

VLAN

1

IP Version

IPv4

Group Address

Member

Available Port

GE1
GE2
GE3
GE4
GE5
GE6
GE7
GE8

>
<

Selected Port

Apply

Close

Edit Group Address

VLAN

1

Group Address

225.0.0.1

Member

Available Port

GE1
GE3
GE4
GE5
GE6
GE7
GE8
GE9

>
<

Selected Port

GE2

Apply

Close

Figure 79 - Multicast > General > Group Address > Add/Edit Group Address

Item	Description
VLAN	The VLAN ID of group.
IP Version	IP Version <ul style="list-style-type: none"> IPv4: ipv4 multicast group IPv6: ipv6 multicast group
Group Address	The group IP address.
Member	The member ports of group. <ul style="list-style-type: none"> Available Port: Optional port member Selected Port: Selected port member

4.9.1.3. Router Port

This page allow user to browse all router port information. The static and forbidden router port can set by user.

To display multicast router port table web page, click **Multicast> General> Router Port**




Figure 80 - Multicast > General > Router Port

Item	Description
IP Version	IP Version <ul style="list-style-type: none"> IPv4: ipv4 multicast router IPv6: ipv6 multicast router
VLAN	The VLAN ID router entry.
Member	Router Port member (include static and learned port member).
Static Port	Static router port member.
Forbidden Port	Forbidden router port member.
Life (Sec)	The expiry time of the router entry.

Click "Add" or "Edit" button to view Add/Edit Router Port menu.

Add Router Port

VLAN	Available VLAN	Selected VLAN
	<div>1</div> <div>3</div>	
IP Version	<div>IPv4</div>	
Type	<input checked="" type="radio"/> Static <input type="radio"/> Forbidden	
Port	Available Port	Selected Port
	<div>GE1</div> <div>GE2</div> <div>GE3</div> <div>GE4</div> <div>GE5</div> <div>GE6</div> <div>GE7</div> <div>GE8</div>	




Figure 81 - Multicast > General > Router Port > Add/Edit Router Port

Item	Description
VLAN	<p>The VLAN ID for router entry</p> <ul style="list-style-type: none"> Available VLAN: Optional VLAN member Selected VLAN: Selected VLAN member.
IP Version	<p>IP Version</p> <ul style="list-style-type: none"> IPv4: ipv4 multicast router IPv6: ipv6 multicast router
Type	<p>The router port type</p> <ul style="list-style-type: none"> Static: static router port Forbidden: forbidden router port, can't learn dynamic router port member
Port	<p>The member ports of router entry.</p> <ul style="list-style-type: none"> Available Port: Optional router port member Selected Port: Selected router port member

4.9.2. IGMP Snooping

Use the IGMP Snooping pages to configure settings of IGMP snooping function.

4.9.2.1. Property

This page allow user to configure global settings of IGMP snooping and configure specific VLAN settings of IGMP Snooping.

To display IGMP Snooping global setting and VLAN Setting web page, click **Multicast> IGMP Snooping> Property**




Figure 82 - Multicast > IGMP Snooping > Property

Item	Description
State	Set the enabling status of IGMP Snooping functionality <ul style="list-style-type: none"> Enable: If Checked Enable IGMP Snooping, else is Disabled IGMP Snooping.
Version	Set the igmp snooping version <ul style="list-style-type: none"> IGMPv2: Only support process igmp v2 packet.

	<ul style="list-style-type: none"> IGMPv3: Support v3 basic and v2.
Report Suppression	Set the enabling status of IGMP v2 report suppression <ul style="list-style-type: none"> Enable: If Checked Enable IGMP Snooping v2 report suppression, else Disable the report suppression function.
VLAN	The IGMP entry VLAN ID.
Operation Status	The enable status of IGMP snooping VLAN functionality.
Router Port Auto Learn	The enabling status of IGMP snooping router port auto learning.
Query Robustness	The Query Robustness allows tuning for the expected packet loss on a subnet.
Query Interval	The interval of querier to send general query.
Query Max Response Interval	In Membership Query Messages, it specifies the maximum allowed time before sending a responding report in units of 1/10 second.
Last Member Query count	The count that Querier-switch sends Group-Specific Queries when it receives a Leave Group message for a group.
Last Member Query Interval	The interval that Querier-switch sends Group-Specific Queries when it receives a Leave Group message for a group.
Immediate leave	The immediate leave status of the group will immediate leave when receive IGMP Leave message.

Click "Edit" button to Edit VLAN Setting menu.

Edit VLAN Setting

VLAN	1
State	<input type="checkbox"/> Enable
Router Port Auto Learn	<input checked="" type="checkbox"/> Enable
Immediate leave	<input type="checkbox"/> Enable
Query Robustness	2 (1 - 7, default 2)
Query Interval	125 Sec (30 - 18000, default 125)
Query Max Response Interval	10 Sec (5 - 20, default 10)
Last Member Query Counter	2 (1 - 7, default 2)
Last Member Query Interval	1 Sec (1 - 25, default 1)
Operational Status	
Status	Disabled
Query Robustness	2
Query Interval	125 (Sec)
Query Max Response Interval	10 (Sec)
Last Member Query Counter	2
Last Member Query Interval	1 (Sec)

Apply
Close

Figure 83 - Multicast > IGMP Snooping > Property >Edit VLAN Setting

Item	Description
VLAN	The selected VLAN List.
State	Set the enabling status of IGMP Snooping VLAN functionality <ul style="list-style-type: none"> Enable: If Checked Enable IGMP Snooping VLAN, else is Disabled IGMP Snooping VLAN.
Router Port Auto Learn	Set the enabling status of IGMP Snooping router port learning <ul style="list-style-type: none"> Enable: If checked Enable learning router port by query and PIM, DVRMP, else Disable the learning router port.
Immediate leave	Immediate Leave the group when receive IGMP Leave message.

	<ul style="list-style-type: none"> • Enable: If checked Enable immediate leave, else disable immediate leave.
Query Robustness	The Admin Query Robustness allows tuning for the expected packet loss on a subnet.
Query Interval	The Admin interval of querier to send general query.
Query Max Response Interval	The Admin query max response interval, In Membership Query Messages, it specifies the maximum allowed time before sending a responding report in units of 1/10 second.
Last Member Query Counter	The Admin last member query count that Querier-switch sends Group-Specific Queries when it receives a Leave Group message for a group.
Last Member Query Interval	The Admin last member query interval that Querier-switch sends Group-Specific Queries when it receives a Leave Group message for a group.
Operational Status	
Status	Operational IGMP snooping status, must both IGMP snooping global and IGMP snooping enable the status will be enable.
Query Robustness	Operational Query Robustness.
Query Interval	Operational Query Interval.
Query Max Response Interval	Operational Query Max Response Interval
Last Member Query Counter	Operational Last Member Query Count.

Last Member Query Interval	Operational Last Member Query Interval.
----------------------------	---

4.9.2.2. Querier

This page allow user to configure querier settings on specific VLAN of IGMP Snooping.

To display IGMP Snooping Querier Setting web page, click **Multicast> IGMP Snooping> Querier**



Figure 84 - Multicast > IGMP Snooping > Querier

Item	Description
VLAN	IGMP Snooping querier entry VLAN ID.
State	The IGMP Snooping querier Admin State.
Operational Status	The IGMP Snooping querier operational status.
Querier Version	The IGMP Snooping querier operational version.
Querier IP	The operational Querier IP address on the VLAN.

Click "Edit" button to view Edit Querier menu.




Figure 85 - Multicast > IGMP Snooping > Querier > Edit Querier

Item	Description
VLAN	The Selected Edit IGMP Snooping querier VLAN List.
State	Set the enabling status of IGMP Querier Election on the chose VLANs <ul style="list-style-type: none"> Enabled: if checked Enable IGMP Querier else Disable IGMP Querier.
Version	Set the query version of IGMP Querier Election on the chose VLANs <ul style="list-style-type: none"> IGMPv2: Querier version 2. IGMPv3: Querier version 3. (IGMP Snooping version should be IGMPv3)

4.9.2.3. Statistics

This page allow user to clear igmp snooping statics.

To display IGMP Snooping Statistics, click **Multicast> IGMP Snooping> Statistics**

Receive Packet	
Total	8
Valid	1
InValid	7
Other	0
Leave	0
Report	0
General Query	0
Special Group Query	0
Source-specific Group Query	0
Transmit Packet	
Leave	0
Report	0
General Query	0
Special Group Query	0
Source-specific Group Query	0

Figure 96 - Multicast > IGMP Snooping > Statistics

Item	Description
Receive Packet	
Total	Total RX igmp packet, include ipv4 multicast data to CPU.
Valid	The valid igmp snooping process packet.
Invalid	The invalid igmp snooping process packet.
Other	The ICMP protocol is not 2, and is not ipv4 multicast data packet.
Leave	IGMP leave packet.
Report	IGMP join and report packet.
General Query	IGMP General Query packet.
Special Group Query	IGMP Special Group General Query packet.

Source-specific Group Query	IGMP Special Source and Group General Query packet.
Transmit Packet	
Leave	IGMP leave packet
Report	IGMP join and report packet
General Query	IGMP general query packet include querier transmit general query packet.
Special Group Query	IGMP special group query packet include querier transmit special group query packet.
Source-specific Group Query	IGMP Special Source and Group General Query packet.

4.9.4 MVR

Use the MVR pages to configure settings of MVR function.

4.9.4.1. Property

To display multicast MVR property Setting web page, click **Multicast> MVR> Property**

State	<input type="checkbox"/> Enable	
VLAN	1	
Mode	<input checked="" type="radio"/> Compatible <input type="radio"/> Dynamic	
Group Start	0.0.0.0	
Group Count	1	(1 - 128)
Query Time	1	Sec (1 - 10)
Operational Group		
Maximum	128	
Current	0	

Apply

Figure 87 - Multicast > MVR > Property

Item	Description
State	<ul style="list-style-type: none"> Enable: if checked enable the MVR state, else disable the MVR state.
VLAN	The MVR VLAN ID.
Mode	Set the MVR mode <ul style="list-style-type: none"> Compatible: compatible mode. Dynamic: dynamic mode, will learn group member on source port.
Group Start	MVR group range start.
Group Count	MVR group continue count.
Query Time	MVR query time when receive MVR leave MVR group packet.
Maximum	The max number of MVR group database.
Current	The learned MVR group current time

4.9.4.2. Port Setting

This page allow user to configure port role and port immediate leave.

To display MVR port role and immediate leave state setting web page, click **Multicast> MVR> Port Setting**

Port Setting Table

<input type="checkbox"/>	Entry	Port	Role	Immediate Leave
<input type="checkbox"/>	1	GE1	None	Disabled
<input type="checkbox"/>	2	GE2	None	Disabled
<input type="checkbox"/>	3	GE3	None	Disabled
<input type="checkbox"/>	18	LAG6	None	Disabled
<input type="checkbox"/>	19	LAG7	None	Disabled
<input type="checkbox"/>	20	LAG8	None	Disabled

Figure 88 - Multicast > MVR > Port Setting

Item	Description
Entry	Entry of number.
Port	Port Name.
Role	Port Role for MVR, the type is None/Receiver/Source.
Immediate Leave	Status of immediate leave.

Click "Edit" button to view Edit Port Setting menu.




Figure 89 - Multicast > MVR > Port Setting > Edit Port Setting

Item	Description
Port	Display the selected port list.
Role	MVR port role <ul style="list-style-type: none"> • None: port role is none. • Receiver: port role is receiver. • Source: port role is source.
Immediate Leave	MVR Port immediate leave <ul style="list-style-type: none"> • Enable: if checked is enable immediate leave, else disable immediate leave.

4.9.4.3. Group Address

This page allow user to browse all multicast MVR groups that dynamic learned or statically added.

To display Multicast MVR Group web page, click **Multicast> MVR> Group Address**




Figure 90 - Multicast > MVR > Group Address

Item	Description
VLAN	The VLAN ID of MVR group.
Group Address	The MVR group IP address.
Member	The member ports of MVR group.
Type	The type of MVR group. Static or Dynamic.
Life(Sec)	The life time of this dynamic MVR group.

Click "Add" button to view Add Group Address Table menu.




Figure 91 - Multicast > MVR > Group Address > Add Group Address

Item	Description
VLAN	The VLAN ID of MVR group.
Group Address	The MVR group IP address.
Member	<p>The member ports of MVR group.</p> <ul style="list-style-type: none"> Available Port: Optional port member, it is only receiver port when MVR mode is compatible, it include source port when mode is dynamic. Selected Port: Selected port member

4.10. Security

Use the Security pages to configure settings for the switch security features.

4.10.1. RADIUS

This page allow user to add, edit or delete RADIUS server settings and modify default parameter of RADIUS server.

To display RADIUS web page, click **Security > RADIUS**




Figure 92 - Security > RADIUS

Item	Description
Retry	Set default retry number.
Timeout	Set default timeout value.
Key String	Set default RADIUS key string
RADIUS Table	
Server Address	RADIUS server address.
Server Port	RADIUS server port.
Priority	RADIUS server priority (smaller value has higher priority). RADIUS session will try to establish with the server setting which has highest priority. If failed, it will try to connect to the server with next higher priority.
Retry	RADIUS server retry value. If it is fail to connect to server, it will keep trying until timeout with retry times.
Timeout	RADIUS server timeout value. If it is fail to connect to server, it will keep trying until timeout.
Usage	RADIUS server usage type <ul style="list-style-type: none">• Login: For login authentication.• 802.1x: For 802.1x authentication.• All: For all types.

Click "Add" or "Edit" button to view Add/Edit RADIUS Server menu.

Add RADIUS Server

Address Type	<input checked="" type="radio"/> Hostname <input type="radio"/> IPv4 <input type="radio"/> IPv6	
Server Address		
Server Port	1812	(0 - 65535, default 1812)
Priority		(0 - 65535)
Key String	<input checked="" type="checkbox"/> Use Default 	
Retry	<input checked="" type="checkbox"/> Use Default 3 (1 - 10, default 3)	
Timeout	<input checked="" type="checkbox"/> Use Default 3 Sec (1 - 30, default 3)	
Usage	<input type="radio"/> Login <input type="radio"/> 802.1X <input checked="" type="radio"/> All	

Apply
Close

Edit RADIUS Server

Server Address	23121	
Server Port	1812	(0 - 65535, default 1812)
Priority	2	(0 - 65535)
Key String	<input checked="" type="checkbox"/> Use Default 121321	
Retry	<input checked="" type="checkbox"/> Use Default 3 (1 - 10, default 3)	
Timeout	<input checked="" type="checkbox"/> Use Default 3 Sec (1 - 30, default 3)	
Usage	<input type="radio"/> Login <input type="radio"/> 802.1X <input checked="" type="radio"/> All	

Apply
Close

Figure 93 - Security > RADIUS > Add/Edit RADIUS Server

Item	Description
Address Type	In add dialog, user need to specify server Address Type <ul style="list-style-type: none"> • Hostname: Use domain name as server address. • IPv4: Use IPv4 as server address. • IPv6: Use IPv6 as server address.
Server Address	In add dialog, user need to input server address based on address type. In edit dialog, it shows current edit server address.
Server Port	Set RADIUS server port.
Priority	Set RADIUS server priority (smaller value has higher priority). RADIUS session will try to establish with the server setting which has highest priority. If failed, it will try to connect to the server with next higher priority.
Retry	Set RADIUS server retry value. If it is fail to connect to server, it will keep trying until timeout with retry times.
Timeout	Set RADIUS server timeout value. If it is fail to connect to server, it will keep trying until timeout.
Usage	Set RADIUS server usage type <ul style="list-style-type: none"> • Login: For login authentication. • 802.1x: For 802.1x authentication. • All: For all types.

4.10.2. Management Access

Use the Management Access pages to configure settings of management access.

4.10.2.1. Management Service

This page allow user to change management services related configurations.

To display Management Service click **Security > Management Access > Management Service**

Management Service		
Telnet	<input type="checkbox"/>	Enable
SSH	<input type="checkbox"/>	Enable
HTTP	<input checked="" type="checkbox"/>	Enable
HTTPS	<input type="checkbox"/>	Enable
SNMP	<input checked="" type="checkbox"/>	Enable

Session Timeout		
Console	<input type="text" value="10"/>	Min (0 - 65535, default 10)
Telnet	<input type="text" value="10"/>	Min (0 - 65535, default 10)
SSH	<input type="text" value="10"/>	Min (0 - 65535, default 10)
HTTP	<input type="text" value="10"/>	Min (0 - 65535, default 10)
HTTPS	<input type="text" value="10"/>	Min (0 - 65535, default 10)

Password Retry Count		
Console	<input type="text" value="3"/>	(0 - 120, default 3)
Telnet	<input type="text" value="3"/>	(0 - 120, default 3)
SSH	<input type="text" value="3"/>	(0 - 120, default 3)

Silent Time		
Console	<input type="text" value="0"/>	Sec (0 - 65535, default 0)
Telnet	<input type="text" value="0"/>	Sec (0 - 65535, default 0)
SSH	<input type="text" value="0"/>	Sec (0 - 65535, default 0)

Apply

Figure 94 - Security > Management Access > Management Service

Item	Description
Management Service	<p>Management service admin state.</p> <ul style="list-style-type: none"> • Telnet: Connect CLI through telnet. • SSH: Connect CLI through SSH. • HTTP: Connect WEBUI through HTTP. • HTTPS: Connect WEBUI through HTTPS. • SNMP: Manage switch trough SNMP.

Session Timeout	Set session timeout minutes for user access to user interface. 0 minutes means never timeout.
Password Retry Count	Retry count is the number which CLI password input error tolerance count. After input error password exceeds this count, the CLI will freeze after silent time.
Silent Time	After input error password exceeds password retry count, the CLI will freeze after silent time.

4.10.2.2. Management ACL

This page allow user to add or delete management ACL rule. A rule cannot be deleted if under active.

To display Management ACL page, click **Security > Management Access > Management ACL**




Figure 95 - Security > Management Access > Management ACL

Item	Description
ACL Name	Input MAC ACL name.
Management ACL	
ACL Name	Display Management ACL name.

State	Display Management ACL whether active.
Rule	Display the number Management ACE rule of ACL.

4.10.2.3. Management ACE

This page allow user to add, edit or delete ACE rule. An ACE rule cannot be edited or deleted if ACL under active. New ACE cannot be added if ACL under active

To display Management ACE page, click **Security > Management Access > Management ACE**




Figure 96 - Security > Management Access > Management ACE

Item	Description
ACL Name	Select the ACL name to which an ACE is being added.
Priority	Display the priority of ACE.
Action	Display the action of ACE.
Service	Display the service ACE
Port	Display the port list of ACE
Address / Mask	Display the source IP address and mask of ACE.

Click "Add" or "Edit" button to view Add/Edit Management ACE menu.

Add Managemet ACE

ACL Name efef

Priority 1 (1 - 65535)

Service

☐ All
☐ Http
☐ Https
☒ Snmp
☐ SSH
☐ Telnet

Action

☐ Permit
☒ Deny

Port

Available Port: GE1, GE2, GE3, GE4, GE5, GE6, GE7, GE8
Selected Port:

IP Version

☒ All
☐ IPv4
☐ IPv6

IPv4 / 255.255.255.255

IPv6 / 128 (1 - 128)

Apply Close

Edit Managemet ACE

ACL Name 3515

Priority 1

Service

☐ All
☐ Http
☐ Https
☒ Snmp
☐ SSH
☐ Telnet

Action

☐ Permit
☒ Deny

Port

Available Port: GE1, GE2, GE3, GE4, GE5, GE6, GE7, GE8
Selected Port: LAG3

IP Version

☒ All
☐ IPv4
☐ IPv6

IPv4 / 255.255.255.255

IPv6 / 128 (1 - 128)

Apply Close

Figure 97 - Security > Management Access > Add Management ACE

Item	Description
ACL Name	Display the ACL name to which an ACE is being added.
Priority	Specify the priority of the ACE. ACEs with higher sequence are processed first (1 is the highest priority). Only available on Add Dialog.
Service	Select the type service of rule. <ul style="list-style-type: none"> All: All services. HTTP: Only HTTP service. HTTPs: Only HTTPs service. SNMP: Only SNMP service. SSH: Only SSH service. Telnet: Only Telnet service
Action	Select the action after ACE match packet.

	<ul style="list-style-type: none"> • Permit: Forward packets that meet the ACE criteria. • Deny: Drop packets that meet the ACE criteria.
Port	Select ports which will be matched.
IP Version	Select the type of source IP address. • <ul style="list-style-type: none"> • All: All IP addresses can access. • • IPv4: Specify IPv4 address ca access. • • IPv6: Specify IPv6 address ca access.
IPv4	Enter the source IPv4 address value and mask to which will be matched.
IPv6	Enter the source IPv6 address value and mask to which will be matched.

4.10.3. Authentication Manager

4.10.3.1. Property

This page allow user to edit authentication global settings and some port modes' configurations.

To display authentication manager Property web page, click **Security > Authentication Manager > Property**.

Authentication Type

Guest VLAN

MAC-Based User ID Format

☐ 802.1x

☐ MAC-Based

☐ WEB-Based

☐ Enable

Port Mode Table

	Entry	Port	Authentication Type			Host Mode	Order	Method	Guest VLAN	VLAN Assign Mode
			802.1x	MAC-Based	WEB-Based					
<input type="checkbox"/>	1	GE1	Disabled	Disabled	Disabled	Multiple Authentication	802.1x	RADIUS	Disabled	Static
<input type="checkbox"/>	2	GE2	Disabled	Disabled	Disabled	Multiple Authentication	802.1x	RADIUS	Disabled	Static
<input type="checkbox"/>	3	GE3	Disabled	Disabled	Disabled	Multiple Authentication	802.1x	RADIUS	Disabled	Static
<input type="checkbox"/>	10	GE10	Disabled	Disabled	Disabled	Multiple Authentication	802.1x	RADIUS	Disabled	Static
<input type="checkbox"/>	11	GE11	Disabled	Disabled	Disabled	Multiple Authentication	802.1x	RADIUS	Disabled	Static
<input type="checkbox"/>	12	GE12	Disabled	Disabled	Disabled	Multiple Authentication	802.1x	RADIUS	Disabled	Static

Figure 98 - Security > Authentication Manager > Property


Item	Description
Authentication Type	Set checkbox to enable/disable following authentication types <ul style="list-style-type: none"> 802.1x: Use IEEE 802.1x to do authentication MAC-Based: Use MAC address to do authentication WEB-Based: Prompt authentication web page for user to do authentication
Guest VLAN	Set checkbox to enable/disable guest VLAN, if guest VLAN is enabled, you need to select one available VLAN ID to be guest VID.
MAC-Based User ID Format	Select mac-based authentication RADIUS username/password ID format. <ul style="list-style-type: none"> XXXXXXXXXXXX Xxxxxxxxxxxxxx XX:XX:XX:XX:XX:XX xx:xx:xx:xx:xx:xx

	<ul style="list-style-type: none"> • XX-XX-XX-XX-XX-XX • XX-XX-XX-XX-XX-XX • XX.XX.XX.XX.XX.XX • XX.XX.XX.XX.XX.XX • XXXX:XXXX:XXXX • XXXX:XXXX:XXXX
Port Mode Table	
Port	Port Name.
Authentication Type (802.1X)	802.1X authentication type state <ul style="list-style-type: none"> • Enabled: 802.1X is enabled. • Disabled: 802.1X is disabled.
Authentication Type (MAC-Based)	MAC-Based authentication type state <ul style="list-style-type: none"> • Enabled: MAC-Based authentication is enabled • Disabled: MAC-Based authentication is disabled
Authentication Type (WEB-Based)	WEB-Based authentication type state <ul style="list-style-type: none"> • Enabled: WEB-Based authentication is enabled • Disabled: WEB-Based authentication is disabled
Host Mode	Authenticating host mode <ul style="list-style-type: none"> • Multiple Authentication: In this mode, every client need to pass authenticate procedure individually. • Multiple Hosts: In this mode, only one client need to be authenticated and other clients will get the same access accessibility. Web-auth cannot be enabled in this mode. • Single Host: In this mode, only one host is allowed to be

	authenticated. It is the same as Multi-auth mode with max hosts number configure to be 1.
Order	<p>Support following authentication type order combinations. Web Authentication should always be the last type. The authentication manager will go to next type if current type is not enabled or authenticated fail. •</p> <ul style="list-style-type: none"> • 802.1x • • MAC-Based • • WEB-Based • • 802.1x MAC-Based • • 802.1x WEB-Based • • MAC-Based 802.1x • • WEB-Based 802.1x • • 802.1x MAC-Based WEB-Based • • 802.1x WEB-Based MAC-Based
Method	<p>Support following authentication method order combinations.</p> <p>These orders only available on MAC-Based authentication and WEB-Based authentication. 802.1x only support Radius method.</p> <ul style="list-style-type: none"> • Local: Use DUT' s local database to do authentication • Radius: Use remote RADIUS server to do authentication • Local Radius • Radius Local
Guest VLAN	<p>Port guest VLAN enable state</p> <ul style="list-style-type: none"> • Enabled: Guest VLAN is enabled on port.

	<ul style="list-style-type: none"> Disabled: Guest VLAN is disabled on port.
VLAN Assign Mode	<p>Support following VLAN assign mode and only apply when source is RADIUS</p> <ul style="list-style-type: none"> Disable: Ignore the VLAN authorization result and keep original VLAN of host. Reject: If get VLAN authorized information, just use it. However, if there is no VLAN authorized information, reject the host and make it unauthorized. Static: If get VLAN authorized information, just use it. If there is no VLAN authorized information, keep original VLAN of host.

Click “Edit” button to view the Edit Port Mode menu.



Edit Port Mode

Port GE4

Authentication Type ☐ 802.1x ☐ MAC-Based ☐ WEB-Based

Host Mode ☒ Multiple Authentication ☐ Multiple Hosts ☐ Single Host

Order Available Type: MAC-Based, WEB-Based; Select Type: 802.1x

Method Available Method: Local; Select Method: RADIUS

Guest VLAN ☐ Enable

VLAN Assign Mode ☐ Disable ☐ Reject ☒ Static

Apply Close

Figure 99 - Security > Authentication Manager > Property > Edit Port Mode

Item	Description
Port	Selected port list.
Authentication Type	Set checkbox to enable/disable authentication types.
Host Mode	<p>Select authenticating host mode</p> <ul style="list-style-type: none"> • Multiple Authentication: In this mode, every client need to pass authenticate procedure individually. • Multiple Hosts: In this mode, only one client need to be authenticated and other clients will get the same access accessibility. Web-auth cannot be enabled in this mode. • Single Host: In this mode, only one host is allowed to be authenticated. It is the same as Multi-auth mode with max hosts number configure to be 1.
Order	<p>Support following authentication type order combinations. Web Authentication should always be the last type. The authentication manager will go to next type if current type is not enabled or authenticated fail. •</p> <ul style="list-style-type: none"> • 802.1x • • MAC-Based • • WEB-Based • • 802.1x MAC-Based • • 802.1x WEB-Based • • MAC-Based 802.1x • • WEB-Based 802.1x • • 802.1x MAC-Based WEB-Based • • 802.1x WEB-Based MAC-Based

Method	<p>Support following authentication method order combinations.</p> <ul style="list-style-type: none">• These orders only available on MAC-Based authentication and WEB-Based authentication. 802.1x only support Radius method.• Local: Use DUT' s local database to do authentication.• Radius: Use remote RADIUS server to do authentication.• Local Radius.• Radius Local.
Guest VLAN	<p>Set checkbox to enable/disable guest VLAN.</p>
VLAN Assign Mode	<p>Support following VLAN assign mode and only apply when source is RADIUS</p> <ul style="list-style-type: none">• Disable: Ignore the VLAN authorization result and keep original VLAN of host.• Reject: If get VLAN authorized information, just use it. However, if there is no VLAN authorized information, reject the host and make it unauthorized.• Static: If get VLAN authorized information, just use it. If there is no VLAN authorized information, keep original VLAN of host.

4.10.3.2. Port Setting

This page allow user to configure authentication manger port settings

To display the authentication manager Port Setting web page, click **Security > Authentication Manager > Port Setting**.

Port Setting Table

	Entry	Port	Port Control	Reauthentication	Max Hosts	Common Timer			802.1x Parameters				Web-Based Parameters	
						Reauthentication	Inactive	Quiet	TX Period	Supplicant Timeout	Server Timeout	Max Request	Max Login	
<input type="checkbox"/>	1	GE1	Disabled	Disabled	256	3600	60	60	30	30	30	2	3	
<input type="checkbox"/>	2	GE2	Disabled	Disabled	256	3600	60	60	30	30	30	2	3	
<input type="checkbox"/>	3	GE3	Disabled	Disabled	256	3600	60	60	30	30	30	2	3	
<input type="checkbox"/>	10	GE10	Disabled	Disabled	256	3600	60	60	30	30	30	2	3	
<input type="checkbox"/>	11	GE11	Disabled	Disabled	256	3600	60	60	30	30	30	2	3	
<input type="checkbox"/>	12	GE12	Disabled	Disabled	256	3600	60	60	30	30	30	2	3	

[Edit](#)
Figure 100 - Security > Authentication Manager > Port Setting

Item	Description
Port	Port
Port Control	<p>Support following authentication port control types.</p> <ul style="list-style-type: none"> • Disable: Disable authentication function and all clients have network accessibility. • Force Authorized: Port is force authorized and all clients have network accessibility. • Force Unauthorized: Port is force unauthorized and all clients have no network accessibility. • Auto: Need passing authentication procedure to get network accessibility.
Reauthentication	<p>Reauthenticate state</p> <ul style="list-style-type: none"> • Enabled: Host will be reauthenticated after reauthentication period. • Disabled: Host will not be reauthenticated after reauthentication period.

Max Hosts	In Multiple Authentication mode, total host number cannot not exceed max hosts number.
Common Timer (Reauthentication)	After re-authenticate period, host will return to initial state and need to pass authentication procedure again.
Common Timer (Inactive)	If no packet from the authenticated host, the inactive timer will increase. After inactive timeout, the host will be unauthorized and corresponding session will be deleted. In multi-host mode, the packet is counting on the authorized host only.
Common Timer (Quiet)	When port is in Locked state after authenticating fail several times, the host will be locked in quiet period. After this quiet period, the host is allowed to authenticate again.
802.1X Params (TX Period)	Number of seconds that the device waits for a response to an Extensible Authentication Protocol (EAP) request/identity frame from the supplicant (client) before resending the request.
802.1X Params (Supplicant Timeout)	The maximum number of EAP requests that can be sent. If a response is not received after the defined period (supplicant timeout), the authentication process is restarted.
802.1X Params (Server Timeout)	Number of seconds that lapses before EAP requests are resent to the supplicant.
802.1X Params (Max Request)	Number of seconds that lapses before the device resends a request to the authentication server.
Web-Based Param (Max Login)	Allow user login fail number. After login fail number exceed, the host will enter Lock state and is not able to authenticate until quiet period exceed.

Click "Edit" button to view Edit Port Setting menu.

Edit Port Setting

Port	GE2	
Port Control	<input checked="" type="radio"/> Disabled <input type="radio"/> Force Authorized <input type="radio"/> Force Unauthorized <input type="radio"/> Auto	
Reauthentication	<input type="checkbox"/> Enable	
Max Hosts	256	(1 - 256, default 256)
Common Timer		
Reauthentication	3600	Sec (300 - 4294967294, default 3600)
Inactive	60	Sec (60 - 65535, default 60)
Quiet	60	Sec (0 - 65535, default 60)
802.1x Parameters		
TX Period	30	Sec (1 - 65535, default 30)
Supplicant Timeout	30	Sec (1 - 65535, default 30)
Server Timeout	30	Sec (1 - 65535, default 30)
Max Request	2	(1 - 10, default 2)

Apply
Close

Figure 101 - Security > Authentication Manager > Port Setting > Edit Port Setting

Item	Description
Port	Port Name.
Port Control	Support following authentication port control types. <ul style="list-style-type: none"> • Disable: Disable authentication function and all clients have network accessibility. Force Authorized: Port is force authorized and all clients have network accessibility. • Force Unauthorized: Port is force unauthorized and all clients have no network accessibility. • Auto: Need passing authentication procedure to get

	network accessibility.
Reauthentication	Set checkbox to enable/disable reauthentication.
Max Hosts	In Multiple Authentication mode, total host number cannot not exceed max hosts number.
Common Timer	
Reauthentication	After re-authenticate period, host will return to initial state and need to pass authentication procedure again.
Inactive	If no packet from the authenticated host, the inactive timer will increase. After inactive timeout, the host will be unauthorized and corresponding session will be deleted. In multi-host mode, the packet is counting on the authorized host only and not all packets on the port.
Quiet	When port is in Locked state after authenticating fail several times, the host will be locked in quiet period. After this quiet period, the host is allowed to authenticate again.
802.1X Params	
TX Period	Number of seconds that the device waits for a response to an Extensible Authentication Protocol (EAP) request/identity frame from the supplicant (client) before resending the request.
Supplicant Timeout	The maximum number of EAP requests that can be sent. If a response is not received after the defined period (supplicant timeout), the authentication process is restarted.
Server Timeout	Number of seconds that lapses before EAP requests are resent to the supplicant.

Max Request	Number of seconds that lapses before the device resends a request to the authentication server.
-------------	---

4.10.3.3. Sessions

This page show all detail information of authentication sessions and allow user to select specific session to delete by clicking “Clear ” button.

To display Sessions web page, click **Security > Authentication Manger > Sessions**

Sessions Table

Showing

All

 entries

Showing 0 to 0 of 0 entries

Session ID	Port	MAC Address	Current Type	Status	Operational Information				Authorized Information			
					VLAN	Session Time	Inactived Time	Quiet Time	VLAN	Reauthentication Period	Inactive Timeout	
0 results found.												

Clear

Refresh

First

Previous

1

Next

Last

Figure 102 - Security > Authentication Manager > Sessions

Item	Description
Session ID	Session ID is unique of each session.
Port	Port name which the host located.
MAC Address	Host MAC address.
Current Type	<p>Show current authenticating type</p> <ul style="list-style-type: none"> 802.1x: Use IEEE 802.1X to do authenticating MAC-Based: Use MAC-Based authentication to do authenticating. WEB-Based: Use WEB-Based authentication to do authenticating.
Status	<p>Show host authentication session status</p> <ul style="list-style-type: none"> IP version (IPv4, IPv6)


	<ul style="list-style-type: none"> • Disable: This session is ready to be deleted • Running: Authentication process is running • Authorized: Authentication is passed and getting network accessibility. • Unauthorized: Authentication is not passed and not getting network accessibility. • Locked: Host is locked and do not allow to do
	<ul style="list-style-type: none"> • authenticating until quiet period. • Guest: Host is in the guest VLAN.
Operational(VLAN)	Shows host operational VLAN ID.
Operational (Session Time)	In “Authorized” state, it shows total time after authorized.
Operational (Inactivated)	In “Authorized” state, it shows how long the host do not send any packet.
Operational (Quiet Time)	In “Locked” state, it shows total time after locked.
Authorized (VLAN)	Shows VLAN ID given from authorized procedure.
Authorized (Reauthentication Period)	Shows reauthentication period given from authorized procedure.
Authorized (Inactive)	Shows inactive timeout given from authorized procedure.

Timeouts)

4.10.4. Port Security

This page allow user to configure port security settings for each interface. When port security is enabled on interface, action will be perform once learned MAC address over limitation.

To display Port Security web page, click **Security > Port Security**



State ☐ Enable

Apply

Port Security Table

Entry	Port	State	MAC Address	Action
1	GE1	Disabled	1	Discard
2	GE2	Disabled	1	Discard
3	GE3	Disabled	1	Discard
18	LAG6	Disabled	1	Discard
19	LAG7	Disabled	1	Discard
20	LAG8	Disabled	1	Discard

Edit

Figure 103 - Security > Port Security

Item	Description
State	Enable/Disable the port security function.
Port	Select one or multiple ports to configure.
State	Select the status of port security <ul style="list-style-type: none"> Disable: Disable port security function. Enable: Enable port security function.

MAC Address	Specify the number of how many mac addresses can be learned.
Action	<p>Select the action if learned mac addresses</p> <ul style="list-style-type: none"> • Forward: Forward this packet whose SMAC is new to system and exceed the learning-limit number. • Discard: Discard this packet whose SMAC is new to system and exceed the learning-limit number. • Shutdown: Shutdown this port when receives a packet whose SMAC is new to system and exceed the learning limit number.

Click "Edit" button to view Edit Port Security menu.



Figure 104 - Security > Port Security > Edit Port Security

Item	Description
Port	Select one or multiple ports to configure.
State	<p>Select the status of port security</p> <ul style="list-style-type: none"> • Disable: Disable port security function. • Enable: Enable port security function.
MAC Address	Specify the number of how many mac addresses can be learned.


Action	<p>Select the action if learned mac addresses</p> <ul style="list-style-type: none"> • Forward: Forward this packet whose SMAC is new to system and exceed the learning-limit number. • Discard: Discard this packet whose SMAC is new to system and exceed the learning-limit number. • Shutdown: Shutdown this port when receives a packet whose SMAC is new to system and exceed the learning limit number.
--------	---

4.10.5. Protected Port

This page allow user to configure protected port setting to prevent the selected ports from communication with each other. Protected port is only allowed to communicate with unprotected port. In other words, protected port is not allowed to communicate with another protected port.

To display Protected Port web page, click **Security > Protected Port**

Protected Port Table



Entry	Port	State
1	GE1	Unprotected
2	GE2	Unprotected
3	GE3	Unprotected
10	GE10	Unprotected
11	GE11	Unprotected
12	GE12	Unprotected

Figure 105 - Security > Protected Port

Item	Descripti on
Port	Port Name.
State	Port protected admin state.

	<ul style="list-style-type: none"> Protected: Port is protected. Unprotected: Port is unprotected
--	---

Click "Edit" button to view Edit Protected Port menu.




Figure 106 - Security > Protected Port > Edit Protected Port

Item	Description
Port	Selected port list.
State	Port protected admin state. <ul style="list-style-type: none"> Protected: Enable protecting function. Unprotected: Disable protecting function.

4.10.6. Storm Control

To display Storm Control global setting web page, click **Security > Storm Control**

Mode
☐ Packet / Sec
☒ Kbits / Sec

IFG
☒ Exclude
☐ Include

Port Setting Table

	Entry	Port	State	Broadcast		Unknown Multicast		Unknown Unicast		Action
				State	Rate (Kbps)	State	Rate (Kbps)	State	Rate (Kbps)	
<input type="checkbox"/>	1	GE1	Disabled	Disabled	10000	Disabled	10000	Disabled	10000	Drop
<input type="checkbox"/>	2	GE2	Disabled	Disabled	10000	Disabled	10000	Disabled	10000	Drop
<input type="checkbox"/>	3	GE3	Disabled	Disabled	10000	Disabled	10000	Disabled	10000	Drop
<input type="checkbox"/>	10	GE10	Disabled	Disabled	10000	Disabled	10000	Disabled	10000	Drop
<input type="checkbox"/>	11	GE11	Disabled	Disabled	10000	Disabled	10000	Disabled	10000	Drop
<input type="checkbox"/>	12	GE12	Disabled	Disabled	10000	Disabled	10000	Disabled	10000	Drop

Figure 107 - Security > Storm Control

Item	Description
Mode(Unit)	Select the unit of storm control <ul style="list-style-type: none"> Packet / Sec: storm control rate calculates by packet-based Kbits / Sec: storm control rate calculates by octet-based.
IFG	Select the rate calculates w/o preamble & IFG (20 bytes) <ul style="list-style-type: none"> Excluded: exclude preamble & IFG (20 bytes) when count ingress storm control rate. Included: include preamble & IFG (20 bytes) when count ingress storm control rate.

Click "Edit" button to view Edit Port Setting menu.




Figure 108 - Security > Storm Control > Edit Port Setting

Item	Description
Port	Select the setting ports.
State	Select the state of setting <ul style="list-style-type: none"> Enable: Enable the storm control function.
Broadcast	Enable: Enable the storm control function of Broadcast packet. Value of storm control rate, Unit: pps (packet per-second, range 1- 262143) or Kbps (Kbits per-second, range 16 - 1000000) depends on global mode setting.
Unknown Multicast	Enable: Enable the storm control function of Unknown multicast packet. Value of storm control rate, Unit: pps (packet per-second, range 1- 262143) or Kbps (Kbits per-second, range 16 - 1000000) depends on global mode setting.

Unknown Unicast	Enable: Enable the storm control function of Unknown unicast packet. Value of storm control rate, Unit: pps (packet per-second, range 1 - 262143) or Kbps (Kbits per-second, range 16 - 1000000) depends on global mode setting.
Action	Select the state of setting <ul style="list-style-type: none">• Drop: Packets exceed storm control rate will be dropped.• Shutdown: Port will be shutdown when packets exceed storm control rate.

4.10.7. DoS

A Denial of Service (DoS) attack is a hacker attempt to make a device unavailable to its users. DoS attacks saturate the device with external communication requests, so that it cannot respond to legitimate traffic. These attacks usually lead to a device CPU overload.

The DoS protection feature is a set of predefined rules that protect the network from malicious attacks. The DoS Security Suite Settings enables activating the security suite.

4.10.7.1. Property

To display Dos Global Setting web page, click **Security > Dos > Property**

POD	<input checked="" type="checkbox"/> Enable
Land	<input checked="" type="checkbox"/> Enable
UDP Blat	<input checked="" type="checkbox"/> Enable
TCP Blat	<input checked="" type="checkbox"/> Enable
DMAC = SMAC	<input checked="" type="checkbox"/> Enable
Null Scan Attack	<input checked="" type="checkbox"/> Enable
X-Mas Scan Attack	<input checked="" type="checkbox"/> Enable
TCP SYN-FIN Attack	<input checked="" type="checkbox"/> Enable
TCP SYN-RST Attack	<input checked="" type="checkbox"/> Enable
ICMP Fragment	<input checked="" type="checkbox"/> Enable
TCP-SYN	<input checked="" type="checkbox"/> Enable Note: Source Port < 1024
TCP Fragment	<input checked="" type="checkbox"/> Enable Note: Offset = 1
Ping Max Size	<input checked="" type="checkbox"/> Enable IPv4 <input checked="" type="checkbox"/> Enable IPv6 512 Byte (0 - 65535, default 512)
TCP Min Hdr size	<input checked="" type="checkbox"/> Enable 20 Byte (0 - 31, default 20)
IPv6 Min Fragment	<input checked="" type="checkbox"/> Enable 1240 Byte (0 - 65535, default 1240)
Smurf Attack	<input checked="" type="checkbox"/> Enable 0 Netmask Length (0 - 32, default 0)
<input type="button" value="Apply"/>	

Figure 109 - Security > DoS > Property

Item	Description
POD	Avoids ping of death attack.
Land	Drops the packets if the source IP address is equal to the destination IP address.
UDP Blat	Drops the packets if the UDP source port equals to the UDP destination port.
TCP Blat	Drops the packages if the TCP source port is equal to the TCP destination port.
DMAC = SMAC	Drops the packets if the destination MAC address is equal to the source MAC address.

Null Scan Attack	Drops the packets with NULL scan.
X-Mas Scan Attack	Drops the packets if the sequence number is zero, and the FIN, URG and PSH bits are set.
TCP SYN-FIN Attack	Drops the packets with SYN and FIN bits set.
TCP SYN-RST Attack	Drops the packets with SYN and RST bits set
ICMP Fragment	Drops the fragmented ICMP packets.
TCP SYN (SPORT<1024)	Drops SYN packets with sport less than 1024.
TCP Fragment (Offset = 1)	Drops the TCP fragment packets with offset equals to one.
Ping Max Size	Specify the maximum size of the ICMPv4/ICMPv6 ping packets. The valid range is from 0 to 65535 bytes, and the default value is 512 bytes.
IPv6 Min Fragment	Checks the minimum size of IPv6 fragments, and drops the packets smaller than the minimum size. The valid range is from 0 to 65535 bytes, and default value is 1240 bytes.
Smurf Attack	Avoids smurf attack. The length range of the netmask is from 0 to 323 bytes, and default length is 0 bytes.

4.10.7.2. Port Setting

To configure and display the state of DoS protection for interfaces, click **Security > DoS > Port Setting**.

Port Setting Table

<input type="checkbox"/>	Entry	Port	State
<input type="checkbox"/>	1	GE1	Disabled
<input type="checkbox"/>	2	GE2	Disabled
<input type="checkbox"/>	3	GE3	Disabled
<input type="checkbox"/>	4	GE4	Disabled
<input type="checkbox"/>	5	GE5	Disabled
<input type="checkbox"/>	6	GE6	Disabled
<input type="checkbox"/>	7	GE7	Disabled
<input type="checkbox"/>	8	GE8	Disabled
<input type="checkbox"/>	9	GE9	Disabled
<input type="checkbox"/>	10	GE10	Disabled
<input type="checkbox"/>	11	GE11	Disabled
<input type="checkbox"/>	12	GE12	Disabled

Figure 110 - Security > DoS > Port Setting

Item	Description
Port	Interface or port number.
State	Enable/Disable the DoS protection on the interface.

4.10.8. DHCP Snooping

Use the DHCP Snooping pages to configure settings of DHCP Snooping

4.10.8.1. Property

This page allow user to configure global and per interface settings of DHCP Snooping.

To display property page, click **Security > DHCP Snooping > Property**

State

☐ Enable

VLAN

Available VLAN

VLAN 1

>

<

Selected VLAN

Port Setting Table

<input type="checkbox"/>	Entry	Port	Trust	Verify Chaddr	Rate Limit
<input type="checkbox"/>	1	GE1	Disabled	Disabled	Unlimited
<input type="checkbox"/>	2	GE2	Disabled	Disabled	Unlimited
<input type="checkbox"/>	3	GE3	Disabled	Disabled	Unlimited
<input type="checkbox"/>	19	LAG7	Disabled	Disabled	Unlimited
<input type="checkbox"/>	20	LAG8	Disabled	Disabled	Unlimited

Figure 111 - Security > DHCP Snooping > Property

Item	Description
State	Set checkbox to enable/disable DHCP Snooping function.
VLAN	Select VLANs in left box then move to right to enable DHCP Snooping. Or select VLANs in right box then move to left to disable DHCP Snooping.
Port Setting Table	
Port	Display port ID.
Trust	Display enable/disabled trust attribute of interface.
Verify Chaddr	Display enable/disabled chaddr validation attribute of interface.
Rate Limit	Display rate limitation value of interface.

Click "Edit" button to view Edit Port Setting menu.




Figure 112 - Security > DHCP Snooping > Property > Edit Port Setting

Item	Description
Port	Display selected port to be edited
Trust	Set checkbox to enable/disabled trust of interface. All DHCP packet will be forward directly if enable trust. Default is disabled.
Verify Chaddr	Set checkbox to enable or disable chaddr validation of interface. All DHCP packets will be checked whether client hardware mac address is same as source mac in Ethernet header if enable chaddr validation. Default is disabled.
Rate Limit	Input rate limitation of DHCP packets. The unit is pps. 0 means unlimited. Default is unlimited.

4.10.8.2. Statistics

This page allow user to browse all statistics that recorded by DHCP snooping function.

To view the Statistics menu, navigate to **Security > DHCP Snooping > Statistics** .

Statistics Table

<input type="checkbox"/>	Entry	Port	Forward	Chaddr Check Drop	Untrust Port Drop	Untrust Port with Option82 Drop	Invalid Drop
<input type="checkbox"/>	1	GE1	0	0	0	0	0
<input type="checkbox"/>	2	GE2	0	0	0	0	0
<input type="checkbox"/>	3	GE3	0	0	0	0	0
<input type="checkbox"/>	19	LAG7	0	0	0	0	0
<input type="checkbox"/>	20	LAG8	0	0	0	0	0


Figure 113 - Security > DHCP Snooping > Statistics

Item	Description
Port	Display port ID.
Forwarded	Display how many packets forwarded normally.
Chaddr Check Drop	Display how many packets dropped by chaddr validation.
Untrusted Port Drop	Display how many DHCP server packets that are received by untrusted port dropped.
Untrusted Port with Option82 Drop	Display how many packets dropped by untrusted port with option82 checking.
Invalid Drop	Display how many packets dropped by invalid checking.

4.10.8.3. Option82 Property

This page allow user to set string of DHCP option82 remote ID filed. The string will attach in option82 if option inserted.

To display Option82 Property page, click **Security > DHCP Snooping > Option82 Property**



☐ User Defined

Remote ID

Operational Status

Remote ID 00:e0:4c:00:00:00 (Switch Mac in Byte Order)

Apply

Port Setting Table

<input type="checkbox"/>	Entry	Port	State	Allow Untrust
<input type="checkbox"/>	1	GE1	Disabled	Drop
<input type="checkbox"/>	2	GE2	Disabled	Drop
<input type="checkbox"/>	3	GE3	Disabled	Drop
<input type="checkbox"/>	19	LAG7	Disabled	Drop
<input type="checkbox"/>	20	LAG8	Disabled	Drop

Edit

Figure 114- Security > DHCP Snooping > Option82 Property

Item	Description
User Defined	Set checkbox to enable user-defined remote-ID. By default, remote ID is switch mac in byte order.
Remote ID	Input user-defined remote ID. Only available when enable user-define remote ID.
Port Setting Table	
Port	Display port ID.
State	Display option82 enable/disable status of interface.
Allow untrusted	Display allow untrusted action of interface.

Click "Edit" button to view Edit Port Setting menu.




Figure 115 - Security > DHCP Snooping > Option82 Property > Edit Port Setting

Item	Description
Port	Display selected port to be edited
State	Set checkbox to enable/disable option82 function of interface.
Allow untrusted	<p>Select the action perform when untrusted port receive DHCP packet has option82 filed. Default is drop.</p> <ul style="list-style-type: none"> • Keep: Keep original option82 content. • Replace: Replace option82 content by switch setting • Drop: Drop packets with option82

4.10.8.4. Option82 Circuit ID

This page allow user to set string of DHCP option82 circuit ID filed. The string will attach in option82 if option inserted.

To display Option82 Circuit ID page, click **Security > DHCP Snooping > Option82 Circuit ID**

Option82 Circuit ID Table

Showing All entries Showing 0 to 0 of 0 entries

<input type="checkbox"/>	Port	VLAN	Circuit ID
0 results found.			

Figure 116 - Security > DHCP Snooping > Option82 Circuit ID

Item	Description
Port	Display port ID of entry.
VLAN	Display associate VLAN of entry.
Circuit ID	Display circuit ID string of entry.

Click “Add” button or "Edit" button to view the Add/Edit Option82 Circuit ID menu.

Add Option82 Circuit ID

Port

GE1

VLAN

(1 - 4094) (Keep empty to set without VLAN)

Circuit ID

Edit Option82 Circuit ID

Port

VLAN

Circuit ID

Figure 117 - Security > DHCP Snooping > Option82 Circuit ID
> Add/Edit Option82 Circuit ID

Item	Description
Port	Select port from list to associate to CID entry. Only available on Add dialog.
VLAN	Input VLAN ID to associate to circuit ID entry. VLAN ID is not mandatory. Only available on Add dialog.
Circuit ID	Input String as circuit ID. Packets match port and VLAN will be inserted circuit ID.

4.10.9. IP Source Guard

Use the IP Source Guard pages to configure settings of IP Source Guard.

4.10.9.1. Port Setting

Use the IP Source Guard pages to configure settings of IP Source Guard.

To display Port Setting page, click **Security > IP Source Guard > Port Setting**

Port Setting Table

<input type="checkbox"/>	Entry	Port	State	Verify Source	Current Entry	Max Entry
<input type="checkbox"/>	1	GE1	Disabled	IP	0	Unlimited
<input type="checkbox"/>	2	GE2	Disabled	IP	0	Unlimited
<input type="checkbox"/>	3	GE3	Disabled	IP	0	Unlimited
<input type="checkbox"/>	19	LAG7	Disabled	IP	0	Unlimited
<input type="checkbox"/>	20	LAG8	Disabled	IP	0	Unlimited

[Edit](#)

Figure 118 - Security > IP Source Guard > Port Setting

Item	Description
Port	Display port ID.
State	Display IP Source Guard enable/disable status of interface.
Verify Source	Display mode of IP Source Guard verification
Current Binding Entry	Display current binding entries of a interface.
Max Binding Entry	Display the number of maximum binding entry of interface.

Click "Edit" button to view the Edit Port Setting menu.



Figure 119 - Security > IP Source Guard > Port Setting > Edit Port Setting

Item	Description
Port	Display selected port to be edited.
Status	Set checkbox to enable or disable IP Source Guard function. Default is disabled.

Verify Source	Select the mode of IP Source Guard verification <ul style="list-style-type: none"> IP: Only verify source IP address of packet. IP-MAC: Verify source IP and source MAC address of packet.
Max Entry	Input the maximum number of entries that a port can be bounded. Default is un-limited on all ports. No entry will be bound if limitation reached.

4.10.9.2. IMPV Binding

This page allow user to add static IP source guard entry and browse all IP source guard entries that learned by DHCP snooping or statically create by user.

To display IPMV Binding page, click **Security > IP Source Guard > IMPV Binding**





Figure 120 - Security > IP Source Guard > IMPV Binding

Item	Description
Port	Display port ID of entry.
VLAN	Display VLAN ID of entry.

MAC Address	Display MAC address of entry. Only available of IP-MAC binding entry.
IP Address	Display IP address of entry. Mask always to be 255.255.255.255 for IP-MAC binding. IP binding entry display user input.
Binding	Display binding type of entry.
Type	Type of existing binding entry <ul style="list-style-type: none"> • Static: Entry added by user. • Dynamic: Entry learned by DHCP snooping.
Lease Time	Lease time of DHCP Snooping learned entry. After lease time entry will be deleted. Only available of dynamic entry.

Click "Add" or "Edit" button to view the Add/Edit IP-MAC-Port-VLAN Binding menu.



Add IP-MAC-Port-VLAN Binding

Port: GE1

VLAN: (1 - 4094)

Binding: ☒ IP-MAC-Port-VLAN ☐ IP-Port-VLAN

MAC Address:

IP Address: / 255.255.255.255

Apply Close

Edit IP-MAC-Port-VLAN Binding

Port: GE1

VLAN: 20

Binding: IP-MAC-Port-VLAN

MAC Address: 00:11:22:33:44:55

IP Address: 192.168.169.5 / 255.255.255.255

Apply Close

Figure 121 - Security > IP Source Guard > Add/Edit IP-MAC-Port-VLAN Binding

Item	Description
Port	Select port from list of a binding entry.
VLAN	Specify a VLAN ID of a binding entry.
Binding	Select matching mode of binding entry <ul style="list-style-type: none">• IP-MAC-Port-VLAN: packet must match IP address、MAC address、Port and VLAN ID.• IP-Port-VLAN: packet must match IP address or subnet、Port and VLAN ID.
MAC Address	Input MAC address. Only available on IP-MAC-Port-VLAN mode.
IP Address	Input IP address and mask. Mask only available on IP-MAC-Port mode.

4.10.9.3. Save Database

This page allow user to configure DHCP snooping database which can backup and restore dynamic DHCP snooping entries.

To display Save Database page, click **Security > DHCP Snooping > Save Database**.

Type	<input checked="" type="radio"/> None <input type="radio"/> Flash <input type="radio"/> TFTP	
Filename	<input type="text"/>	
Address Type	<input checked="" type="radio"/> Hostname <input type="radio"/> IPv4	
Server Address	<input type="text"/>	
Write Delay	<input type="text" value="300"/>	Sec (15 - 86400, default 300)
Timeout	<input type="text" value="300"/>	Sec (0 - 86400, default 300)

Figure 122 - Security > IP Source Guard > Save Database

Item	Description
Type	<p>Select the type of database agent.</p> <ul style="list-style-type: none"> None: Disable database agent service. Flash: Save DHCP dynamic binding entries to flash. TFTP: Save DHCP dynamic binding entries to remote TFTP server.
Filename	<p>Input filename for backup file. Only available when selecting type “flash” and “TFTP” .</p>
Address Type	<p>Select the type of TFTP server.</p> <ul style="list-style-type: none"> Hostname: TFTP server address is hostname. IPv4: TFTP server address is IPv4 address
Server Address	<p>Input remote TFTP server hostname or IP address. Only available when selecting type “TFTP”</p>
Write Delay	<p>Input delay timer for doing backup after change happened. Default is 300 seconds.</p>

Timeout	Input aborts timeout for doing backup failure. Default is 300 seconds.
---------	--

4.11. ACL

Use the ACL pages to configure settings for the switch ACL features.

4.11.1. MAC ACL

This page allow user to add or delete ACL rule. A rule cannot be deleted if under binding.

To display MAC ACL page, click **ACL > MAC ACL**




Figure 123 - ACL > MAC ACL

Item	Description
ACL Name	Input MAC ACL name.
ACL Name	Display MAC ACL name.
Rule	Display the number ACE rule of ACL.
Port	Display the port list that bind this ACL.

4.11.2. MAC ACE

This page allow user to add, edit or delete ACE rule. An ACE rule cannot be edited or deleted if ACL under binding. New ACE cannot be added if ACL under binding.

To display MAC ACE page, click **ACL > MAC ACE**

ACE Table

ACL Name

Showing entries Showing 1 to 1 of 1 entries

	Sequence	Action	Source MAC		Destination MAC		Ethertype	VLAN	802.1p	
			Address	Mask	Address	Mask			Value	Mask
<input type="checkbox"/>	546	Permit	Any	Any	Any	Any	Any	Any	Any	Any

Figure 124 - ACL > MAC ACE

Item	Description
ACL Name	Select the ACL name to which an ACE is being added.
Sequence	Display the sequence of ACE.
Action	Display the action of ACE.
Source MAC	Display the source MAC address and mask of ACE.
Destination MAC	Display the destination MAC address and mask of ACE.
Ethertype	Display the Ethernet frame type of ACE.
VLAN ID	Display the VLAN ID of ACE.
802.1p Value	Display the 802.1p value of ACE.
802.1p Mask	Display the 802.1p mask of ACE.

Click "Edit" button to view the Edit ACE menu.




Figure 125 - ACL > Edit ACE

Item	Description
ACL Name	Display the ACL name to which an ACE is being added..
Sequence	Specify the sequence of the ACE. ACEs with higher sequence are processed first (1 is the highest priority). Only available on Add Dialog.
Action	<p>Select the action after ACE match packet. •</p> <ul style="list-style-type: none"> ● Permit: Forward packets that meet the ACE criteria. ● Deny: Drop packets that meet the ACE criteria. ● Shutdown: Drop packets that meet the ACE criteria, and disable the port from where the packets were received. Such ports can be reactivated from the Port Settings page.
	Select the type for source MAC address. •

Source MAC	<ul style="list-style-type: none"> Any: All source addresses are acceptable. • User Defined: Only a source address or a range of source addresses which users define are acceptable. Enter the source MAC address and mask to which will be matched.
Destination MAC	<p>Select the type for Destination MAC address. •</p> <ul style="list-style-type: none"> Any: All destination addresses are acceptable. • User Defined: Only a destination address or a range of destination addresses which users define are acceptable. Enter the destination MAC address and mask to which will be matched.
Ethertype	<p>Select the type for Ethernet frame type. •</p> <ul style="list-style-type: none"> Any: All Ethernet frame type is acceptable. • User Defined: Only an Ethernet frame type which users define is acceptable. Enter the Ethernet frame type value to which will be matched.
VLAN	<p>Select the type for VLAN ID. •</p> <ul style="list-style-type: none"> Any: All VLAN ID is acceptable. • User Defined: Only a VLAN ID which users define is acceptable. Enter the VLAN ID to which will be matched.
802.1p	<p>Select the type for 802.1p value. •</p> <ul style="list-style-type: none"> Any: All 802.1p value is acceptable. • User Defined: Only an 802.1p value or a range of 802.1p value which users define is acceptable. Enter the 802.1p value and mask to which will be matched.

4.11.3. IPv4 ACL

This page allow user to add or delete IPv4 ACL rule. A rule cannot be deleted if under binding.

To display IPv4 ACL page, click **ACL > IPv4 ACL**




Figure 126 - ACL > IPv4 ACL

Item	Description
ACL Name	Input IPv4 ACL name.
ACL Name	Display IPv4 ACL name.
Rule	Display the number ACE rule of ACL.
Port	Display the port list that bind this ACL.

4.11.4. IPv4 ACE

This page allow user to add, edit or delete ACE rule. An ACE rule cannot be edited or deleted if ACL under binding. New ACE cannot be added if ACL under binding.

To display IPv4 ACE page, click **ACL > IPv4 ACE**

ACE Table

ACL Name None

Showing All entries Showing 0 to 0 of 0 entries

	Sequence	Action	Protocol	Source IP		Destination IP		Source Port	Destination Port	TCP Flags	Type of Service		ICMP	
				Address	Mask	Address	Mask				DSCP	IP Precedence	Type	Code
0 results found.														

First Previous **1** Next Last

Figure 127 - ACL > IPv4 ACE

Item	Description
ACL Name	Select the ACL name to which an ACE is being added.
Sequence	Display the sequence of ACE.
Action	Display the action of ACE.
Protocol	Display the protocol value of ACE.
Source IP	Display the source IP address and mask of ACE.
Destination IP	Display the destination IP address and mask of ACE.
Source Port	Display single source port or a range of source ports of ACE. Only available when protocol is TCP or UDP.
Destination Port	Display single destination port or a range of destination ports of ACE. Only available when protocol is TCP or UDP.
TCP Flags	Display the TCP flag value if ACE. Only available when protocol is TCP.
Type of Service	Display the ToS value of ACE which could be DSCP or IP Precedence.
ICMP	Display the ICMP type and code of ACE. Only available when protocol is ICMP.

Click "Add" or "Edit" button to view the Add/Edit ACE menu.

Add ACE

ACL Name: 35135

Sequence:

Action: ☒ Permit ☐ Deny ☐ Shutdown

Protocol: ☒ Any ☐ Select: ICMP ☐ Define:

Source IP: ☒ Any ☐

Destination IP: ☒ Any ☐

Type of Service: ☒ Any ☐ DSCP: ☐ IP Precedence:

Source Port: ☒ Any ☐ Single: ☐ Range:

Destination Port: ☒ Any ☐ Single: ☐ Range:

TCP Flags: Urg: ☐ Set ☐ Unset ☒ Don't care
 Ack: ☐ Set ☐ Unset ☒ Don't care
 Psh: ☐ Set ☐ Unset ☒ Don't care
 Rst: ☐ Set ☐ Unset ☒ Don't care
 Syn: ☐ Set ☐ Unset ☒ Don't care
 Fin: ☐ Set ☐ Unset ☒ Don't care

ICMP Type: ☒ Any ☐ Select: Echo Reply ☐ Define:

ICMP Code: ☒ Any ☐ Define:

Apply Close

Edit ACE

ACL Name: 35135

Sequence: 7587

Action: ☒ Permit ☐ Deny ☐ Shutdown

Protocol: ☒ Any ☐ Select: ICMP ☐ Define:

Source IP: ☒ Any ☐

Destination IP: ☒ Any ☐

Type of Service: ☒ Any ☐ DSCP: ☐ IP Precedence:

Source Port: ☒ Any ☐ Single: ☐ Range:

Destination Port: ☒ Any ☐ Single: ☐ Range:

TCP Flags: Urg: ☐ Set ☐ Unset ☒ Don't care
 Ack: ☐ Set ☐ Unset ☒ Don't care
 Psh: ☐ Set ☐ Unset ☒ Don't care
 Rst: ☐ Set ☐ Unset ☒ Don't care
 Syn: ☐ Set ☐ Unset ☒ Don't care
 Fin: ☐ Set ☐ Unset ☒ Don't care

ICMP Type: ☒ Any ☐ Select: Echo Reply ☐ Define:

ICMP Code: ☒ Any ☐ Define:

Apply Close

Figure 128 - ACL > Add/Edit ACE

Item	Description
ACL Name	Display the ACL name to which an ACE is being added.
Sequence	Specify the sequence of the ACE. ACEs with higher sequence are processed first (1 is the highest sequence). Only available on Add dialog.
	Select the action for a match. •

Action	<ul style="list-style-type: none"> • Permit: Forward packets that meet the ACE criteria. • Deny: Drop packets that meet the ACE criteria. • Shutdown: Drop packets that meet the ACE criteria, and disable the port from where the packets were received. Such ports can be reactivated from the Port Settings page.
Protocol	<p>Select the type of protocol for a match. •</p> <ul style="list-style-type: none"> • Any (IP): All IP protocols are acceptable. • • Select from list: Select one of the following protocols from the drop-down list. (ICMP/IPinIP/TCP/EGP/IGP/UDP/HMP/RDP/IPV6/IPV6:ROUT/IPV6:FRAG/ RSVP/IPV6:ICMP/OSPF/PIM/L2TP) • Protocol ID to match: Enter the protocol ID.
Source IP	<p>Select the type for source IP address. •</p> <ul style="list-style-type: none"> • Any: All source addresses are acceptable. • • User Defined: Only a source address or a range of source addresses which users define are acceptable. Enter the source IP address value and mask to which will be matched.
Destination IP	<p>Select the type for destination IP address. •</p> <ul style="list-style-type: none"> • Any: All destination addresses are acceptable. • • User Defined: Only a destination address or a range of destination addresses which users define are acceptable. Enter the destination IP address value and mask to which will be matched.
Source Port	<p>Select the type of protocol for a match. Only available when protocol is TCP or UDP. •</p> <ul style="list-style-type: none"> • Any: All source ports are acceptable. • • Single: Enter a single TCP/UDP source port to which


	<p>packets are matched. •</p> <ul style="list-style-type: none"> • Range: Select a range of TCP/UDP source ports to which the packet is matched. There are eight different port ranges that can be configured (shared between source and destination ports). TCP and UDP protocols each have eight port ranges.
Destination Port	<p>Select the type of protocol for a match. Only available when protocol is TCP or UDP. •</p> <ul style="list-style-type: none"> • Any: All source ports are acceptable. • • Single: Enter a single TCP/UDP source port to which packets are matched. • <p>Range: Select a range of TCP/UDP source ports to which the packet is matched. There are eight different port ranges that can be configured (shared between source and destination ports). TCP and UDP protocols each have eight port ranges.</p>
Destination Port	<p>Select the type of protocol for a match. Only available when protocol is TCP or UDP. •</p> <ul style="list-style-type: none"> • Any: All source ports are acceptable. • • Single: Enter a single TCP/UDP source port to which packets are matched. • • Range: Select a range of TCP/UDP source ports to which the packet is matched. There are eight different port ranges that can be configured (shared between source and destination ports). TCP and UDP protocols each have eight port ranges.
TCP Flags	<p>Select one or more TCP flags with which to filter packets. Filtered packets are either forwarded or dropped. Filtering packets by TCP flags increases packet control, which increases network security. Only available when protocol is TCP.</p>

Type of Service	<p>Select the type of service for a match. •</p> <ul style="list-style-type: none"> Any: All types of service are acceptable. • DSCP to match: Enter a Differentiated Services Code Point (DSCP) to match. • IP Precedence to match: Enter a IP Precedence to match.
ICMP Type	<p>Either select the message type by name or enter the message type number. Only available when protocol is ICMP. •</p> <ul style="list-style-type: none"> Any: All message types are acceptable. • Select from list: Select message type by name. Protocol ID to match: Enter the number of message type.
ICMP Code	<p>Select the type for ICMP code. Only available when protocol is ICMP. •</p> <ul style="list-style-type: none"> Any: All codes are acceptable. • User Defined: Enter an ICMP code to match.

4.11.5. ACL Binding

This page allow user to bind or unbind ACL rule to or from interface. IPv4 and Ipv6 ACL cannot be bound to the same port simultaneously.

To display ACL Binding page, click **ACL > ACL Binding**



ACL Binding Table

Entry	Port	MAC ACL	IPv4 ACL	IPv6 ACL
1	GE1			
2	GE2			
3	GE3			
19	LAG7			
20	LAG8			

Figure 129 - ACL > ACL Binding

Item	Description
Port	Display port entry ID.
MAC ACL	Display mac ACL name that bound of interface. Empty means no rule bound.
IPv4 ACL	Display ipv4 ACL name that bound of interface. Empty means no rule bound.
IPv6 ACL	Display ipv6 ACL name that bound of interface. Empty means no rule bound.

Click "Edit" button to view the Edit ACL Binding menu.



Figure 130 - ACL > Edit ACL Binding

Item	Description
Port	Display port entry ID.
MAC ACL	Select mac ACL name from list to bind.
IPv4 ACL	Select IPv4 ACL name from list to bind.
IPv6 ACL	Select IPv6 ACL name from list to bind.

4.12. QoS


Use the QoS pages to configure settings for the switch QoS interface.

4.12.1. General

Use the QoS general pages to configure settings for general purpose.

4.12.1.1. Property

To display Property web page, click **QoS > General > Property**



Entry	Port	CoS	Trust	Remarking		
				CoS	DSCP	IP Precedence
1	GE1	0	Enabled	Disabled	Disabled	Disabled
2	GE2	0	Enabled	Disabled	Disabled	Disabled
3	GE3	0	Enabled	Disabled	Disabled	Disabled
19	LAG7	0	Enabled	Disabled	Disabled	Disabled
20	LAG8	0	Enabled	Disabled	Disabled	Disabled

Figure 131 - QoS > General > Property

Item	Description
State	Set checkbox to enable/disable QoS.
Trust	Select QoS trust mode <ul style="list-style-type: none"> CoS: Traffic is mapped to queues based on the CoS field in the VLAN tag, or based on the per-port default CoS value

	<p>(if there is no VLAN tag on the incoming packet), the actual mapping of the CoS to queue can be configured on port setting dialog.</p> <ul style="list-style-type: none"> • CoS-DSCP: Uses the trust CoS mode for non-IP traffic and trust DSCP mode for IP traffic. • IP Precedence: Traffic is mapped to queues based on the IP precedence. The actual mapping of the IP precedence to queue can be configured on the IP Precedence mapping page.
Port Setting Table	
Port	Port name
CoS	Port default CoS priority value for the selected ports.
Trust	<p>Port trust state</p> <ul style="list-style-type: none"> • Enabled: Traffic will follow trust mode in global setting • Disabled: Traffic will always use best efforts
Remarking (CoS)	<p>Set checkbox to enable/disable port CoS remarking.</p> <ul style="list-style-type: none"> • Enabled: CoS remarking is enabled • Disabled: CoS remarking is disabled
Remarking (IP Precedence)	<p>Set checkbox to enable/disable port IP Precedence remarking.</p> <ul style="list-style-type: none"> • Enabled: DSCP remarking is enabled • Disabled: DSCP remarking is disabled

Click "Edit" button to view the Edit Port Setting menu.

Edit Port Setting

Port	LAG8
CoS	0 (0 - 7)
Trust	<input checked="" type="checkbox"/> Enable

Remarking

CoS	<input type="checkbox"/> Enable
DSCP	<input type="checkbox"/> Enable
IP Precedence	<input type="checkbox"/> Enable

Apply Close

Figure 132 - Qos > General > Property

Item	Description
Port	Selected port list.
CoS	Set default CoS/802.1p priority value for the selected ports.
Trust	Set checkbox to enable/disable port trust state.
Remarking (CoS)	Set checkbox to enable/disable port CoS remarking.
Remarking (IP Precedence)	Set checkbox to enable/disable port IP Precedence remarking.

4.12.1.2. Queue Scheduling

The switch supports eight queues for each interface. Queue number 8 is the highest priority queue.

Queue number 1 is the lowest priority queue. There are two ways of determining how traffic in queues is handled, Strict Priority (SP) and Weighted Round Robin (WRR).

- Strict Priority (SP)–Egress traffic from the highest priority queue is transmitted

first. Traffic from the lower queues is processed only after the highest queue has been transmitted, which provide the highest level of priority of traffic to the highest numbered queue.

- **Weighted Round Robin (WRR)**–In WRR mode the number of packets sent from the queue is proportional to the weight of the queue (the higher the weight, the more frames are sent).

The queuing modes can be selected on the Queue page. When the queuing mode is by Strict Priority, the priority sets the order in which queues are serviced, starting with queue_8 (the highest priority queue) and going to the next lower queue when each queue is completed.

When the queuing mode is Weighted Round Robin, queues are serviced until their quota has been used up and then another queue is serviced. It is also possible to assign some of the lower queues to WRR, while keeping some of the higher queues in Strict Priority. In this case traffic for the SP queues is always sent before traffic from the WRR queues. After the SP queues have been emptied, traffic from the WRR queues is forwarded. (The relative portion from each WRR queue depends on its weight).

To display Queue Scheduling web page, click **QoS > General > Queue Scheduling**

Queue	Method			
	Strict Priority	WRR	Weight	WRR Bandwidth (%)
1	<input checked="" type="radio"/>	<input type="radio"/>	1	
2	<input checked="" type="radio"/>	<input type="radio"/>	2	
3	<input checked="" type="radio"/>	<input type="radio"/>	3	
4	<input checked="" type="radio"/>	<input type="radio"/>	4	
5	<input checked="" type="radio"/>	<input type="radio"/>	5	
6	<input checked="" type="radio"/>	<input type="radio"/>	9	
7	<input checked="" type="radio"/>	<input type="radio"/>	13	
8	<input checked="" type="radio"/>	<input type="radio"/>	15	

Apply


Figure 133 - QoS > General > Queue Scheduling

Item	Description
Queue	Queue ID to configure.
Strict Priority	Set queue to strict priority type.
WRR	Set queue to Weight round robin type.
Weight	If the queue type is WRR, set the queue weight for the queue.
WRR Bandwidth	Percentage of WRR queue bandwidth.

4.12.1.3. CoS Mapping

The CoS to Queue table determines the egress queues of the incoming packets based on the 802.1p priority in their VLAN tags. For incoming untagged packets, the 802.1p priority will be the default CoS/802.1p priority assigned to the ingress ports. Use the Queues to CoS table to remark the CoS/802.1p priority for egress traffic from each queue.

To display CoS Mapping web page, click **QoS > General > CoS Mapping**



The screenshot shows the 'CoS Mapping' web page. It contains two main sections:

- CoS to Queue Mapping:** A table with 'CoS' (0-7) and 'Queue' (2-8) columns. Each cell contains a dropdown menu. Below the table is an 'Apply' button.
- Queue to CoS Mapping:** A table with 'Queue' (1-8) and 'CoS' (1-7) columns. Each cell contains a dropdown menu. Below the table is an 'Apply' button.

Figure 134 - QoS > General > Cos Mapping

Item	Description
CoS to Queue Mapping	
CoS	CoS value.
Queue	Select queue id for the CoS value.
Queue to CoS Mapping	
Queue	Queue ID
CoS	Select CoS value for the queue id.

4.12.1.5. IP Precedence Mapping

This page allow user to configure IP Precedence to Queue mapping and Queue to IP Precedence mapping.

To display IP Precedence Mapping web page, click **QoS > General > IP Precedence Mapping**

IP Precedence to Queue Mapping

IP Precedence	Queue
0	1
1	2
2	3
3	4
4	5
5	6
6	7
7	8

Queue to IP Precedence Mapping

Queue	IP Precedence
1	0
2	1
3	2
4	3
5	4
6	5
7	6
8	7

Figure 135 - QoS > General > IP Precedence Mapping

Item	Description
IP Precedence to Queue Mapping	
IP Precedence	IP Precedence value.
Queue	Queue value which IP Precedence is mapped.
Queue to IP Precedence Mapping	
Queue	Queue ID.
IP Precedence	IP Precedence value which queue is mapped.

4.12.2. Rate Limit

Use the Rate Limit pages to define values that determine how much traffic the switch can receive and send on specific port or queue.

4.12.2.1. Ingress/Egress Port

This page allow user to configure ingress port rate limit and egress port rate limit. The ingress rate limit is the number of bits per second that can be received from the ingress interface. Excess bandwidth above this limit is discarded.

To display Ingress / Egress Port web page, click **QoS > Rate Limit > Ingress / Egress Port**

Ingress / Egress Port Table

<input type="checkbox"/>	Entry	Port	Ingress		Egress	
			State	Rate (Kbps)	State	Rate (Kbps)
<input type="checkbox"/>	1	GE1	Disabled		Disabled	
<input type="checkbox"/>	2	GE2	Disabled		Disabled	
<input type="checkbox"/>	3	GE3	Disabled		Disabled	
<input type="checkbox"/>	10	GE10	Disabled		Disabled	
<input type="checkbox"/>	11	GE11	Disabled		Disabled	
<input type="checkbox"/>	12	GE12	Disabled		Disabled	

Edit

Figure 136 - QoS > Rate Limit > Ingress / Egress Port

Item	Description
Port	Port name.
Ingress (State)	Port ingress rate limit state <ul style="list-style-type: none"> Enabled: Ingress rate limit is enabled Disabled: Ingress rate limit is disabled
Ingress (Rate)	Port ingress rate limit value if ingress rate state is enabled.
IP Precedence	IP Precedence value which queue is mapped.
Egress (State)	Port egress rate limit state <ul style="list-style-type: none"> Enabled: Egress rate limit is enabled Disabled: Egress rate limit is disabled
Egress (Rate)	Port egress rate limit value if egress rate state is enabled.

Click "Edit" button to view the Ingress / Egress Port menu.




Figure 137 - QoS > Rate Limit > Ingress / Egress Port

Item	Description
Port	Select port list.
Ingress	Set checkbox to enable/disable ingress rate limit. If ingress rate limit is enabled, rate limit value need to be assigned.
Egress	Set checkbox to enable/disable egress rate limit. If egress rate limit is enabled, rate limit value need to be assigned.

4.13. Diagnostics

Use the Diagnostics pages to configure settings for the switch diagnostics feature or operating diagnostic utilities.

4.13.1. Logging

4.13.1.1. Property

To enable/disable the logging service, click **Diagnostic > Logging > Property**.

State	<input checked="" type="checkbox"/> Enable
Console Logging	
State	<input checked="" type="checkbox"/> Enable
Minimum Severity	Notice ▼ <small>Note: Emergency, Alert, Critical, Error, Warning, Notice</small>
RAM Logging	
State	<input checked="" type="checkbox"/> Enable
Minimum Severity	Notice ▼ <small>Note: Emergency, Alert, Critical, Error, Warning, Notice</small>
Flash Logging	
State	<input type="checkbox"/> Enable
Minimum Severity	Notice ▼ <small>Note: Emergency, Alert, Critical, Error, Warning, Notice</small>
<input type="button" value="Apply"/>	


Figure 138 - Diagnostics > Logging > Property

Item	Description
State	Enable/Disable the global logging services. When the logging service is enabled, logging configuration of each destination rule can be individually configured. If the logging service is disabled, no messages will be sent to these destinations.
Console Logging	
State	Enable/Disable the console logging service
Minimum Severity	The minimum severity for the console logging.
RAM Logging	
State	Enable/Disable the RAM logging service.
Minimum Severity	The minimum severity for the RAM logging.
Flash Logging	

State	Enable/Disable the flash logging service.
Minimum Severity	The minimum severity for the flash login.

4.13.1.2. Remote Server

To configure the remote logging server, click **Diagnostic > Logging > Remote Server**.



Remote Server Table

Search:

Entry	Server Address	Server Port	Facility	Minimum Severity
0 results found.				


Figure 139 - Diagnostics > Logging > Remote Server

Item	Description
Server Address	The IP address of the remote logging server.
Server Ports	The port number of the remote logging server.
Facility	The facility of the logging messages. It can be one of the following values: local0, local1, local2, local3, local4, local5, local6, and local7.
Severity	<p>The minimum severity.</p> <ul style="list-style-type: none"> • Emergence: System is not usable. • Alert: Immediate action is needed. • Critical: System is in the critical condition. • Error: System is in error condition • Warning: System warning has occurred

	<ul style="list-style-type: none"> • Notice: System is functioning properly, but a system notice has occurred. • Informational: Device information. • Debug: Provides detailed information about an event.

4.13.2. Mirroring

To display Port Mirroring web page, click **Diagnostics > Mirroring**



	Session ID	State	Monitor Port	Ingress Port	Egress Port
<input type="radio"/>	1	Disabled	---	---	---
<input type="radio"/>	2	Disabled	---	---	---
<input type="radio"/>	3	Disabled	---	---	---
<input type="radio"/>	4	Disabled	---	---	---

Edit

Figure 140 - Diagnostics > Mirroring

Item	Description
Session ID	Select mirror session ID.
State	Select mirror session state : port-base mirror or disable <ul style="list-style-type: none"> • Enabled: Enable port based mirror • Disabled: Disable mirror.
Monitor Port	Select mirror session monitor port, and select whether

	normal packet could be sent or received by monitor port.
Ingress port	Select mirror session source rx ports.
Egress port	Select mirror session source tx ports.

Click "Edit" button to view the Edit Mirroring menu.





Figure 141- Diagnostics > Mirroring > Edit Mirroring

Item	Description
Session ID	Selected mirror session ID.
State	Select mirror session state : port-base mirror or disable <ul style="list-style-type: none"> Enabled: Enable port based mirror Disabled: Disable mirror.
Monitor Port	Select mirror session monitor port, and select whether normal packet could be sent or received by monitor port.

Ingress port	Select mirror session source rx ports.
Egress port	Select mirror session source tx ports.

4.13.3. Ping

For the ping functionality, click **Diagnostic > Ping**



The screenshot displays the 'Ping' diagnostic tool interface. It includes a configuration section with 'Address Type' (radio buttons for Hostname, IPv4, IPv6), 'Server Address' (text input), and 'Count' (input field with '4' and a range 'Sec (1 - 65535)'). Below the configuration are 'Ping' and 'Stop' buttons. The 'Ping Result' section shows a table with 'Packet Status' (Status: N/A, Transmit Packet: 0, Receive Packet: 0, Packet Lost: 0%) and 'Round Trip Time' (Min: 0.0 ms, Max: 0.0 ms, Average: 0.0 ms).

Figure 142 - Diagnostics > Ping

Item	Description
Address Type	Specify the address type to “Hostname” or “IPv4” .
Server Address	Specify the Hostname/IPv4 address for the remote logging server.
Count	Specify the numbers of each ICMP ping request.

4.13.4. Traceroute

For trace route functionality, click **Diagnostic > Traceroute**.




Figure 143 - Diagnostics > Traceroute

Item	Description
Address Type	Specify the address type to “Hostname” or “IPv4” .
Server Address	Specify the Hostname/IPv4 address for the remote logging server.
Time to Live	Specify the max hops of hosts for traceroute.

4.14. Management


Use the Management pages to configure settings for the switch management features.

4.14.1. User Account

The default username/password is admin/admin. And default account is not able to be deleted.

Use this page to add additional users that are permitted to manage the switch or to change the passwords of existing users.

To display User Account web page, click **Management > User Account**



User Account

Showing All entries Showing 1 to 1 of 1 entries


<input type="checkbox"/>	Username	Privilege
<input type="checkbox"/>	admin	Admin

Add Edit Delete First Previous 1 Next Last

Figure 150 - Management > User Account

Item	Description
Username	User name of the account.
Privilege	<p>Select privilege level for new account.</p> <ul style="list-style-type: none"> Admin: Allow to change switch settings. Privilege value equals to 15. User: See switch settings only. Not allow to change it. Privilege level equals to 1.

Click "Add" or "Edit" button to view the Add/Edit User Account menu.



Edit User Account

Username: admin

Password:

Confirm Password:

Privilege: ☒ Admin ☐ User

Apply Close

Edit User Account

Username: admin

Password:

Confirm Password:

Privilege: ☒ Admin ☐ User

Apply Close

Figure 151 - Management > User Account > Add/Edit User Account

Item	Description
Username	User name of the account.
Password	Set password of the account.
Confirm Password	Set the same password of the account as in "Password" field.
Privilege	<p>Select privilege level for new account.</p> <ul style="list-style-type: none"> Admin: Allow to change switch settings. Privilege value equals to 15. User: See switch settings only. Not allow to change it. Privilege level equals to 1.

4.14.2. Firmware

4.14.2.1. Upgrade / Backup

This page allow user to upgrade or backup firmware image through HTTP or TFTP server.

To display firmware upgrade or backup web page, click **Management > Firmware > Upgrade/Backup**




Figure 152 - Management > Firmware > Upgrade/Backup

Item	Description
Action	Firmware operations <ul style="list-style-type: none"> • Upgrade: Upgrade firmware from remote host to DUT. • Backup: Backup firmware image from DUT to remote host.
Method	Firmware upgrade / backup method. <ul style="list-style-type: none"> • TFTP: Using TFTP to upgrade/backup firmware. • HTTP: Using WEB browser to upgrade/backup firmware.
Filename	Use browser to upgrade firmware, you should select firmware image file on your host PC.

To display firmware upgrade or backup web page, click **Management > Firmware > Upgrade/Backup**





Figure 153 - Management > Firmware > Upgrade/Backup

Item	Description
Action	Firmware operations <ul style="list-style-type: none"> Upgrade: Upgrade firmware from remote host to DUT Backup: Backup firmware image from DUT to remote host
Method	Firmware upgrade / backup method <ul style="list-style-type: none"> TFTP: Using TFTP to upgrade/backup firmware. HTTP: Using WEB browser to upgrade/backup firmware.
Address Type	Specify TFTP server address type <ul style="list-style-type: none"> Hostname: Use domain name as server address IPv4: Use IPv4 as server address IPv6: Use IPv6 as server address
Server Address	Specify TFTP server address.
Filename	Firmware image file name on remote TFTP server

To display firmware upgrade or backup web page, click **Management > Firmware > Upgrade/Backup**



Action	<input type="radio"/> Upgrade <input checked="" type="radio"/> Backup
Method	<input type="radio"/> TFTP <input checked="" type="radio"/> HTTP
Firmware	<input checked="" type="radio"/> Image0 <input type="radio"/> Image1

Apply

Figure 154 - Management > Firmware > Upgrade/Backup

Item	Description
Action	Firmware operations <ul style="list-style-type: none"> Upgrade: Upgrade firmware from remote host to DUT Backup: Backup firmware image from DUT to remote host
Method	Firmware upgrade / backup method <ul style="list-style-type: none"> TFTP: Using TFTP to upgrade/backup firmware. HTTP: Using WEB browser to upgrade/backup firmware.
Firmware	Firmware partition need to backup <ul style="list-style-type: none"> Image0: Firmware image in flash partition 0 Image1: Firmware image in flash partition 1

To view the Firmware Upgrade/Backup menu, navigate to **Management > Firmware > Upgrade/Backup**.

Action	<input type="radio"/> Upgrade <input checked="" type="radio"/> Backup
Method	<input checked="" type="radio"/> TFTP <input type="radio"/> HTTP
Firmware	<input checked="" type="radio"/> Image0 <input type="radio"/> Image1
Address Type	<input checked="" type="radio"/> Hostname <input type="radio"/> IPv4 <input type="radio"/> IPv6
Server Address	<input type="text"/>
Filename	<input type="text"/>

Apply

Figure 155 - Management > Firmware > Upgrade/Backup

Item	Description
Action	Firmware operations <ul style="list-style-type: none"> Upgrade: Upgrade firmware from remote host to DUT Backup: Backup firmware image from DUT to remote host
Method	Firmware upgrade / backup method <ul style="list-style-type: none"> TFTP: Using TFTP to upgrade/backup firmware. HTTP: Using WEB browser to upgrade/backup firmware.
Firmware	Firmware partition need to backup <ul style="list-style-type: none"> Image0: Firmware image in flash partition 0. Image1: Firmware image in flash partition 1.
Address Type	Specify TFTP server address type <ul style="list-style-type: none"> Hostname: Use domain name as server address. IPv4: Use IPv4 as server address. IPv6: Use IPv6 as server address.

Server Address	Specify TFTP server address.
Filename	File name saved on remote TFTP server.

4.14.2.2. Active Image

This page allow user to select firmware image on next booting and show firmware information on both flash partitions.

To display the Active Image web page, click **Management > Firmware > Active Image**.




Figure 156 - Management > Firmware > Active Image

Item	Description
Active Image	Select firmware image to use on next booting

Firmware	Firmware flash partition name.
Version	Firmware version.
Name	Firmware name.
Size	Firmware image size.
Created	Firmware image created date.

4.14.3. Configuration

4.14.3.1. Upgrade / Backup

This page allow user to upgrade or backup configuration file through HTTP or TFTP server.

To display firmware upgrade or backup web page, click **Management > Configuration > Upgrade/Backup**




Figure 157 - Management > Configuration > Upgrade/Backup

Item	Description
Action	Configuration operations <ul style="list-style-type: none">• Upgrade: Upgrade firmware from remote host to DUT• Backup: Backup firmware image from DUT to remote host
Method	Configuration upgrade / backup method <ul style="list-style-type: none">• TFTP: Using TFTP to upgrade/backup firmware• HTTP: Using WEB browser to upgrade/backup firmware
Configuration	Configuration types <ul style="list-style-type: none">• Running Configuration: Merge to current running configuration file• Startup Configuration: Replace startup configuration file• Backup Configuration: Replace backup configuration file
Filename	Use browser to upgrade configuration, you should select configuration file on your host PC.

To display firmware upgrade or backup web page, click **Management > Configuration > Upgrade/Backup**




Figure 158 - Management > Configuration > Upgrade/Backup

Item	Description
Action	<p>Configuration operations</p> <ul style="list-style-type: none"> Upgrade: Upgrade firmware from remote host to DUT Backup: Backup firmware image from DUT to remote host
Method	<p>Configuration upgrade / backup method</p> <ul style="list-style-type: none"> TFTP: Using TFTP to upgrade/backup firmware HTTP: Using WEB browser to upgrade/backup firmware
Configuration	<p>Configuration types</p> <ul style="list-style-type: none"> Running Configuration: Merge to current running configuration file Startup Configuration: Replace startup configuration file Backup Configuration: Replace backup configuration file
Address Type	<p>Specify TFTP server address type</p> <ul style="list-style-type: none"> Hostname: Use domain name as server address IPv4: Use IPv4 as server address IPv6: Use IPv6 as server address

Server Address	Specify TFTP server address
Filename	File name saved on remote TFTP server

To display firmware upgrade or backup web page, click **Management > Configuration > Upgrade/Backup**




Figure 159 - Management > Configuration > Upgrade/Backup

Item	Description
Action	Configuration operations <ul style="list-style-type: none"> Upgrade: Upgrade firmware from remote host to DUT Backup: Backup firmware image from DUT to remote host
Method	Configuration upgrade / backup method <ul style="list-style-type: none"> TFTP: Using TFTP to upgrade/backup firmware HTTP: Using WEB browser to upgrade/backup firmware

Configuration	<p>Configuration types</p> <ul style="list-style-type: none"> Running Configuration: Backup running configuration file. Startup Configuration: Backup start configuration file. Backup Configuration: Backup configuration file. RAM Log: Backup log file stored in RAM. Flash Log: Backup log files store in Flash.
---------------	---

To display firmware upgrade or backup web page, click **Management > Configuration > Upgrade/Backup**




Figure 160 - Management > Configuration > Upgrade/Backup

Item	Description
Action	<p>Configuration operations</p> <ul style="list-style-type: none"> Upgrade: Upgrade firmware from remote host to DUT

	<ul style="list-style-type: none"> • Backup: Backup firmware image from DUT to remote host
Method	Configuration upgrade / backup method <ul style="list-style-type: none"> • TFTP: Using TFTP to upgrade/backup firmware • HTTP: Using WEB browser to upgrade/backup firmware
Configuration	Configuration types <ul style="list-style-type: none"> • Running Configuration: Backup running configuration file. • Startup Configuration: Backup start configuration file. • Backup Configuration: Backup configuration file. • RAM Log: Backup log file stored in RAM. • Flash Log: Backup log files store in Flash.
Address Type	Specify TFTP server address type <ul style="list-style-type: none"> • Hostname: Use domain name as server address • IPv4: Use IPv4 as server address • IPv6: Use IPv6 as server address
Server Address	Specify TFTP server address.
Filename	File name saved on remote TFTP server.

4.14.3.2. Save Configuration

This page allow user to manage configuration file saved on DUT and click “Restore Factory Default” button to restore factory defaults.

To display the Save Configuration web page, click **Management > Configuration > Save Configuration**

Source File	<input checked="" type="radio"/> Running Configuration <input type="radio"/> Startup Configuration <input type="radio"/> Backup Configuration
Destination File	<input checked="" type="radio"/> Startup Configuration <input type="radio"/> Backup Configuration

Figure 161 - Management > Configuration > Save Configuration

Item	Description
Source File	Source file types <ul style="list-style-type: none"> Running Configuration: Copy running configuration file to destination. Startup Configuration: Copy startup configuration file to destination. Backup Configuration: Copy backup configuration file to destination
Destination File	Destination file <ul style="list-style-type: none"> Startup Configuration: Save file as startup configuration. Backup Configuration: Save file as backup configuration.

4.14.4. SNMP

4.14.4.1. View

To configure and display the SNMP view table, click **Management > SNMP > View**.

View Table

Showing **All** entries Showing 1 to 1 of 1 entries

<input type="checkbox"/>	View	OID Subtree	Type
<input type="checkbox"/>	all	.1	Included

Figure 162 - Management > SNMP > View

Item	Description
View	The SNMP view name. Its maximum length is 30 characters
OID Subtree	Specify the ASN.1 subtree object identifier (OID) to be included or excluded from the SNMP view
Type	Include or exclude the selected MIBs in the view

4.14.4.2. Group

To configure and display the SNMP group settings, click **Management > SNMP > Group**.

Group Table

Showing **All** entries Showing 1 to 2 of 2 entries

<input type="checkbox"/>	Group	Version	Security Level	View		
				Read	Write	Notify
<input type="checkbox"/>	d	SNMPv2	No Security	all		
<input type="checkbox"/>	uy	SNMPv3	No Security	all		

Configure [SNMP View](#) to associate a non-default view with a group.

Figure 163 - Management > SNMP > Group

Item	Description
Group	Specify SNMP group name, and the maximum length is 30 characters.
Version	Specify SNMP version <ul style="list-style-type: none"> • SNMPv1: SNMP Version 1. • SNMPv2: Community-based SNMP Version 2. • SNMPv3: User security model SNMP version 3.
Security Level	Specify SNMP security level <ul style="list-style-type: none"> • No Security : Specify that no packet authentication is performed. • Authentication: Specify that no packet authentication without encryption is performed. • Authentication and Privacy: Specify that no packet authentication with encryption is performed.
View	
Read	Group read view name.
Write	Group write view name.
Notify	The view name that sends only traps with contents that is included in SNMP view selected for notification.

Click "Add" or "Edit" button to view the Add/Edit Group menu.

Add Group

Group

Version

Security Level

View

☒ SNMPv1
☐ SNMPv2
☐ SNMPv3
☒ No Security
☐ Authentication
☐ Authentication and Privacy
☒ Read
all
☐ Write
all
☐ Notify
all

Apply Close

Edit Group

Group

Version

Security Level

View

1
☒ SNMPv1
☐ SNMPv2
☐ SNMPv3
☒ No Security
☐ Authentication
☐ Authentication and Privacy
☒ Read
all
☐ Write
all
☐ Notify
all

Apply Close

Figure 164 - Management > SNMP > Group > Add/Edit Group

Item	Description
Group	Specify SNMP group name, and the maximum length is 30 characters.
Version	Specify SNMP version <ul style="list-style-type: none"> SNMPv1: SNMP Version 1. SNMPv2: Community-based SNMP Version 2. SNMPv3: User security model SNMP version 3.

Security Level	Specify SNMP security level <ul style="list-style-type: none"> No Security : Specify that no packet authentication is performed. Authentication: Specify that no packet authentication without encryption is performed. Authentication and Privacy: Specify that no packet authentication with encryption is performed.
View	
Read	Select read view name if Read is checked.
Write	Select write view name, if Write is checked.
Notify	Select notify view name, if Notify is checked.

4.14.4.3. Community

To configure and display the SNMP community settings, click **Management > SNMP > Community**.





Figure 165 - Management > SNMP > Community

Item	Description
Community	The SNMP community name. Its maximum length is 20

	characters.
Group	Specify the SNMP group configured by the command snmp group to define the object available to the community.
View	Specify the SNMP view to define the object available to the community.
Access	SNMP access mode <ul style="list-style-type: none"> • Read-Only: Read only. • Read-Write: Read and write.

Click "Add" or "Edit" button to view the Add/Edit Community menu.



Add Community

Community:

Type: ☒ Basic ☐ Advanced

View:

Access: ☒ Read-Only ☐ Read-Write

Group:

Apply Close

Edit Community

Community: public

Type: ☒ Basic ☐ Advanced

View:

Access: ☐ Read-Only ☒ Read-Write

Group:


Apply Close

Figure 166 - Management > SNMP > Group > Add/Edit Community

Item	Description
Community	The SNMP community name. Its maximum length is 20 characters.
Type	SNMP Community mode <ul style="list-style-type: none"> Basic: SNMP community specifies view and access right. Advanced: SNMP community specifies group.
View	Specify the SNMP view to define the object available to the community.
Access	SNMP access mode <ul style="list-style-type: none"> Read-Only: Read only. Read-Write: Read and write.
Group	Specify the SNMP group configured by the command snmp group to define the object available to the community.

4.14.4.4. User

To configure and display the SNMP users, click **Management > SNMP > User**.



User Table

Showing entries Showing 0 to 0 of 0 entries

<input type="checkbox"/>	User	Group	Security Level	Authentication Method	Privacy Method
0 results found.					

First Previous 1 Next Last

Configure [SNMP Group](#) to associate an SNMPv3 group with an SNMPv3 user.

Figure 167 - Management > SNMP > User

Item	Description
User	Specify the SNMP user name on the host that connects to the SNMP agent. The max character is 30 characters. For the SNMP v1 or v2c, the user name must match the community name.
Group	Specify the SNMP group to which the SNMP user belongs.
Security Level	SNMP privilege mode <ul style="list-style-type: none"> • No Security : Specify that no packet authentication is performed. • Authentication: Specify that no packet authentication without encryption is performed. • Authentication and Privacy: Specify that no packet authentication with encryption is performed.
Authentication Method	Authentication Protocol which is available when Privilege Mode is Authentication or Authentication and Privacy. <ul style="list-style-type: none"> • None: No authentication required. • MD5: Specify the HMAC-MD5-96 authentication protocol. • SHA: Specify the HMAC-SHA-96 authentication protocol
Privacy Method	Encryption Protocol <ul style="list-style-type: none"> • None: No privacy required. • DES: DES algorithm

Click "Add" or "Edit" button to view Add/Edit User menu.

Add User

User

Group

Security Level

☒ No Security
☐ Authentication
☐ Authentication and Privacy

Authentication

Method

☒ None
☐ MD5
☐ SHA

Password

Privacy

Method

☒ None
☐ DES

Password

Edit User

User 2

Group

Security Level

☒ No Security
☐ Authentication
☐ Authentication and Privacy

Authentication

Method

☒ None
☐ MD5
☐ SHA

Password

Privacy

Method

☒ None
☐ DES

Password

Figure 168 - Management > SNMP > User > Add/Edit User

Item	Description
User	Specify the SNMP user name on the host that connects to the SNMP agent. The max character is 30 characters.
Group	Specify the SNMP group to which the SNMP user belongs.
Security Level	SNMP privilege mode <ul style="list-style-type: none"> No Security : Specify that no packet authentication is

	<p>performed.</p> <ul style="list-style-type: none"> • Authentication: Specify that no packet authentication without encryption is performed. • Authentication and Privacy: Specify that no packet authentication with encryption is performed.
Authentication	
Method	<p>Authentication Protocol which is available when Privilege Mode is Authentication or Authentication and Privacy.</p> <ul style="list-style-type: none"> • None: No authentication required. • MD5: Specify the HMAC-MD5-96 authentication protocol. • SHA: Specify the HMAC-SHA-96 authentication protocol.
Password	<p>The authentication password, The number of character range is 8 to 32 characters.</p>
Privacy	
Method	<p>Encryption Protocol</p> <ul style="list-style-type: none"> • None: No privacy required. • DES: DES algorithm
Password	<p>The privacy password, The number of character range is 8 to 64 characters.</p>

4.14.4.5. Engine ID

To configure and display SNMP local and remote engine ID, click **Management > SNMP > Engine ID**.





Figure 169 - Management > SNMP > Engine ID

Item	Description
Local Engine ID	
Engine ID	<p>If checked “User Defined” , the local engine ID is configure by user, else use the default Engine ID which is made up of MAC and Enterprise ID.</p> <p>The user defined engine ID is range 10 to 64 hexadecimal characters, and the hexadecimal number must be divided by 2.</p>
Remote Engine ID Table	
Table	
Server Address	Remote host.
Engine ID	Specify Remote SNMP engine ID. The engine ID is range10 to 64 hexadecimal characters, and the hexadecimal number must be divided by 2.

Click "Add" button to view Add Remote Engine ID menu.



Add Remote Engine ID

Address Type: ☒ Hostname ☐ IPv4 ☐ IPv6

Server Address:


Engine ID: (10 - 64 Hexadecimal Characters)

Apply Close

Figure 170 - Management > SNMP > Add Engine ID

Item	Description
Address Type	Remote host address type for Hostname/IPv4/IPv6.
Server Address	Remote host.
Engine ID	Specify Remote SNMP engine ID. The engine ID is range 10 to 64 hexadecimal characters, and the hexadecimal number must be divided by 2.

Click "Edit" button to view Edit Remote Engine ID menu.



Edit Remote Engine ID

Server Address: 224.0.0.1

Engine ID: 1351faf1feef (10 - 64 Hexadecimal Characters)


Apply Close

Figure 171 - Management > SNMP > Edit Engine ID

Item	Description
Server Address	Edit Remote host address
Engine ID	Specify Remote SNMP engine ID. The engine ID is range 10 to 64 hexadecimal characters, and the hexadecimal number must be divided by 2.

4.14.4.6. Trap Event

To configure and display SNMP trap event, click **Management > SNMP > Trap Event**.



Authentication Failure	<input checked="" type="checkbox"/> Enable
Link Up / Down	<input checked="" type="checkbox"/> Enable
Cold Start	<input checked="" type="checkbox"/> Enable
Warm Start	<input checked="" type="checkbox"/> Enable

Apply

Figure 172 - Management > SNMP > Trap Event

Item	Description
Authentication Failure	SNMP authentication failure trap, when community not match or user authentication password not match.
Link Up/Down	Port link up or down trap.
Cold Start	Device reboot configure by user trap.
Warm Start	Device reboot by power down trap.

4.14.4.7. Notification

To configure the hosts to receive SNMPv1/v2/v3 notification, click **Management**

> SNMP > Notification.

Notification Table

Showing entries Showing 1 to 2 of 2 entries

<input type="checkbox"/>	Server Address	Server Port	Timeout	Retry	Version	Type	Community / User	Security Level
<input type="checkbox"/>	224.0.0.1	162			SNMPv1	Trap	public	No Security
<input type="checkbox"/>	224.0.0.1	162			SNMPv2	Trap	public	No Security

For SNMPv1,2 Notification, [SNMP Community](#) needs to be defined.
For SNMPv3 Notification, [SNMP User](#) must be created.

Figure 173 - Management > SNMP > Notification

Item	Description
Server Address	IP address or the hostname of the SNMP trap recipients.
Server Port	Recipients server UDP port number.
Timeout	Specify the SNMP informs timeout.
Retry	Specify the retry counter of the SNMP informs.
Version	Specify SNMP notification version <ul style="list-style-type: none"> SNMPv1: SNMP Version 1 notification. SNMPv2: SNMP Version 2 notification. SNMPv3: SNMP Version 3 notification.
Type	Notification Type <ul style="list-style-type: none"> Trap: Send SNMP traps to the host. Inform: Send SNMP informs to the host.
Community/User	SNMP community/user name for notification. If version is SNMPv3 the name is user name, else is community name.

UDP Port	Specify the UDP port number.
Timeout	Specify the SNMP informs timeout.
Security Level	SNMP trap packet security level <ul style="list-style-type: none"> • No Security: Specify that no packet authentication is performed. • Authentication: Specify that no packet authentication without encryption is performed. • Authentication and Privacy: Specify that no packet authentication with encryption is performed.

Click "Add" button to view the Notification menu.




Figure 174 - Management > SNMP > Notification > Add Notification

Item	Description
Address Type	Notify recipients host address type.

Server Address	IP address or the hostname of the SNMP trap recipients.
Version	Specify SNMP notification version <ul style="list-style-type: none"> • SNMPv1: SNMP Version 1 notification. • SNMPv2: SNMP Version 2 notification. • SNMPv3: SNMP Version 3 notification.
Type	Notification Type <ul style="list-style-type: none"> • Trap: Send SNMP traps to the host. • Inform: Send SNMP informs to the host.(version 1 have no inform)
Community/User	SNMP community/user name for notification. If version is SNMPv3 the name is user name, else is community name.
Security Level	SNMP notification packet security level, the security level must less than or equal to the community/user name <ul style="list-style-type: none"> • No Security: Specify that no packet authentication is performed. • Authentication: Specify that no packet authentication without encryption is performed. • Authentication and Privacy: Specify that no packet authentication with encryption is performed.
Server Port	Recipients server UDP port number, if “use default” checked the value is 162, else user configure.
Timeout	Specify the SNMP informs timeout, if “use default” checked the value is 15, else user configure.
Retry	Specify the SNMP informs retry count, if “use default” checked the value is 3, else user configure.

Click "Edit" button to view the Edit Notification menu.




Figure 175 - Management > SNMP > Notification > Edit Notification

Item	Description
Server Address	Edit SNMP notify recipients address
Version	Specify SNMP notification version <ul style="list-style-type: none"> • SNMPv1: SNMP Version 1 notification. • SNMPv2: SNMP Version 2 notification. • SNMPv3: SNMP Version 3 notification.
Type	Notification Type <ul style="list-style-type: none"> • Trap: Send SNMP traps to the host. • Inform: Send SNMP informs to the host.(version 1 have no inform)
Community/User	SNMP community/user name for notification. If version is SNMPv3 the name is user name, else is community name.
Community Level	SNMP notification packet security level, the security level must less than or equal to the community/user name <ul style="list-style-type: none"> • No Security: Specify that no packet authentication is performed.

	<ul style="list-style-type: none"> • Authentication: Specify that no packet authentication without encryption is performed. • Authentication and Privacy: Specify that no packet authentication with encryption is performed.
Server Port	Recipients server UDP port number, if “use default” checked the value is 162, else user configure.
Timeout	Specify the SNMP informs timeout, if “use default” checked the value is 15, else user configure.
Retry	Specify the SNMP informs retry count, if “use default” checked the value is 3, else user configure.

4.14.5. RMON

4.14.5.1. Statistics

To display RMON Statistics, click **Management > RMON > Statistics**.

Statistics Table

Refresh Rate sec

Entry	Port	Bytes Received	Drop Events	Packets Received	Broadcast Packets	Multicast Packets	CRC & Align Errors	Undersize Packets	Oversize Packets	Fragments	Jabbers	Collisions	Frames of 64 Bytes	Frames of 65 to 127 Bytes	Frames of 128 to 255 Bytes	Frames of 256 to 511 Bytes	Frames of 512 to 1023 Bytes	Frames Greater than 1024 Bytes
<input type="checkbox"/>	1 GE1	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
<input type="checkbox"/>	2 GE2	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
<input type="checkbox"/>	3 GE3	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
<input type="checkbox"/>	19 LAG7	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
<input type="checkbox"/>	20 LAG8	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0

Clear Refresh View

Figure 215 - Management > RMON > Statistics

Item	Description
Port	The port for the RMON statistics.
Bytes Received	Number of octets received, including bad packets and FCS octets, but excluding framing bits.

Drop Events	Number of packets that were dropped.
Packets Received	Number of packets received, including bad packets, Multicast packets, and Broadcast packets.
Broadcast Packets	Number of good Broadcast packets received. This number does not include Multicast packets.
Multicast Packets	Number of good Multicast packets received.
CRC & Align Errors	Number of CRC and Align errors that have occurred.
Undersize Packets	Number of undersized packets (less than 64 octets) received.
Oversize Packets	Number of oversized packets (over 1518 octets) received.
Fragments	Number of fragments (packets with less than 64 octets, excluding framing bits, but including FCS octets) received.
Jabbers	<p>Number of received packets that were longer than 1632 octets. This number excludes frame bits, but includes FCS octets that had either a bad FCS (Frame Check Sequence) with an integral number of octets (FCS Error) or a bad FCS with a non-integral octet (Alignment Error) number. A Jabber packet is defined as an Ethernet frame that satisfies the following criteria: •</p> <ul style="list-style-type: none"> • Packet data length is greater than MRU. • Packet has an invalid CRC. • RX error event has not been detected.
Collisions	Number of collisions received. If Jumbo Frames are enabled, the threshold of Jabber Frames is raised to the maximum size of Jumbo Frames.
Frames of 64 Bytes	Number of frames, containing 64 bytes that were received.
Frames of 65 to	Number of frames, containing 65 to 127 bytes that were

127 Bytes	received.
Frames of 128 to 225 Bytes	Number of frames, containing 128 to 255 bytes that were received.
Frames of 256 to 511 Bytes	Number of frames, containing 256 to 511 bytes that were received.
Frames of 512 to 1023 Bytes	Number of frames, containing 512 to 1023 bytes that were received.
Frames Greater than 1024 Bytes	Number of frames, containing 1024 to 1518 bytes that were received.
Clear	Clear the statistics for the selected ports.
View	View the statistics on the specified port.

Click "View" button to view the view Port Statistics menu.

View Port Statistics

Port	LAG7
Refresh Rate	<input checked="" type="radio"/> None <input type="radio"/> 5 sec <input type="radio"/> 10 sec <input type="radio"/> 30 sec
Received Bytes (Octets)	0
Drop Events	0
Received Packets	0
Broadcast Packets Received	0
Multicast Packets Received	0
CRC & Align Errors	0
Undersize Packets	0
Oversize Packets	0
Fragments	0
Jabbers	0
Collisions	0
Frames of 64 Bytes	0
Frames of 65 to 127 Bytes	0
Frames of 128 to 255 Bytes	0
Frames of 256 to 511 Bytes	0
Frames Greater than 1024 Bytes	0

Figure 216 - Management > RMON > Statistics

4.14.5.2. History

For the RMON history, click **Management > RMON > History**.

History Table

Showing entries
 Showing 0 to 0 of 0 entries


<input type="checkbox"/>	Entry	Port	Interval	Owner	Sample	
					Maximum	Current
0 results found.						

Figure 217 - Management > RMON > History

Item	Description
------	-------------

Port	The port for the RMON history.
Interval	The number of seconds for each sample.
Owner	The owner name of event (0~31 characters).
Sample Maximum	The maximum number of buckets.
Sample Current	The current number of buckets.
Add	Add the new RMON history entries
Edit	Edit the RMON history
Delete	Delete the RMON histories
View	View the history log.

Click "Add/Edit" button to Add/Edit the History menu.



Add History

Entry	1
Port	GE1
Max Sample	50 (1 - 50, default 50)
Interval	1800 (1 - 3600, default 1800)
Owner	

Apply Close

Edit History

Entry	undefined
Port	GE1
Max Sample	0 (1 - 50, default 50)
Interval	0 (1 - 3600, default 1800)
Owner	

Apply Close

Figure 218 - Management > RMON > Add /Edit History

Item	Description
Port	Specify port for the RMON history.
Max Sample	Specify the maximum number of buckets.
Interval	Specify the number of seconds for each sample.
Owner	Specify the owner name of event (0~31 characters).

Click "View" button to view the History menu.




Figure 219 - Management > RMON > View History

Item	Description
Port	The port for the RMON statistics.
Bytes Received	Number of octets received, including bad packets and FCS. octets, but excluding framing bits
Drop Events	Number of packets that were dropped.
Packets Received	Number of packets received, including bad packets, Multicast packets, and Broadcast packets.
Broadcast Packets	Number of good Broadcast packets received. This number does not include Multicast packets.
Multicast Packets	Number of good Multicast packets received.
CRC & Align Errors	Number of CRC and Align errors that have occurred.
Undersize	Number of undersized packets (less than 64 octets)

Packages	received.
Oversize Packages	Number of oversized packets (over 1518 octets) received.
Fragments	Number of fragments (packets with less than 64 octets, excluding framing bits, but including FCS octets) received.
Jabbers	<p>Number of received packets that were longer than 1632 octets. This number excludes frame bits, but includes FCS octets that had either a bad FCS (Frame Check Sequence) with an integral number of octets (FCS Error) or a bad FCS with a non-integral octet (Alignment Error) number. A Jabber packet is defined as an Ethernet frame that satisfies the following criteria: <input type="checkbox"/></p> <ul style="list-style-type: none"> • Packet data length is greater than MRU. • Packet has an invalid CRC. • RX error event has not been detected.
Collision	Number of collisions received. If Jumbo Frames are enabled, the threshold of Jabber Frames is raised to the maximum. size of Jumbo Frames.
Utilization	Percentage of current interface traffic compared to the maximum traffic that the interface can handle.

4.14.5.3. Event

For the RMON event, click **Management > RMON > Event**.





Figure 220 - Management > RMON > Event

Item	Description
Community	The SNMP community when the notification type is specified as trap
Description	The description for the event
Notification	<p>The notification type for the event, and the possible value are:</p> <ul style="list-style-type: none"> • None: Nothing for notification. • Event Log: Logging the event in the RMON Event Log table. • Trap: Send a SNMP trap. • Event Log and Trap: Logging the event and send the SNMP trap.
Time	The time that the event was triggered.
Owner	The owner for the event.


Click "Add/Edit" button to view the Add/Edit Event menu.



The image shows a screenshot of the "Add Event" dialog box. The dialog has a title bar "Add Event" and a dashed border. Inside, there is a table-like structure with the following fields:

Entry	1
Notification	<input checked="" type="radio"/> None <input type="radio"/> Event Log <input type="radio"/> Trap <input type="radio"/> Event Log and Trap
Community	Default Community
Description	Default Description
Owner	

At the bottom of the dialog, there are two buttons: "Apply" and "Close".



Edit Event	
Entry	undefined
Notification	<input checked="" type="radio"/> None <input type="radio"/> Event Log <input type="radio"/> Trap <input type="radio"/> Event Log and Trap
Community	<input type="text"/>
Description	<input type="text"/>
Owner	<input type="text"/>
<input type="button" value="Apply"/> <input type="button" value="Close"/>	

Figure 221 - Management > RMON > Add/Edit Event

Item	Description
Notification	<p>Specify the notification type for the event, and the possible value are: •</p> <ul style="list-style-type: none"> • None: Nothing for notification. • • Event Log: Logging the event in the RMON Event Log table • Trap: Send a SNMP trap. • • Event Log and Trap: Logging the event and send the SNMP trap
Community	Specify the SNMP community when the notification type is specified as “Trap” pr “Event Log and Trap”
Description	Specify the description for the event.
Owner	Specify owner for the event.

Click "View" button to view the View Event Log menu.

View Event Log

Entry:1

Showing **All** entries Showing 0 to 0 of 0 entries

Log ID	Time	Description
0 results found.		

1

Figure 222 - Management > RMON > View Event Log

Item	Description
Log ID	The log identifier.
Time	The time that the event was triggered.
Description	The description for the event.

4.14.5.4. Alarm

For the RMON Alarm menu, click **Management > RMON > Alarm**.

Alarm Table

Showing **All** entries Showing 0 to 0 of 0 entries

	Entry	Port	Counter		Sampling	Interval	Owner	Trigger	Rising		Falling		
			Name	Value					Threshold	Event	Threshold	Event	
0 results found.													

1

Figure 223 - Management > RMON > Alarm

Item	Description
Port	The port configuration for the RMON alarm.
Counter	The counter for sampling • <ul style="list-style-type: none"> DropEvents (Drop Event): Total number of events

	<p>received in which the packets were dropped. •</p> <ul style="list-style-type: none"> • Octets (Received Bytes): Octets. • • Pkts (Received Packets): Number of packets.
	<ul style="list-style-type: none"> • BroadcastPkts (Broadcast Packets Received): Broadcast packets. • • MulticastPkts (Multicast Packets Received): Multicast packets. • • CRCAlignError (CRC and Align Error): CRC alignment error. • • UndersizePkts (Undersize Packets): Number of undersized packets. • • OversizePkts (Oversize Packets): Number of oversized packets. • • Fragments (Fragments): Total number of packet fragment. • • Jabbers (Jabbers): Total number of packet jabber. • Collisions (Collisions): Collision. • • Pkts64Octetes (Frames of 64 Bytes): Number of packets size 64 octets. • • Pkts65to127Octetes (Frames of 65 to 127 Bytes): Number of packets size 65 to 127 octets. • Pkts128to255Octetes (Frames of 128 to 255 Bytes): Number of packets size 128 to 255 octets. • Pkts256to511Octetes (Frames of 256 to 511 Bytes): Number of packets size 256 to 511 octets. • Pkts512to1023Octetes (Frames of 512 to 1023 Bytes):

	<p>Number of packets size 512 to 1023 octets.</p> <ul style="list-style-type: none"> • Pkts1024to1518Octets (Frames Greater than 1024 Bytes): Number of packets size 1024 to 1518 octets.
Sampling	<p>The sampling type including: •</p> <ul style="list-style-type: none"> • Absolute: The selected variable value is compared directly with the thresholds at the end of the sampling interval. • • Delta: The selected variable value of the last sample is subtracted from the current value and the difference is compared with the thresholds.
Interval	The number of seconds for each sample.
Owner	The owner for the alarm entry.
Trigger	The type of event triggering.
Rising Threshold	The threshold for firing rising event.
Rising Event	The rising event when alarm was fired.
Falling Threshold	The threshold for firing falling event.
Falling Event	The falling event when alarm was fired.

Click "Add/Edit" button to view the Add/Edit menu.

Add Alarm

Entry: 1

Port: GE1

Counter: Drop Events

Sampling: ☒ Absolute ☐ Delta

Interval: 100 Sec (1 - 2147483647, default 100)

Owner:

Trigger: ☒ Rising ☐ Falling ☐ Rising and Falling

Rising

Threshold: 100 (0 - 2147483647, default 100)

Event: 1 - Default Description

Falling

Threshold: 20 (0 - 2147483647, default 20)

Event: 1 - Default Description

Apply Close

Edit Alarm

Entry: undefined

Port: GE1

Counter: Drop Events

Sampling: ☐ Absolute ☒ Delta

Interval: 0 Sec (1 - 2147483647, default 100)

Owner:

Trigger: ☒ Rising ☐ Falling ☐ Rising and Falling

Rising

Threshold: 0 (0 - 2147483647, default 100)

Event: 1 - Default Description

Falling

Threshold: 0 (0 - 2147483647, default 20)

Event: 1 - Default Description

Apply Close

Figure 224 - Management > RMON > Add/Edit Alarm

Item	Description
Port	Specify the port for sampling
Counter	<p>Specify the counter for sampling .</p> <ul style="list-style-type: none"> Drop Event: Total number of events received in which the packets were dropped. . Received Bytes (Octets): Octets. Received Packets: Number of packets. Broadcast Packets Received: Broadcast packets. Multicast Packets Received: Multicast packets. CRC and Align Error: CRC alignment error. . Undersize Packets: Number of undersized packets.
	<ul style="list-style-type: none"> Oversize Packets: Number of oversized packets. Fragments: Total number of packet fragment.

	<ul style="list-style-type: none"> • Jabbers: Total number of packet jabber. • • Collisions: Collision. • • Frames of 64 Bytes: Number of packets size 64 octets. • Frames of 65 to 127 Bytes: Number of packets size 65 to 127 octets. • • Frames of 128 to 255 Bytes: Number of packets size 128 to 255 octets. • • Frames of 256 to 511 Bytes: Number of packets size 256 to 511 octets. • • Frames of 512 to 1023 Bytes: Number of packets size 512 to 1023 octets. • • Frames Greater than 1024 Bytes: Number of packets size 1024 to 1518 octets.
Sampling	<p>Specify the sampling type. •</p> <ul style="list-style-type: none"> • Absolute: The selected variable value is compared directly with the thresholds at the end of the sampling interval. • • Delta: The selected variable value of the last sample is subtracted from the current value and the difference is compared with the thresholds.
Interval	Specify the sampling interval.
Owner	Specify the owner for the sampling.
Trigger	Specify the type for the alarm trigger.
RISING	
Threshold	Specify the threshold for firing rising event.
Event	Specify the index of rising event when alarm was fired.

Falling	
Threshold	Specify the threshold for firing falling event.
Event	Specify the index of falling event when alarm was fired.



Limited Lifetime Warranty

This Product is covered under DIGICARE Limited Lifetime Warranty program backed by DIGICARE Service Center. To avail this Limited Lifetime Warranty offer, customer needs to contact DIGICARE's Technical Assistance Center for the same. You may be asked to provide proof of purchase of product for warranty claim of defective product. Please refer website www.digisol.com for the detailed support terms & conditions and support process.

Warranty Policy

1. **Hardware Warranty :** Hardware warranty period shall be limited up to Three years. External Power Adapter shall carry One year warranty only against manufacturing defects. Any repair or replacement will be rendered by DIGICARE at its Service Center only.
2. **Software Warranty :** DIGISOL issues this Limited Software Warranty that the software portion of the product ("Software") will substantially confirm to DIGISOL's then current functional specifications for the software, as set forth in the applicable documentation, from the date of original retail purchase of the Software for a period of one year ("Software Warranty period"), provided that the Software is properly installed on approved hardware and operated as contemplated in its documentation.
3. **Governing Law:** This warranty shall be governed by Indian Laws.
4. **Limited Lifetime Warranty** shall subject to the terms & conditions specified in the DIGISOL PRODUCT WARRANTY policy displayed on www.digisol.com



📧 helpdesk@digisol.com
☎ 1800 209 3444

