



## Basic Configuration Commands

As our products undergo continuous development the specifications are subject to change without prior notice.

# Table of Contents

Chapter 1 System Management Commands.....	1
1.1 File Management Configuration Commands.....	1
1.1.1 copy.....	1
1.1.2 delete.....	2
1.1.3 dir.....	3
1.1.4 ip address.....	4
1.1.5 ip default-gateway.....	4
1.1.6 show configuration.....	5
1.1.7 format.....	6
1.1.8 more.....	6
1.2 Basic System Management Commands.....	7
1.2.1 boot flash.....	8
1.2.2 cd.....	9
1.2.3 chinese.....	9
1.2.4 date.....	10
1.2.5 english.....	11
1.2.6 md.....	12
1.2.7 pwd.....	12
1.2.8 rd.....	13
1.2.9 rename.....	14
1.2.10 reboot.....	14
1.2.11 alias.....	15
1.2.12 boot system flash.....	16
1.2.13 help.....	17
1.2.14 history.....	18
1.2.15 show.....	19
1.2.16 show alias.....	21
1.2.17 show break.....	22
Chapter 2 Terminal Service Configuration Commands.....	23
2.1 Telnet Configuration Commands.....	23

---

2.1.1 telnet .....	23
2.1.2 ip telnet.....	26
2.1.3 ctrl-shift-6+x (the current connection is mounted).....	28
2.1.4 where .....	29
2.1.5 resume .....	30
2.1.6 disconnect.....	31
2.1.7 clear telnet.....	33
2.1.8 show telnet.....	34
2.1.9 debug telnet.....	35
2.2 Terminal Configuration Commands .....	35
2.2.1 attach-port .....	36
2.2.2 autocommand .....	37
2.2.3 clear line .....	38
2.2.4 connect.....	38
2.2.5 disconnect .....	39
2.2.6 exec-timeout.....	39
2.2.7 length .....	40
2.2.8 line .....	40
2.2.9 location .....	41
2.2.10 login authentication.....	42
2.2.11 monitor .....	42
2.2.12 no debug all.....	43
2.2.13 password.....	43
2.2.14 resume.....	44
2.2.15 show debug.....	45
2.2.16 show line .....	45
2.2.17 terminal length.....	46
2.2.18 terminal monitor .....	47
2.2.19 terminal width.....	48
2.2.20 terminal-type .....	49
2.2.21 where.....	49
2.2.22 width .....	50
Chapter 3 Maintenance and Debugging Tool Commands .....	51
3.1 Network Testing Tool Commands.....	51

---

3.1.1 ping.....	51
3.1.2 traceroute .....	54
3.2 Fault Diagnosis Commands.....	56
3.2.1 logging.....	57
3.2.2 logging buffered.....	58
3.2.3 logging console.....	59
3.2.4 logging facility .....	61
3.2.5 logging monitor .....	62
3.2.6 logging on.....	64
3.2.7 logging trap .....	66
3.2.8 logging command .....	67
3.2.9 logging source-interface .....	68
3.2.10 logging history alerts .....	68
3.2.11 logging history critical.....	69
3.2.12 logging history debugging.....	70
3.2.13 logging history emergencies .....	70
3.2.14 logging history errors.....	71
3.2.15 logging history informational .....	71
3.2.16 logging history notifications.....	72
3.2.17 logging history warnings.....	73
3.2.18 logging history rate-limit .....	73
3.2.19 logging history size .....	74
3.2.20 service timestamps .....	75
3.2.21 clear logging.....	76
3.2.22 show break .....	76
3.2.23 show debug.....	78
3.2.24 show logging .....	79
Chapter 4 SSH Configuration Commands.....	81
4.1.1 ip sshd enable.....	81
4.1.2 ip sshd timeout.....	81
4.1.3 ip sshd auth-method .....	82
4.1.4 ip sshd access-class.....	83
4.1.5 ip sshd auth-retries.....	84
4.1.6 ip sshd clear .....	85

4.1.7 ip sshd silence-period.....	85
4.1.8 ip sshd sftp.....	86
4.1.9 ip sshd save.....	87
4.1.10 ip sshd disable-aes.....	88
4.1.11 ssh.....	89
4.1.12 show ssh .....	90
4.1.13 show ip sshd .....	90

## Chapter 1 System Management Commands

### 1.1 File Management Configuration Commands

The file management configuration commands include:

- copy
- delete
- dir
- ip address
- ip route
- show configuration
- format
- more

#### 1.1.1 copy

##### Syntax

To read a file from the tftp server to a switch, use the **copy** command.

**copy tftp<:filename> {flash<:filename>|rom} [ip\_addr]**

##### Parameter

Parameter	Description
p<:filename>	Read a file from the tftp server. Filename indicates the relevant filename. If not specified the filename, the system will prompt user to input the filename after executing the copy command.
sh <:filename>	Write a file to the flash memory of the switch. Filename indicates the relevant filename. If not specified the filename, the system will prompt user to input the filename after executing the copy command.
n	Updates bootrom for the switch.
addr	Specifies the IP address of tftp server. If not specified, the system will prompt user to input the IP address after executing the

	copy command.
--	---------------

**Default**

None

**Command Mode**

Monitor mode

**Usage Guidelines**

None

**Example**

```
monitor#copy tftp:switch.bin flash:switch.bin 192.2.2.1
```

The example shows how to read the switch.bin from the tftp server to the flash memory of the switch:

**Related Command**

None

**1.1.2 delete****Syntax**

To delete a file, use the **delete** command.

```
delete file-name
```

**Parameter**

Parameter	Description
<i>-name</i>	ecifies the filename (maximum 20 characters)

**Default**

If not specified the file-name, the system will delete startup-config by default.

**Command Mode**

Monitor mode

**Usage Guidelines**

None

**Related Command**

None

**1.1.3 dir****Syntax**

To display filename, use the **dir** command.

**dir** *file-name*

**Parameter**

Parameter	Description
<i>-name</i>	ecifies the filename (maximum 20 characters)

**Default**

None

**Command Mode**

monitor mode

**Usage Guidelines**

None

**Related Command**

None

### 1.1.4 ip address

#### Syntax

To set an IP address for an Ethernet interface, use the **ip address** command.

**ip address** *ip-address mask*

#### Parameter

Parameter	Description
<i>address</i>	address
<i>mask</i>	network mask

#### Default

None

#### Command Mode

Monitor mode

#### Usage Guidelines

None

#### Example

```
monitor#ip address 192.168.1.1 255.255.255.0
```

#### Related Command

ip route

ping

### 1.1.5 ip default-gateway

#### Syntax

To set the default gateway, run the following command:

**ip default-gateway** *gw\_ip\_addr*

**Parameter**

Parameter	Description
<i>_ip_addr</i>	e address of the default gateway.

**Default**

None

**Command Mode**

The monitoring state.

**Usage Guidelines**

None

**Example**

```
monitor#ip default-gateway 192.168.1.3
```

**Related Command**

ip address

**1.1.6 show configuration****Syntax**

To display the running configuration file, use the **show configuration** command.

**show configuration**

**Parameter**

None

**Default**

None

**Command Mode**

Monitor mode

**Usage Guidelines**

None

**Related Command**

None

**1.1.7 format****Syntax**

To format file system, use the **format** command.

**format**

**Parameter**

None

**Default**

None

**Command Mode**

EXEC

**Usage Guidelines**

All files in the file system will de deleted after executing the **format** command.

**Related Command**

None

**1.1.8 more****Syntax**

To display the contents of a file, use the **more** command.

---

**more** *file-name*

### Parameter

Parameter	Description
<i>-name</i>	Specifies the name of a file (maximum 20 characters)

### Default

None

### Command Mode

EXEC

### Usage Guidelines

If all files are displayable characters, they will be displayed in ASCII format, or they will be displayed binary format.

### Related Command

None

## 1.2 Basic System Management Commands

- bootflash
- cd
- chinese
- english
- date
- md
- pwd
- rd
- rename
- reboot
- show break
- alias
- boot system flash

- help
- show
- history
- show alias

### 1.2.1 boot flash

#### Syntax

To enable the system from the specified file in monitor mode, use the **boot flash** command.

**boot flash** *filename*

#### Parameter

Parameter	Description
<i>name</i>	ecified file name.

#### Default

None

#### Command Mode

Monitor mode

#### Usage Guidelines

Use the boot flash command to enable the device after user entering the monitor mode.

#### Example

```
monitor#boot flash switch.bin
```

#### Related Command

None

### 1.2.2 cd

#### Syntax

To change the current directory, use the **cd** command.

**cd** *directory* | ..

#### Parameter:

Parameter	Description
<i>directory</i>	name of the directory. (maximum 20 characters)
	per directory.

#### Default

None

#### Command Mode

Monitor mode

#### Usage Guidelines

None

#### Example

```
monitor#cd my_dir
```

#### Related Command

pwd

### 1.2.3 chinese

#### Syntax

To switch command prompt to chinese mode, use the **chinese** command.

#### Parameter

None

**Default**

None

**Command Mode**

Monitor mode

**Usage Guidelines**

None

**Example**

None

**Related Command**

None

#### 1.2.4 date

**Syntax**

To set the absolute time, use the **date** command.

**Parameter**

None

**Default**

None

**Command Mode**

Monitor mode

**Usage Guidelines**

This command is used to set the absolute time for the system. For the switch with a battery-powered clock, the clock will be powered by the battery. If the clock doesn't keep good time, you need to change the battery.

For the switch without a battery-powered clock, the system date is configured to July 1<sup>st</sup>, 1970 after the reboot of the switch, and user needs to set the current time each time when starting the switch.

**Example**

monitor#date

The current date is 2000-7-27 21:17:24

Enter the new date(yyyy-mm-dd):2000-7-27

Enter the new time(hh:mm:ss):21:17:00

**Related Command****1.2.5 english****Syntax**

To switch the command prompt to english mode, use the **english** command.

**Parameter**

None

**Default**

None

**Command Mode**

Monitor mode

**Usage Guidelines**

None

**Example**

None

**Related Command**

None

**1.2.6 md****Syntax**

**md** *directory*

**Parameter**

Parameter	Description
<i>directory</i>	name of directory (maximum 20 characters)

**Default**

None

**Command Mode**

Monitor mode

**Usage Guidelines**

To set a directory, use the **md** command

**Related Command**

None

**1.2.7 pwd****Parameter**

None

**Default**

None

**Command Mode**

Monitor mode

**Usage Guidelines**

To display the current directory, use the **pwd** command

**Related Command**

None

**1.2.8 rd****Syntax**

**rd** *directory*

**Parameter**

Parameter	Description
<i>directory</i>	name of the directory( maximum 20 characters)

**Default**

None

**Command Mode**

Monitor mode

**Usage Guidelines**

The system prompts if the directory is not empty. The system prompts if the directory doesn't exist. To delete a command, use the rd command.

**Related Command**

None

---

### 1.2.9 rename

#### Syntax

To rename a file in a file system, use the **rename** command.

**rename** *old\_file\_name new\_file\_name*

#### Parameter

Parameter	Description
<i>l_file_name</i>	e original filename.
<i>w_file_name</i>	e new filename.

#### Default

None

#### Command Mode

Monitor mode

#### Usage Guidelines

None

#### Related Command

None

### 1.2.10 reboot

#### Parameter

None

#### Default

None

#### Command Mode

Monitor mode

## Usage Guidelines

To reboot a switch, use the **reboot** command.

## Related Command

None

### 1.2.11 alias

## Syntax

**alias** *alias\_name command\_line*

## Parameter

Parameter	Description
<i>as_name</i>	me the alias name.
<i>command_line</i>	e command of naming the alias name.

## Default

None

## Comand mode

Global configuration mode

## Usage Guidelines

The command can be used to replace "command\_line" with "alias\_name". For instance, alias update1 copy tftp: switch.bin flash:switch.bin 10.168.30.188. The command " copy tftp: switch.bin flash:switch.bin 10.168.30.188 " will automatically run on the OLT only update 1 is input.

## Example

The following example shows how to use the command to replace " copy tftp:BDMSU8508\_4.0.0B.bin flash:switch.bin 10.168.30.188" with " update1".

```
alias update1 copy tftp:BDMSU8508_4.0.0B.bin flash:switch.bin 10.168.30.188
```

---

**Related Command**

None

**1.2.12 boot system flash****Syntax**

Run the **boot system flash** command to specify the systematic mirroring files when the system is started up. Run the **no boot system flash** command to delete the previous configuration.

**boot system flash** *filename***no boot system flash** *filename***Parameter**

Parameter	Description
<i>name</i>	is the specified filename, which contains no more than 20 characters.

**Default**

None

**Command Mode**

Global configuration mode

**Usage Guidelines**

If you have not configured the command, the system will execute the first systematic mirroring file in the flash file system. If you have configured multiple commands, the system will execute the mirroring files one by one. If the file does not exist or the check sum is wrong, the system will execute the next file. If both fail, the system will run at the monitoring state.

**Example**

```
config#boot system flash switch.bin
```

**Related Command**

None

**1.2.13 help****Syntax**

**help**

**Parameter**

None

**Default**

None

**Command Mode**

EXEC mode

**Usage Guidelines**

The command is used to display the help system of the switch.

**Example**

The foloowing example shows how to display the help system of the switch, after you enter the command.

```
switch# help
```

Help may be requested at any point in a command by entering a question mark '?'. If nothing matches, the help list will be empty and you must backup until entering a '?' shows the available options.

Two styles of help are provided:

1. Full help is available when you are ready to enter a command argument(e.g.'show ?') and describes each possible argument.
2. Partial help is provided when an abbreviated argument is entered and you want to know what arguments match the input (e.g. 'interface e?'.)

---

**Related Command**

None

**1.2.14 history****Syntax**

The command is used to check the historical commands. Run the **[no] history** command to delete the historical commands.

**[no] history** [ + <count> | - <count> | clear]

**Parameter**

Parameter	Description
<count>	Displays the count<1-20> historical command from the beginning to the end.
count>	Displays the count<1-20> historical command from the end to the beginning.

**Default**

If there are no more than 20 commands executed, all historical command lines will be displayed from the beginning to the end. If there are more than 20 commands executed, the latest 20 command lines will be displayed from the beginning to the end.

**Command Mode**

Abandom command mode

**Usage Guidelines**

The modularized switch can save up to 20 historical commands. You can invoke these commands with the “up” or “down” key or directly use it after edition.

**Example**

The following example shows the latest five commands from the end to the

```

beginning:
switch#history - 5

config

int e1/1

no ip addr

ip addr 192.2.2.49 255.255.255.0

exit

```

### Related Command

None

### 1.2.15 show

#### Syntax

To display the relevant information of the system, which or specific ones of which can be filtered through the filter, run the following command:

**show <sub-command> [ | <begin | include | exclude | redirect> <WORD> [SEPARATOR WORD]]**

#### Parameter

Parameter	Description
<b>b-command</b>	stands for a child command.
	es the output filter.
<b>gin</b>	means to show the result of the <b>show</b> command starting with a specific word.
<b>clude</b>	means to show the sentences of the result of the <b>show</b> command containing a specific word.
<b>clude</b>	means not to show the lines of the result of the <b>show</b> command containing a specific word.
<b>direct</b>	edirects the result of the <b>show</b> command to the file in the designated file system.

<b>WORD</b>	stands for a designated word, which is the designated filename as to the <b>redirect</b> command.
<b>SEPARATOR WORD</b>	stands for the designated separator, which is space by default to separate the words.

### Default

None

### Command Mode

EXEC mode or global configuration mode

### Usage Guidelines

This command can be used to filter the useless information in the result of the **show** command, especially when the result is too much to read. For example, if you want to browse a designated MAC address in an MAC address table, which contains a lot of MAC addresses, this command will give you convenience for you.

### Example

The following example shows how to display the lines, in which the word “interface” is contained, in the result of **show running-config**.

```
Switch#show running-config | include interface
Building configuration...
```

Current configuration:

```
!
interface GigaEthernet0/1
interface GigaEthernet0/2
interface GigaEthernet0/3
interface GigaEthernet0/4
interface GigaEthernet0/5
interface GigaEthernet0/6
```

```
interface GigaEthernet0/7
```

```
interface GigaEthernet0/8
```

## Related Command

None

### 1.2.16 show alias

## Syntax

To display all alias commands, or the alias commands in a specified mode, use the `show aliases` command.

**show alias** [*<alias name>*]

## Parameter

parameter	description
<i>name</i>	command

## Default

Display all alias commands in the format of alias name=command line.

## Command Mode

EXEC mode or global configuration mode

## Usage Guidelines

None

## Example

The following example shows how to use the command to display all alias names:

```
switch_config#show alias
```

```
hualab=date
```

```
router=snmp
```

## Related Command

alias

### 1.2.17 show break

**Syntax**

It is used to display the abnormal information of the system. The system stores all abnormal information in the latest running. The abnormal information contains the times of abnormality, the stack content and the invoked functions when abnormality occurs.

**Parameter**

None

**Default**

None

**Command Mode**

Monitor mode

**Usage Guidelines**

The command is only used for debugging.

**Related Command**

None

## Chapter 2 Terminal Service Configuration Commands

### 2.1 Telnet Configuration Commands

The chapter describes telnet and related commands. The **telnet** command is used to establish a session with the remote server. The **telnet** command is always working at the UNIX operating systems. Option negotiation is required. Telnet does not provide itself the login authentication. Telnet is different from Rlogin because telnet does not provide itself password check.

The telnet configuration commands include:

- telnet
- ip telnet
- where
- disconnect
- resume
- clear Telnet
- show Telnet
- debug Telnet

#### 2.1.1 telnet

##### Syntax

The following is a command for establishing a telnet session:

```
telnet server-ip-addr/server-host-name [/port port][/source-interface interface] [/local
local-ip-addr] [/debug][/echo/noecho] [/script scriptname]
```

##### Parameter

Parameter	Description
<i>server-ip-addr</i>	otted-decimal IP address of the remote server
<i>server-host-name</i>	ame of the remote server, which is configured by the <b>ip host</b> command
<i>port</i>	net port of the remote server

<i>erface</i>	cal interface where the telnet connection is originated
<i>al-ip-addr</i>	cal IP address where the telnet connection is originated
<i>debug</i>	A negotiation process for opening the debug at the client side and printing the connection
<i>cho</i> <i>pecho</i>	able or disable the local echo. The default value is <b>noecho</b> .
<i>riptname</i>	script name used for auto login

## Default

The default port number is 23. The interface has no default number.

## Command Mode

EXEC mode or global configuration mode

## Usage Guidelines

You can use one of the following command lines to establish a remote login.

```
telnet server-ip-addr/server-host-name
```

In this case, the application program directly sends the telnet login request to port 23 of the remote server. The local IP address is the IP address which is nearest to the peer and found by the routing table.

```
telnet server-ip-addr/server-host-name /port port
```

In this case, the application program sends a telnet login request to the port of the peer.

```
telnet server-ip-addr/server-host-name /source-interface interface
```

In this case, the application program uses the IP address on the interface as the local IP address.

```
telnet server-ip-addr/server-host-name /debug
```

In this case, the application program opens the debug and exports the connection at the client side.

```
telnet server-ip-addr/server-host-name echo/noecho
```

In this case, the application program enables or disables the local echo. The local echo is disabled by default. The echo is completed at the server side.

Only when the server is not in charge of echo is the local echo enabled.

```
telnet server-ip-addr/server-host-name /script scriptname
```

Before executing the automatic login command of the script, run the command

**ip telnet script** to configure the script.

The previous commands can be used together.

During the session with the remote server, you can press the **Q** button to exit the session. If the session is not manually closed, the session will be complete after a 10-second timeout.

### Example

Suppose you want to telnet server 192.168.20.124, the telnet port of the server is port 23 and port 2323, and the local two interfaces are e1/1(192.168.20.240) and s1/0(202.96.124.240). You can run the following operations to complete the remote login.

1. telnet 192.168.20.124 /port 2323

In this case, the telnet connection with port 2323 of the peer is to be established. The local IP address of the peer is 192.168.20.240.

2. telnet 192.168.20.124 /source-interface s1/0

In this case, the telnet connection with port 23 of the peer is to be established. The local IP address of the peer is 202.96.124.240.

3. telnet 192.168.20.124 /local 192.168.20.240

In this case, the telnet connection with port 23 of the peer is to be established. The local IP address of the peer is 192.168.20.240.

4. telnet 192.168.20.124 /debug

In this case, the telnet connection negotiation with port 23 of the peer will be printed out.

5. telnet 192.168.20.124 /echo

In this case, the local echo is enabled. If the echo is also enabled at the server side, all input will be echoed twice.

6. telnet 192.168.20.124 /script s1

Use login script S1 for automatic login.

## 2.1.2 ip telnet

### Syntax

The following are the configuration commands of the telnet session:

**ip telnet source-interface** *vlan value*

**ip telnet access-class** *accesslist*

**ip telnet listen-port** *start-port [end-port]*

**ip telnet script** *scriptname 'user\_prompt' user\_answer 'pwd\_prompt' pwd\_answer*

### Parameter

Parameter	Description
<i>m</i>	Maximum number of Telnet connections.
<i>ue</i>	cal interface where the telnet request is originated
<i>cesslist</i>	Access list name to limit the source address when the local client receives the connection
<i>rt-port</i>	arting port number designated at the listening port area
<i>d-port</i>	d port number designated at the listening port area
<i>riptname</i>	me of the login script
<i>er_prompt</i>	ername prompt returned by the telnet server
<i>er_answer</i>	ername response information from the client side
<i>d_prompt</i>	ssword prompt returned by the telnet server
<i>d_answer</i>	ssword response information submitted by the client side

### Default

None

### Command Mode

Global configuration

---

## Usage Guidelines

- Run the following command to configure the local interface for originating the telnet connection:

`ip telnet source-interface interface`

In this case, all telnet connections originated afterwards are through the interface. The configuration command is similar to the command **telnet source-interface *interface***. However, the **telnet** command has no interface parameters followed. When the interface is configured and the **telnet** command has interface parameters, the interface followed the telnet command is used.

- Run the following command to configure the name of the access list which performs limitation on local telnet connection reception.

`ip telnet access-class accesslist`

In this case, the access list will be checked when the server accepts all telnet connections.

- Run the following command to configure a port, except the default port 23, to receive the telnet service.

**`ip telnet listen-port start-port [end-port]`**

Usage Guidelines: If the end port number is not designated, the listening will be executed at a specific port. The number of the designated ports cannot be bigger than 16 and the port number ranges between 3001 and 3999.

- Run the following command to configure the telnet login script.

`ip telnet script s1 'login:' switch 'Password:' test`

Usage Guidelines: When the script is configured, the username prompt and password prompt and their answers must be correctly matched, especially the prompt information is capital sensitive and has inverted comma ("). If one of them is wrongly configured, the automatic login cannot be performed.

### Note:

You can add the NO prefix on the above four commands and then run them to cancel previous configuration.

## Example

1. ip telnet source-interface vlan1

In this case, the interface vlan1 will be adopted to originate all telnet connections afterwards.

2. ip telnet access-class abc

In this case, all the received telnet connections use access list **abc** to perform the access list check.

3. ip telnet listen-port 3001 3010

Except port 23, all ports from port 3001 to port 3010 can receive the telnet connection.

4. ip telnet script s1 'login:' switch 'Password:' test

The login script **s1** is configured. The username prompt is **login:** and the answer is **switch**. The password prompt is **Password:** and the answer is **test**.

### 2.1.3 ctrl-shift-6+x (the current connection is mounted)

#### Syntax

Run the following command to mount the current telnet connection:

**ctrl-shift-6+x**

#### Parameter

None

#### Default

None

#### Command Mode

Any moment in the current telnet session

#### Usage Guidelines

You can use the shortcut key to mount the current telnet connection at the client side.

## Example

```
switchA>telnet 192.168.20.1
```

```
Welcome to Multi-Protocol 2000 Series switch
```

```
switchB>ena
```

```
switchB#(press ctrl-shift-6+x)
```

```
switchA>
```

You press **ctrl-shift-6+x** to mount the telnet connection to switch B and return to the current state of switch A.

### 2.1.4 where

#### Syntax

Run the following command to check the currently mounted telnet session:

**where**

#### Parameter

None

#### Default

None

#### Command Mode

Global configuration

#### Usage Guidelines

You can use the command to check the mounted outward telnet connection at the client side. The displayed information contains the serial number, peer address, local address and local port.

##### **Note:**

The **where** command is different from the **show telnet** command. The former is used at the client side and the displayed information is the outward telnet connection. The latter is used at the server and the displayed information is the inward telnet connection.

**Example**

```

switchA>telnet 192.168.20.1

Welcome to Multi-Protocol 2000 Series switch

switchB>ena

switchB#(Press ctrl-shift-6+x)

switchA> telnet 192.168.20.2

Welcome to Multi-Protocol 2000 Series switch

switchC>ena

switchC#(Press ctrl-shift-6+x)

switchA>where

```

NO.	Remote Addr	Remote Port	Local Addr	Local Port
1	192.168.20.1	23	192.168.20.180	20034
2	192.168.20.2	23	192.168.20.180	20035

Enter **where** at switch A. The mounted outward connection is displayed.

**2.1.5 resume****Syntax**

The following command is used to resume the currently mounted outward telnet connection:

**resume** *no*

**Parameter**

Parameter	Description
	Number of the currently mounted telnet session that is checked through the <b>where</b> command

**Default**

None

## Command Mode

Global configuration

## Usage Guidelines

The command can be used to resume the currently mounted outward telnet connection at the client side.

## Example

```
switchA>telnet 192.168.20.1

Welcome to Multi-Protocol 2000 Series switch

switchB>ena

switchB#( press ctrl-shift-6+x)

switchA> telnet 192.168.20.2

Welcome to Multi-Protocol 2000 Series switch

switchC>ena

switchC#( press ctrl-shift-6+x)

switchA>where
```

NO.	Remote Addr	Remote Port	Local Addr	Local Port
1	192.168.20.1	23	192.168.20.180	20034
2	192.168.20.2	23	192.168.20.180	20035

```
switchA>Resume 1

[Resuming connection 1 to 192.168.20.73 . . . ]

(enter)

switchB#
```

After you enter **where** at switch A and the mounted outward connection of switch A is displayed. When entering **Resume1**, you will be prompted that connection 1 is resumed. The command prompts of switch B are displayed after the **Enter** key is pressed.

### 2.1.6 disconnect

## Syntax

The following command is used to clear the currently mounted outward telnet

session:

**disconnect** *no*

### Parameter

Parameter	Description
	Number of the currently mounted telnet session that is checked through the <b>where</b> command

### Default

None

### Command Mode

Global configuration mode

### Usage Guidelines

The command can be used to clear the currently mounted outward telnet connection at the client side.

#### Note:

The **disconnect** command is different from the **clear telnet** command.

The former is used at the client side and clears the outward telnet connection. The latter is used at the server and clears the inward telnet connection.

### Example

```
switchA>telnet 192.168.20.1
Welcome to Multi-Protocol 2000 Series switch
switchB>ena
switchB#(press ctrl-shift-6+x)
switchA> telnet 192.168.20.2
Welcome to Multi-Protocol 2000 Series switch
switchC>ena
switchC#(press ctrl-shift-6+x)
switchA>where
```

NO.	Remote Addr	Remote Port	Local Addr	Local Port
1	192.168.20.1	23	192.168.20.180	20034
2	192.168.20.2	23	192.168.20.180	20035

switchA>disconnect 1

<Closing connection to 192.168.20.1> <y/n>y

Connection closed by remote host.

switchA>

After you enter **where** at switch A and the mounted outward connection of switch A is displayed, enter **disconnect 1**. You will be prompted whether the connection of switch B is closed. After you enter **Y**, the connection is closed.

## 2.1.7 clear telnet

### Syntax

The following is a command format to clear the telnet session at the server:

**clear telnet** *no*

### Parameter

Parameter	Description
	umber of the telnet session that is displayed after the <b>show telnet</b> command is run

### Default

None

### Command Mode

EXEC mode

### Usage Guidelines

The command is used to clear the telnet session at the server.

**Example**

```
clear telnet 1
```

The telnet session whose sequence number is 1 is cleared at the server.

**2.1.8 show telnet****Syntax**

The following is a command format to display the telnet session at the server:

**show telnet**

**Parameter**

None

**Default**

None

**Command Mode**

All command modes except the user mode

**Usage Guidelines**

The command is used to display the telnet session at the server. The displayed information includes the sequence number, peer address, peer port, local address and local port.

**Example**

```
Switch# show telnet
```

If you run the previous command, the result is shown as follows:

NO.	Remote Addr	Remote Port	Local Addr	Local Port
1	192.168.20.220	1097	192.168.20.240	23
2	192.168.20.180	14034	192.168.20.240	23

### 2.1.9 debug telnet

#### Syntax

The following is a format of the **debug** command for the telnet session:

**debug telnet**

#### Parameter

None

#### Default

None

#### Command Mode

EXEC mode

#### Usage Guidelines

The command is used to enable the telnet debug.

If the switch of the telnet debug is opened, the negotiation processes of all the incoming telnet sessions are printed on the window that the debug command invokes. The **debug telnet** command is different from the **telnet debug** command. The former is to export the debug information of the telnet session connected to the server. The latter is to export the debug information of the telnet session that the client originates.

#### Example

```
debug telnet
```

After using the command, the debug information of the telnet session that is connected to the server is displayed.

## 2.2 Terminal Configuration Commands

The terminal configuration commands include:

- attach-port
- autocommand

- clear line
- connect
- disconnect
- exec-timeout
- length
- line
- location
- login authentication
- monitor
- no debug all
- password
- resume
- show debug
- show line
- terminal-type
- terminal monitor
- terminal width
- terminal length
- where
- width

### 2.2.1 attach-port

#### Syntax

The following command is to bind the telnet listening port to the **line vty** number and enable the telnet connection at a specific port generates **vtty** according to the designated sequence number.

**[no] attach-port** *PORT*

#### Parameter

Parameter	Description
<i>vtty</i>	Listening port of the telnet server (3001-3999)

**Default**

None

**Command Mode**

Line configuration mode

**Example**

The following example shows how to bind listening port 3001 to line vty 2 3.

```
switch_config# line vty 2 3
```

```
switch_config_line#attach-port 3001
```

**2.2.2 autocommand****Syntax**

It is used to set the automatically-run command when user logs in to the terminal. The connection is cut off after the command is executed.

**autocommand** *LINE*

**no autocommand**

**Parameter**

Parameter	Description
<i>LINE</i>	Command to be executed

**Command Mode**

Line configuration mode

**Example**

```
switch_conf#line vty 1
```

```
switch_conf_line#autocommand pad 123456
```

After you successfully log in, the host whose X.121 address is 123456 will be automatically padded.

### 2.2.3 clear line

#### Syntax

To clear the designated line, use the following command:

**clear line** [*aux* | *tty* | *vty*] [*number*]

#### Parameter

Similar to the **line** command

#### Command Mode

EXEC mode

#### Example

```
switch#clear line vty 0
```

### 2.2.4 connect

#### Syntax

To connect the telnet server, use the following command:

**connect** *server-ip-addr/server-host-name* {[**/port** *port*]}[**/source-interface** *interface*] [**/local** *local-ip-addr*]} [**/script** *word*]

#### Parameter

Parameter	Description
<i>server-ip-addr/server-host-name</i>	address of the server or the host name of the server
<i>port</i>	port number
<i>source-interface</i>	name of the interface where the connection is originated
<i>local-ip-addr</i>	local IP address where the connection is originated
<i>script</i>	name of the script

**Command Mode**

All configuration modes

**Example**

```
switch# connect 192.168.20.1
```

**2.2.5 disconnect****Syntax**

To delete the mounted telnet session, use the following command:

```
disconnect N
```

**Parameter**

Parameter	Description
	Number of the mounted telnet session

**Command Mode**

All configuration modes

**Example**

```
switch#disconnect 1
```

**2.2.6 exec-timeout****Syntax**

To set the maximum spare time for the terminal, use the following command:

```
[no] exec-timeout [time]
```

**Parameter**

Parameter	Description
<i>time</i>	are time whose unit is second.. Range: 0-864000.

**Default**

0 (No time-out limitation)

**Command Mode**

Line configuration mode

**Example**

Set the spare time of the line to one hour.

```
switch_config_line#exec-timeout 3600
```

**2.2.7 length****Syntax**

To set the line number on the screen of the terminal, use the following command:

**[no] length** *[value]*

**Parameter**

Parameter	Description
<i>value</i>	value between 0 and 512  The value <b>0</b> means there is no pause.

**Default**

24

**Command Mode**

Line configuration mode

**2.2.8 line****Syntax**

To enter the line configuration mode, use the following command:

**line** **[aux | console | tty | vty]** *[number]*

**Parameter**

Parameter	Description
<i>console</i>	monitoring line, which has only one number <b>0</b>
<i>number</i>	virtual lines such as Telnet, PAD and Rlogin
<i>number</i>	number in the line of the type

**Command Mode**

Global configuration mode

**Example**

The following example shows how to enter the line configuration mode of VTY 0 to 10.

```
switch_config#line vty 0 10
```

**2.2.9 location****Syntax**

To recoded the description of the current line, use the following command. To return to the default setting, use the no form of this command.

**location** [*LINE*]

**no location**

**Parameter**

Parameter	Description
<i>LINE</i>	description of the current line

**Command Mode**

Line configuration mode

## 2.2.10 login authentication

### Syntax

To set line login authentication parameters, use the following command. To return to the default setting, use the no form of this command.

**[no] line login authentication [default | WORD]**

### Parameter

Parameter	Description
<b>fault</b>	fault authentication mode
<b>WORD</b>	name of the authentication list

### Command Mode

Line configuration mode

### Example

```
switch_conf_line#login authentication test
```

In the example, the authentication list of the line is set to **test**.

## 2.2.11 monitor

### Syntax

To export the log and debugging information to the line, use the following command. To return to the default setting, use the no form of this command.

**[no] monitor**

### Parameter

None

### Command Mode

Line configuration mode

**Example**

```
switch_config_line#monitor
```

**2.2.12 no debug all****Syntax**

To shut down all debugging output of the current VTY, use the following command.

**no debug all**

**Parameter**

None

**Command Mode**

EXEC mode

**Example**

```
switch#no debug all
```

**2.2.13 password****Syntax**

To set the password for the terminal, use the following command. To return to the default setting, use the no form of this command.

**password** {*password* | [encryption-type] *encrypted-password* }

**no password**

**Parameter**

Parameter	Description
<i>password</i>	password configured on the line, which is entered in the plaintext form and whose maximum length is 30 bits.
[encryption-type] <i>encrypted-password</i>	<b>crypttion-type</b> means the encryption type of the password. Currently, MY COMPANY products only support two encryption

<i>d</i>	<p>modes: 0 and 7. The number <b>0</b> means the password is not encrypted and the plaintext of password is directly entered. It is the same as the way of directly entering the password. The number <b>7</b> means the password is encrypted through an algorithm defined by MY COMPANY. You need to enter the encryption text for the encrypted password. The encryption text can be copied from the configuration files of other switches.</p>
----------	--

For password encryption, refer to the explanation of the commands **service password-encryption** and **enable password**.

### Command Mode

Line configuration mode

### Example

```
switch_conf#line vty 1
```

```
switch_conf_line#password test
```

The previous example shows the login password of VTY1 is set to **test**.

## 2.2.14 resume

### Syntax

To resume the mounted telnet session, use the following command.

```
resume N
```

### Parameter

Parameter	Description
	umber of the mounted telnet session

### Command Mode

All configuration modes

**Example**

```
switch#resume 1
```

**2.2.15 show debug****Syntax**

To display all debugging information of the current VTY, use the following command.

```
show debug
```

**Parameter**

None

**Command Mode**

EXEC mode or global configuration mode

**Example**

```
Switch# show debug
http authentication debug is on
http cli debug is on
http request debug is on
http response debug is on
http session debug is on
http erro debug is on
http file debug is on
TELNET:
Incoming Telnet debugging is on
```

**2.2.16 show line****Syntax**

To display the status of the current effective line, use the following command.

```
show line {[console | vty] [number]}
```

**Parameter**

If there is no parameter followed, the status of all effective lines will be displayed.

The definition of other parameters is similar to that of the **line** command.

**Command Mode**

All configuration modes except the user mode

**2.2.17 terminal length****Syntax**

It is used to change the line number on the current terminal screen. The parameter can be obtained by the remote host. The rlogin protocol uses the parameter to notify the remote UNIX host. Run the **no terminal length** command to resume the default value:

**terminal length** *length*

**no terminal length**

**Parameter**

Parameter	Description
<i>length</i>	<p>line number displayed on each screen</p> <p>range: 0-512.</p>

**Default**

Pause when 24 lines are displayed on the screen.

**Command Mode**

Global configuration mode

**Usage Guidelines**

The command is effective only to the current terminal. When the session is complete, the terminal attribute is invalid.

**Example**

```
switch#terminal length 40
```

**Related Command**

**line**

**2.2.18 terminal monitor****Syntax**

It is used to display the debugging output information and system faulty information at the current terminal. The no form of the command is used to disable the monitoring:

**terminal monitor**

**no terminal monitor**

**Parameter**

None

**Default**

The system monitoring port (console) is open by default. Other terminals are closed by default.

**Command Mode**

Global configuration

**Usage Guidelines**

The command is effective only to the current terminal. When the session is complete, the terminal attribute is invalid.

**Example**

```
switch#terminal monitor
```

---

## Related Command

line

debug

### 2.2.19 terminal width

#### Syntax

In default settings, the switch is to export 80 characters in each line. If the default settings cannot meet your requirements, you can reset it. The parameter can be obtained by the remote host. Run the **terminal width** command to set the character number in each line. Run the **no terminal width** command to resume to the default value.

**terminal width** *number*

**no terminal width**

#### Parameter

Parameter	Description
<i>number</i>	character number of each line

#### Default

Display 80 characters in each line

#### Command Mode

Global configuration

#### Usage Guidelines

The command is effective only to the current terminal. When the session is complete, the terminal attribute is invalid.

#### Example

switch#terminal width 40

**Related Command**

line

**2.2.20 terminal-type****Syntax**

To set the terminal type, use the following command.

**[no] terminal-type** [*name*]

**Parameter**

Parameter	Description
<i>name</i>	terminal name  Terminal types currently supported are VT100, ANSI and VT100J.

**Default**

ANSI

**Command Mode**

Line configuration mode

**2.2.21 where****Syntax**

To check the currently mounted outward telnet session at the client side, use the following command.

**where**

**Parameter**

None

**Command Mode**

All configuration modes

---

**Example**

```
switch#where
```

**2.2.22 width****Syntax**

To set the terminal width of the line, use the following command. To return to the default setting, use the no form of this command.

**[no] width [value]**

**Parameter**

Parameter	Description
<i>value</i>	value between 0 and 256  The value <b>0</b> means no execution.

**Default**

80

**Command Mode**

Line configuration mode

## Chapter 3 Maintenance and Debugging Tool Commands

### 3.1 Network Testing Tool Commands

#### 3.1.1 ping

##### Syntax

It is used to test host accessibility and network connectivity. After the **ping** command is run, an ICMP request message is sent to the destination host, and then the destination host returns an ICMP response message.

**ping** [-a][-d][-f] [-i {source-ip-address}] [-m {source-interface}] [-j host1 [host2 host3 ...]] [-k host1 [host2, host3 ...]] [-l length] [-n number] [-r hops] [-s tos] [-t ttl] [-v] [-w *waittime*] [-b *interval*] [-c] **host**

##### Parameter

Parameter	Description
	ts ping all along until it is been interrupted.
	ts not apply the routing table.
	ts the DF digit (message is not segmented).  the message required to be sent is larger than the MTU of the path, the message will be dropped by the routing switch on the path and the routing switch will then return an ICMP error message to the source host. If network performance has problems, one node in the network may be configured to a small MTU. You can use the <b>-f</b> option to decide the smallest MTU on the path.  efault: No resetting
	ts the source IP address of the message or the IP address of an interface.  efault: Main IP address of the message-sending interface

<i>source-ip-address</i>	source IP address adopted by the message
<i>source-interface</i>	message takes the IP address of the <b>source-interface</b> interface as the source address.
<i>host1 [host2 host3...]</i>	its the relaxation source route. default: Not set
<i>host1 [host2 host3...]</i>	its the strict source route default: Not set
<i>length</i>	its the length of ICMP data in the message. default: 56 bytes
<i>number</i>	its the total number of messages. default: 5 messages
<i>hops</i>	records routes. to <b>hops</b> routes are recorded. default: not record
<i>tos</i>	its IP TOS of the message to <b>tos</b> . default: 0
<i>tll</i>	its IP TTL of the message to <b>tll</b> . default: 255
	tailed output
<i>waittime</i>	ne for each message to wait for response default: 2 seconds
<i>interval</i>	its the time interval of sending ping packet. it: 10ms; Value range: 0-65535; Default Value: 0.
	mple output
<i>st</i>	estination host

## Command Mode

EXEC mode, global configuration mode

## Usage Guidelines

The command supports that the destination address is the broadcast address or the multicast address. If the destination address is the broadcast address (255.255.255.255) or the multicast address, the ICMP request message is sent on all interfaces that support broadcast or multicast. The routing switch is to export the addresses of all response hosts. By pinging multicast address 224.0.0.1, you can obtain the information about all hosts in directly-connected network segment that support multicast transmission.

Press the **Q** or **q** key to stop the **ping** command.

Simple output is adopted by default.

Parameter	Description
	response message is received.
	response message is not received in the timeout time.
	the message that the ICMP destination cannot be reached is received.
	the ICMP source control message is received.
	the ICMP redirection message is received.
	the ICMP timeout message is received.
	the ICMP parameter problem message is received.

The statistics information is exported:

Parameter	Description
packets transmitted	number of transmitted messages
packets received	number of received response messages, excluding other ICMP messages
packet loss	rate of messages that are not responded to
round-trip min/avg/max	minimum/average/maximum time of a round trip (ms)

## Example

```
switch#ping -l 10000 -n 30 192.168.20.125
```

```
PING 192.168.20.125 (192.168.20.125): 10000 data bytes
```

!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!

--- 192.168.20.125 ping statistics ---

30 packets transmitted, 30 packets received, 0% packet loss

round-trip min/avg/max = 50/64/110 ms

### 3.1.2 traceroute

#### Syntax

It is used to detect which routes have already reached the destination.

You can transmit to the destination the UDP packets (or ICMP ECHO packets) of different TTLs to confirm which routes have come to the destination. Each router on this path has to deduct 1 from the TTL value before forwarding ICMP ECHO packets. Speaking from this aspect, TTL is an effective hop count. When the TTL value of a packet is deducted to zero, the router sends back to the source system the ICMP timeout message.

By checking the ICMP timeout message sent back by intermedial routers, you can confirm the routers. At the arrival of the destination, the traceroute sends a UDP packet whose port ID is larger than 30000; the destination node hence can only transmit back a Port Unreachable ICMP message. This reception of this message means the arrival of destination.

**traceroute** [-i source-ip-address ] [-m source-interface}] [-j host1 [host2 host3 ...]] [-k host1 [host2, host3 ...]] [-p port-number] [-q probe-count] [-r hops] [-t ttl] [-w waittime] [-x icmp] **host**

#### Parameter

Parameter	Description
<i>source-ip-address</i>	ts the source IP address of packet.
<i>source-interface</i>	ts the packet-transmitted port.
<i>host1 [host2 host3...]</i>	ts the loose source route.Default: Not set
<i>host1 [host2 host3...]</i>	ts the strict source route. fault: Not set

<i>port-number</i>	ts the ID of destination port that transmits UDP packets. Default: 33434
<i>probe-count</i>	ts the number of packets that you detect each time. efault: 3 packets
<i>hops</i>	records the routes (at most <b><i>hops</i></b> routes can be recorded). efault: The routes are not recorded.
<i>tTL</i>	ts the IP TTL of packets as TTL. efault: the minimum and maximum TTLs are 1 and 30 respectively.
<i>waittime</i>	means the time that each packet waits for echo. efault: 3 seconds
<i>icmp</i>	ts the detection packet to be the ICMP ECHO packet. efault: UDP packet
<i>st</i>	means the destination host.

## Command Mode

EXEC or global configuration mode

## Usage Guidelines

The UDP packet is used for detection by default, but you can run **→x icmp** to replace it with ICMP ECHO for detection.

If you want to stop traceroute, press **q** or **Q**.

By default, the simple output information is as follows.

Parameter	Description
	ceives an ICMP-route unreachable packet.
	ceives an ICMP-host unreachable packet.
	ceives an ICMP-protocol unreachable packet.
	ceives an ICMP unreachable (need to be fragmented) packet.
	ceive an ICMP unreachable (failing to detect the source-station route) packet.

The exported statistics information is as follows:

Parameter	Description
hops max	Means the maximum detection hops (the threshold of ICMP).
packet size	Means the size of each detection packet.

### Example

```
switch#traceroute 90.1.1.10

traceroute to 90.1.1.10 (90.1.1.10), 30 hops max, 36 byte packets
 1  90.2.2.1  0 ms  0 ms  0 ms
 2  90.1.1.10  0 ms  0 ms  0 ms
```

## 3.2 Fault Diagnosis Commands

The chapter describes the commands used for fault diagnosis. All the following commands are used to detect the reason of the fault. You can use other commands to remove the fault, such as the **debug** command.

The fault diagnosis commands include:

- logging
- logging buffered
- logging console
- logging facility
- logging monitor
- logging on
- logging trap
- logging command
- logging source-interface
- logging history alerts
- logging history critical
- logging history debugging
- logging history emergencies
- logging history errors
- logging history informational
- logging history notifications
- logging history warnings

- logging history rate-limit
- logging history size
- service timestamps
- clear logging
- show break
- show debug
- show logging

### 3.2.1 logging

#### Syntax

To record the log information to the **syslog** server, use the following command.

To return to the default setting, use the no form of this command.

**logging** *A.B.C.D*

**no logging** *A.B.C.D*

#### Parameter

Parameter	Description
<i>B.C.D</i>	address of the <b>syslog</b> server
<i>vel</i>	vel of log information on the server Refer to table 1.

#### Default:

The log information is not recorded to the server.

#### Command Mode

Global configuration mode

#### Usage Guidelines

The **logging** command is used to record the log information to the designated **syslog** server. It can be used for many times to designate multiple **syslog** servers.

**Example**

logging 192.168.1.1 errors

**Related Command**

logging trap

**3.2.2 logging buffered****Syntax**

To record the log information to the memory of the switch, use the following command. To return to the default setting, use the no form of this command.

**logging buffered** [*size* | *level* | *dump* ]

**no logging buffered**

**Parameter**

Parameter	Description
<i>size</i>	Size of memory cache  Value range: 4096-2147483647  Unit: byte
<i>level</i>	Information level of the log recorded to memory cache  Refer to table 1.
<i>dump</i>	When the system has abnormality, the information in the current memory is currently recorded to the flash and the information is resumed after the system is restarted.

**Default**

The information is not recorded to the memory cache.

**Command Mode**

Global configuration mode

## Usage Guidelines

The command records the log information to the memory cache of the switch. The memory cache is circularly used. After the memory cache is fully occupied, the latter information will cover the previous information.

You can use the **show logging** command to display the log information recorded in the memory cache of the switch.

Do not use big memory for it causes the shortage of memory.

Table 1 Level of log recording

Prompt	Level	Description	Syslog Definition
emergencies		system unusable	LOG_EMERG
alerts		immediate action needed	LOG_ALERT
critical		critical conditions	LOG_CRIT
errors		error conditions	LOG_ERR
warnings		warning conditions	LOG_WARNING
notifications		normal but significant condition	LOG_NOTICE
informational		informational messages only	LOG_INFO
debugging		debugging messages	LOG_DEBUG

## Related Command

**clear logging**

**show loggin**

### 3.2.3 logging console

#### Syntax

Run the command **logging console** to control the information volume displayed on the console.

Run the command **no logging console** to forbid the log information to be displayed on the console:

**logging console *level***

**no logging console**

### Parameter

Parameter	Description
<i>level</i>	Information level of the logs displayed on the console Refer to table 2.

### Default

The log level displayed on the console port is debugging by default.

### Command Mode

Global configuration mode

### Usage Guidelines

After the information level is specified, information of this level or the lower level will be displayed on the console.

Run the command **show logging** to display the currently configured level and the statistics information recorded in the log.

Table 2 Level of log recording

Prompt	Level	Description	Syslog Definition
emergencies		system unusable	LOG_EMERG
alerts		immediate action needed	LOG_ALERT
critical		critical conditions	LOG_CRIT
errors		error conditions	LOG_ERR
warnings		warning conditions	LOG_WARNING
notifications		normal but significant condition	LOG_NOTICE
informational		informational messages only	LOG_INFO

bugging		bugging messages	LOG_DEBUG
---------	--	------------------	-----------

### Example

logging console alerts

### Related Command

**logging facility**  
**show logging**

## 3.2.4 logging facility

### Syntax

Run the command **logging facility** to configure to record specified error information. To restore to **local7**, run the command **no logging facility**.

**logging facility** *facility-type*  
**no logging facility**

### Parameter

Parameter	Description
<i>facility-type</i>	<p>ility type</p> <p>fer to table 3.</p>

### Default

local7

### Command Mode

Global configuration

### Usage Guidelines

Table 3 Facility type

Type	Description
th	thorization system

on	on facility
emon	stem daemon
rn	rn timer
cal0-7	reserved for locally defined messages
.	the printer system
ail	mail system
ws	SENET news
s9	stem use
s10	stem use
s11	stem use
s12	stem use
s13	stem use
s14	stem use
slog	stem log
er	er process
cp	VIX-to-UNIX copy system

### Example

logging facility kern

### Related Command

**logging console**

### 3.2.5 logging monitor

#### Syntax

Run the command **logging monitor** to control the information volume displayed on the terminal line.

Run the command **no logging monitor** to forbid the log information to be

displayed on the terminal line.

**logging monitor *level***

**no logging monitor**

### Parameter

Parameter	Description
<i>level</i>	Information level of the logs displayed on the terminal line Refer to table 4.

### Default

Debugging

### Command Mode

Global configuration mode

### Usage Guidelines

Table 4 Level of log recording

Prompt	Level	Description	Syslog Definition
emergencies	0	System is unusable	LOG_EMERG
alerts	1	Immediate action needed	LOG_ALERT
critical	2	Critical conditions	LOG_CRIT
errors	3	Error conditions	LOG_ERR
warnings	4	Warning conditions	LOG_WARNING
notifications	5	Normal but significant condition	LOG_NOTICE
informational	6	Informational messages only	LOG_INFO
debugging	7	Debugging messages	LOG_DEBUG

**Example**

logging monitor errors

**Related Command**

terminal monitor

### 3.2.6 logging on

**Syntax**

Run the command **logging on** to control the recording of error information.

Run the command **no logging on** to forbid all records.

**logging on**

**no logging on**

**Parameter**

None

**Default**

logging on

**Command Mode**

Global configuration mode

**Example**

```
switch_config# logging on
```

```
switch_config# ^Z
```

```
switch#
```

```
Configured from console 0 by DEFAULT
```

```
switch# ping 192.167.1.1
```

```
switch#ping 192.167.1.1
```

```
PING 192.167.1.1 (192.167.1.1): 56 data bytes
```

```
!!!!
```

--- 192.167.1.1 ping statistics ---

5 packets transmitted, 5 packets received, 0% packet loss

round-trip min/avg/max = 0/4/10 ms

switch#IP: s=192.167.1.111 (local), d=192.167.1.1 (FastEthernet0/0), g=192.167.1.1,  
len=84, sending

IP: s=192.167.1.1 (FastEthernet0/0), d=192.167.1.111 (FastEthernet0/0), len=84,rcvd

IP: s=192.167.1.111 (local), d=192.167.1.1 (FastEthernet0/0), g=192.167.1.1, len=84,  
sending

IP: s=192.167.1.1 (FastEthernet0/0), d=192.167.1.111 (FastEthernet0/0), len=84,rcvd

IP: s=192.167.1.111 (local), d=192.167.1.1 (FastEthernet0/0), g=192.167.1.1, len=84,  
sending

IP: s=192.167.1.1 (FastEthernet0/0), d=192.167.1.111 (FastEthernet0/0), len=84,rcvd

IP: s=192.167.1.111 (local), d=192.167.1.1 (FastEthernet0/0), g=192.167.1.1, len=84,  
sending

IP: s=192.167.1.1 (FastEthernet0/0), d=192.167.1.111 (FastEthernet0/0), len=84,rcvd

IP: s=192.167.1.111 (local), d=192.167.1.1 (FastEthernet0/0), g=192.167.1.1, len=84,  
sending

IP: s=192.167.1.1 (FastEthernet0/0), d=192.167.1.111 (FastEthernet0/0), len=84,rcvd

switch\_config# **no logging on**

switch\_config# ^Z

switch#

switch# **ping** 192.167.1.1

PING 192.167.1.1 (192.167.1.1): 56 data bytes

!!!!

--- 192.167.1.1 ping statistics ---

5 packets transmitted, 5 packets received, 0% packet loss

round-trip min/avg/max = 0/4/10 ms

## Related Command

logging

logging buffered

logging monitor

logging console

### 3.2.7 logging trap

#### Syntax

Run the command **logging trap** to control the information volume recorded to the syslog server.

Run the command **no logging trap** to forbid the information to be recorded to the syslog server.

**logging trap** *level*

**no logging trap**

#### Parameter

Parameter	Description
<i>level</i>	Information level of the logs displayed on the syslog server Refer to table 5.

#### Default

Informational

#### Command Mode

Global configuration mode

#### Usage Guidelines

Table 5 Level of log recording

Prompt	Level	Description	Syslog Definition
emergencies		System is unusable	LOG_EMERG
alerts		Immediate action needed	LOG_ALERT
Critical		Critical conditions	LOG_CRIT

Errors		Error conditions	LOG_ERR
Warnings		Warning conditions	LOG_WARNING
Notifications		Normal but significant condition	LOG_NOTICE
Informational		Informational messages only	LOG_INFO
Debugging		Debugging messages	LOG_DEBUG

### Example

```
logging 192.168.1.1
```

```
logging trap notifications
```

### Related Command

```
logging
```

## 3.2.8 logging command

### Syntax

To enable the command execution recording, run **logging command**. After this function is opened, a log will be generated for each of all entered commands, in which the line to execute this command, the command line, the execution result, the login line and the login address will be recorded.

You can use **no logging command** to disable this function.

### Parameter

None

### Default

```
no logging command
```

### Command Mode

Global configuration mode

### Example

```
Switch_config#logging command
Switch_config#Jul 11 15:26:56 %CMD-6-EXECUTE: `logging command ` return 0, switch(vty 0,
192.168.25.42).
```

### Related Command

logging

## 3.2.9 logging source-interface

### Syntax

This command is used to set the source port of log exchange.  
You can use **no logging source-interface** to disable this function.

### Parameter

None

### Default

no logging source-interface

### Command Mode

Global configuration mode

### Example

```
Switch_config# logging source-interface vlan 1
```

### Related Command

logging

## 3.2.10 logging history alerts

### Syntax

This command is used to set the level of the historical log table to **alerts** (need to act immediately).

**Parameter**

None

**Default**

logging history warnings

**Command Mode**

Global configuration mode

**Example**

Switch\_config#logging history alerts

**Related Command**

logging

### 3.2.11 logging history critical

**Syntax**

This command is used to set the level of the historical log table to critical.

**Parameter**

None

**Default**

logging history warnings

**Command Mode**

Global configuration mode

**Example**

Switch\_config#logging history critical

**Related Command**

logging

**3.2.12 logging history debugging****Syntax**

This command is used to set the level of the historical log table to **debugging**.

**Parameter**

None

**Default**

logging history warnings

**Command Mode**

Global configuration mode

**Example**

Switch\_config#logging history debugging

**Related Command**

logging

**3.2.13 logging history emergencies****Syntax**

This command is used to set the level of the historical log table to **emergencies** (system unavailable).

**Parameter**

None

**Default**

logging history warnings

**Command Mode**

Global configuration mode

**Example**

Switch\_config#logging history emergencies

**Related Command**

logging

### 3.2.14 logging history errors

**Syntax**

This command is used to set the level of the historical log table to **errors**.

**Parameter**

None

**Default**

logging history warnings

**Command Mode**

Global configuration mode

**Example**

Switch\_config#logging history errors

**Related Command**

logging

### 3.2.15 logging history informational

**Syntax**

This command is used to set the level of the historical log table to **informational**.

**Parameter**

None

**Default**

logging history warnings

**Command Mode**

Global configuration mode

**Example**

Switch\_config#logging history informational

**Related Command**

logging

### 3.2.16 logging history notifications

**Syntax**

This command is used to set the level of the historical log table to **notifications** (normal but important condition).

**Parameter**

None

**Default**

logging history warnings

**Command Mode**

Global configuration mode

**Example**

Switch\_config#logging history notifications

**Related Command**

logging

## 3.2.17 logging history warnings

**Syntax**

This command is used to set the level of the historical log table to **warnings**.

**Parameter**

None

**Default**

logging history warnings

**Command Mode**

Global configuration mode

**Example**

Switch\_config#logging history warnings

**Related Command**

logging

## 3.2.18 logging history rate-limit

**Syntax**

This command is used to set the log output rate.

**Parameter**

Parameter	Description
512>	ands for the number of logs which are exported each second.

**Default**

logging history rate-limit 0

**Command Mode**

Global configuration mode

**Example**

Switch\_config#logging history rate-limit 256

**Related Command**

logging

### 3.2.19 logging history size

**Syntax**

This command is used to set the number of entries in the historical log table.

**Parameter**

Parameter	Description
-500>	ands for the number of historical log entries.

**Default**

logging history size 0

**Command Mode**

Global configuration mode

**Example**

Switch\_config#logging history size 256

**Related Command**

logging

### 3.2.20 service timestamps

#### Syntax

Run the command **service timestamps** to configure the time stamp that is added when the system is debugged or records the log information.

Run the command **no service timestamps** to cancel the time stamp that is added when the system is debugged or records the log information.

**service timestamps** [log|debug] [*uptime*| *datetime*]

**no service timestamps** [log|debug]

#### Parameter

Parameter	Description
log	Displays the time stamp before the log information.
debug	Displays the time stamp before the debug information.
<i>uptime</i>	Duration between the startup of the switch and the current time
<i>datetime</i>	Real-time clock time

#### Default

Service timestamps log date

Service timestamps debug date

#### Command Mode

Global configuration mode

#### Usage Guidelines

The time stamp in the **uptime** form is displayed like HHHH:MM:SS, meaning the duration from the start-up of the switch to the current time.

The time stamp in the **date** form is displayed like YEAR-MON-DAY HH:MM:SS, meaning the real-time clock time.

**Example**

Service timestamps debug uptime

**3.2.21 clear logging****Syntax**

It is used to clear the log information recorded in the memory cache.

**clear logging**

**Parameter**

None

**Command Mode**

EXEC mode

**Related Command**

logging buffered

show logging

**3.2.22 show break****Syntax**

It is used to display the information about abnormal breakdown of the switch.

**show break**

**Parameter**

None

**Default**

None

**Command Mode**

EXEC mode

## Usage Guidelines

It is used to display the information about abnormal breakdown of the switch, helping to find the cause of the abnormality.

## Example

```
switch#show break
Exception Type:1400-Data TLB error
BreakNum: 1 s date: 2000-1-1 time: 0:34:6
r0      r1      r2      r3      r4      r5      r6
00008538-01dbc970-0054ca18-00000003-80808080-fefeff-01dbcca1-
r7      r8      r9      r10     r11     r12     r13
00000000-00009032-00000000-7ffffff0-00008588-44444444-0054c190-
r14     r15     r16     r17     r18     r19     r20
000083f4-000083f4-00000000-00000000-00000000-00000000-00000000-
r21     r22     r23     r24     r25     r26     r27
00000000-0000000a-00000001-00000000-00000000-004d6ce8-01dbd15c-
r28     r29     r30     r31     spr8     spr9     ip
00000002-00467078-00010300-00000300-00000310-00008588-00000370-
Variables :
00008538-44444444-01dbd15c-01dbcaac-00000002-00000000-004d6ce8-
01dbca18-
00008538 --- do_chram_mem_sys_addr---bspcfg.o
0001060c --- subcmd---cmdparse.o---libcmd.a
000083e4 --- do_chram_mem_sys---bspcfg.o
0000fb24 --- lookupcmd---cmdparse.o---libcmd.a
0000f05c --- cmdparse---cmdparse.o---libcmd.a
003e220c --- vty---vty.o---libvty.a
00499820 --- pSOS_qcv_broadcast---ksppc.o---os\\libsys.a
```

The whole displayed content can be divided into six parts:

1 RROR:file function.map not found

The prompt information means that the system has not been installed the software **function.map**, which does not affect the system running.

If the version of the software **function.map** is not consistent with that of the switch, the system prompts that the version is not consistent.

2 Exception Type—Abnormal hex code plus abnormal name

3 BreakNum

It is the current abnormal number. It means the number of abnormalities that the system has since it is powered on in the latest time. It is followed by the time when the abnormality occurs.

4 Content of the register

The common content of the register is listed out.

5 Variable area

The content in the stack is listed out.

6 Calling relationship of the number

If the **map** file is not installed on the system, only the function's address is displayed. If the **map** file is installed on the system, the corresponding function name, **.o** file name and **.a** file name are displayed.

The calling relationship is from bottom to top.

### 3.2.23 show debug

#### Syntax

It is used to display all the enabled debugging options of the switch.

**show debug**

#### Parameter

None

#### Command Mode

EXEC mode

**Example**

```
switch# show debug
```

Crypto Subsystem:

Crypto Ipsec debugging is on

Crypto Isakmp debugging is on

Crypto Packet debugging is on

**Related Command**

debug

**3.2.24 show logging****Syntax**

It is used to display the state of logging (syslog).

**show logging**

**Parameter**

None

**Command Mode**

EXEC mode

**Usage Guidelines**

It is used to display the state of logging (syslog), including the login information about the console, monitor and syslog.

**Example**

```
switch# show logging
```

Syslog logging: enabled (0 messages dropped, 0 flushes, 0 overruns)

Console logging: level debugging, 12 messages logged

Monitor logging: level debugging, 0 messages logged

Buffer logging: level debugging, 4 messages logged

Trap logging: level informations, 0 message lines logged

Log Buffer (4096 bytes):

2000-1-4 00:30:11 Configured from console 0 by DEFAULT

2000-1-4 00:30:28 User DEFAULT enter privilege mode from console 0, level = 15

### **Related Command**

clear logging

## Chapter 4 SSH Configuration Commands

### 4.1.1 ip sshd enable

#### Syntax

**ip sshd enable**  
**no ip sshd enable**

#### Parameter

None

#### Default

Disable

#### Usage Guidelines

It is used to generate the rsa encryption key and then monitor the connection to the ssh server. The process of generating encryption key is a process of consuming the calculation time. It takes one or two minutes.

#### Command Mode

Global configuration mode

#### Example

In the following example, the SSH service is generated.

```
device_config#ip sshd enable
```

### 4.1.2 ip sshd timeout

#### Syntax

**ip sshd timeout *time-length***  
**no ip timeout**

**Parameter**

Parameter	Description
Timeout	Maximum time from the establishment of connection to the authentication approval Value range: 60-65535

**Default**

180 seconds

**Usage Guidelines**

To prevent the illegal user from occupying the connection resources, the connections that are not approved will be shut down after the set duration is exceeded.

**Command Mode**

Global configuration mode

**Example**

In the following example, the timeout time is set to 360 seconds:

```
device_config#ip sshd timeout 360
```

**4.1.3 ip sshd auth-method****Syntax**

**ip sshd auth-method** *method*

**no sshd auth-method**

**Parameter**

Parameter	Description
Method	Authentication method list. The length of the authentication method's name is no more than 20 characters.

## Default

The **default** authentication method list is used.

## Usage Guidelines

The ssh server uses the authentication method list of the login type.

## Command Mode

Global configuration mode

## Example

In the following example, an **auth-ssh** authentication method list is configured and it is applied to the ssh server:

```
device_config#aaa authentication login auth-ssh local
```

```
device_config#ip sshd auth-method auth-ssh
```

### 4.1.4 ip sshd access-class

## Syntax

**ip sshd access-class** *access-list*

**no ip sshd access-class**

## Parameter

Parameter	Description
<i>access-list</i>	Standard IP access list. The length of the access list's name is no more than 20 characters.

## Default

No access control list

## Usage Guidelines

It is used to configure the access control list for the ssh server. Only the connections complying with the regulations in the access control list can be approved.

## Command Mode

Global configuration mode

## Example

In the following example, an **ssh-accesslist** access control list is configured and applied in the ssh server:

```
device_config# ip access-list standard ssh-accesslist
```

```
device_config_std_nacl#deny 192.168.20.40
```

```
device_config#ip sshd access-class ssh-accesslist
```

### 4.1.5 ip sshd auth-retries

## Syntax

**ip sshd auth-retries** *times*

**no ip sshd auth-retries**

## Parameter

Parameter	Description
times	Maximum re-authentication times Value range: 0-65535

## Default

6 times

## Usage Guidelines

The connection will be shut down when the re-authentication times exceeds the set times.

## Command Mode

Global configuration mode

## Example

In the following example, the maximum re-authentication times is set to five

times:

```
device_config#ip sshd auth-retries 5
```

#### 4.1.6 ip sshd clear

##### Syntax

**ip sshd clear** *ID*

##### Parameter

Parameter	Description
	Number of the SSH connection to the local device Value range: 0-65535

##### Default

None

##### Usage Guidelines

It is used to mandatorily close the incoming ssh connection with the specified number. You can run the command **show ip sshd line** to check the current incoming connection's number.

##### Command Mode

Global configuration mode

##### Example

In the following example, the No.0 incoming connection is mandatorily closed:

```
device_config#ip sshd clear 0
```

#### 4.1.7 ip sshd silence-period

##### Syntax

**ip sshd silence-period** *time-length*  
**no ip sshd silence-period**

**Parameter**

Parameter	Description
silence-length	Specifies the time of the silence, which ranges from 0 to 3600.

**Default**

60s

**Usage Guidelines**

This command is used to set the login silence period. After the accumulated login failures exceed a certain threshold, the system regards that there exist attacks and disables the SSH service in a period of time, that is, the system enters the login silence period.

The silence period is set by the **ip sshd silence-period** command. The default silence period is 60 seconds. The allowable login failures are set by the **ip sshd auth-retries** command, whose default value is 6.

**Command Mode**

Global configuration mode

**Example**

The following example shows how to set the silence period to 200 seconds.

```
switch_config#ip sshd silence-period 200
```

**4.1.8 ip sshd sftp****Syntax**

```
ip sshd sftp
no ip sshd sftp
```

**Parameter**

None

**Default**

None

**Usage Guidelines**

This command is used to enable the SFTP function. The SFTP function refers to the secure file transmission system based on SSH, of which the authentication procedure and data transmission are encrypted. Though it has low transmission efficiency, network security is highly improved.

**Command Mode**

Global configuration mode

**Example**

The following example shows how to enable the SFTP function.

```
switch_config#ip sshd sftp
```

**4.1.9 ip sshd save****Syntax**

ip sshd save

no ip sshd save

**Parameter**

None

**Default**

None

**Usage Guidelines**

This command is used to save the initial key. When the SSH server is restarted, the key will be first read from the flash; if the key reading is successful, the recalculation of key will be avoided and the startup time will be shortened.

**Command Mode**

Global configuration mode

**Example**

The following example shows how to enable the key protection function.

```
switch_config#ip sshd save
```

**4.1.10 ip sshd disable-aes****Syntax**

```
ip sshd disable-aes  
no ip sshd disable-aes
```

**Parameter**

None

**Default**

The AES encryption algorithm is forbidden.

**Usage Guidelines**

This command is used to decide whether to use the AES algorithm during the encryption algorithm negotiation. The AES algorithms such as aes128-cbc and aes256-cbc are not used by default.

**Command Mode**

Global configuration mode

**Example**

The following example shows how to disable the AES encryption algorithm.

```
switch_config#ip sshd disable-aes
```

## 4.1.11 ssh

**Syntax**

```
ssh -l userid -d destIP [-c {des|3des|blowfish}] [-o numberofpasswdprompts] [-p port] [-v {1|2}] [-s password]
```

**Parameter**

Parameter	Description
<i>userid</i>	er account on the server
<i>destl</i>	stination IP address in the dotted decimal system
<i>numberofpas swdprompts</i>	<p>-authentication times after the first authentication fails</p> <p>tual re-authentication times is the set value plus the smallest value set on the server. Its default value is three times.</p> <p>ue range: 0-65535</p>
<i>port</i>	<p>rt number that the server monitors</p> <p>default value is 22.</p> <p>ue range: 0-65535</p>
<b>{des 3des bl owfish}</b>	<p>ryption algorithm used during communication</p> <p>e encryption algorithm is 3des by default.</p>
<i>version</i>	ecified version No.
<i>password</i>	t the password

**Default**

None

**Usage Guidelines**

The command is used to create a connection with the remote ssh server.

**Command Mode**

Privileged mode

**Example**

In the following example, a connection with the ssh server whose IP address is 192.168.20.41 is created. The account is **zmz** and the encryption algorithm is **blowfish**:

```
device#ip ssh -l zmz -d 192.168.20.41 -c blowfish
```

**4.1.12 show ssh****Syntax**

**show ssh**

**Parameter**

None

**Default**

None

**Usage Guidelines**

It is used to display the sessions on the ssh server.

**Command Mode**

Privileged mode

**Example**

In the following example, the sessions on the ssh server are displayed:

```
device#show ssh
```

**4.1.13 show ip sshd****Syntax**

**show ip sshd**

**Parameter**

None

**Default**

None

**Usage Guidelines**

It is used to display the current state of the ssh server.

**Command Mode**

Privileged mode

**Example**

In the following example, the current state of the ssh server is displayed:

```
device#show ip sshd
```