



DIGISOL[®]

Basic Configuration

As our products undergo continuous development the specifications are subject to change without prior notice.

Table of Contents

Chapter1	NetworkManagementConfiguration	3
1.1	Configuring SNMP	3
1.1.1	Introduction.....	3
1.1.2	SNMP Configuration Tasks	5
1.1.3	Configuration Example	13
1.2	RMON Configuration.....	14
1.2.1	RMON Configuration Task.....	14



Chapter1 Network Management Configuration

1.1 Configuring SNMP

1.1.1 Introduction

The SNMP system includes the following parts:

- SNMP management side (NMS)
- SNMP agent (AGENT)
- Management information base (MIB)

SNMP is a protocol working on the application layer. It provides the packet format between SNMP management side and agent.

SNMP management side can be part of the network management system (NMS, like Cisco Works). Agent and MIB are stored on the system. You need to define the relationship between network management side and agent before configuring SNMP on the system.

SNMP agent contains MIB variables. SNMP management side can check or modify value of these variables. The management side can get the variable value from agent or stores the variable value to agent. The agent collects data from MIB. MIB is the database of device parameter and network data. The agent also can respond to the loading of the management side or there quest to configure data. SNMP agent can send trap to the management side. Trap sends alarm information to NMS indicating a certain condition of the network. Trap can point out improper user authentication, restart, link layer state (enable or disable), close of TCP connection, lose of the connection to adjacent systems or other important events.

1. SNMP notification

When some special events occur, the system will send 'inform' to SNMP management side. For example, when the agent system detects an abnormal condition, it will send information to the management side.

SNMP notification can be treated as trap or inform request to send. Since the receiving side doesn't send any reply when receiving a trap, this leads to the receiving side cannot be sure that the trap has been received. Therefore the trap is not reliable. In comparison, SNMP management side that receives "inform request" uses PDU that SNMP echoes as there ply



for this information. If no “inform request” is received on the management side, no echo will be sent. If the receiving side doesn’t send any reply, then you can resend the “inform request”. Then notifications can reach their destination.

Since inform requests are more reliable, they consume more resources of the system and network. The trap will be discarded when it is sent. The “inform request” has to be stored in the memory until the echo is received or their quest timeouts. In addition, the trap is sent only once, while the “inform request” can be resent for many times. Resending "inform request" adds to network communications and causes more load on network. Therefore, trap and inform request provide balance between reliability and resource. If SNMP management side needs receiving every notification greatly, then the “inform request” can be used. If you give priority to the communication amount of the network and there is no need to receive every notification, then trap can be used.

This switch only supports trap, but we provide the extension for "inform request".

2. SNMP version

System of our company supports the following SNMP versions:

- SNMPv1---simple network management protocol, a complete Internet standard, which is defined in RFC1157.
- SNMPv2C--- Group-based Management framework of SNMPv2, Internet test protocol, which is defined in RFC1901.

Layer3 switch of our company also supports the following NMP:

- SNMPv3--- a simple network management protocol version 3, which is defined inRFC3410.

SNMPv1 uses group-based security format. Use IP address access control list and password to define the management side group that can access to agent MIB.

SNMPv3 provides secure access to devices by a combination of authenticating and encrypting packets over the network.

The security features provided inSNMPv3 are:

- Message integrity — Ensuring that a packet has not been tampered with in-transit.
- Authentication — Determining the message is from a valid source.
- Encryption — Scrambling the contents of a packet prevent it from being seen by an unauthorized source.

SNMP v3 provides for both security models and security levels. A security model is an authentication strategy that is set up for a user and the group in which the user resides. A security level is the permitted level of security within a security model. A combination of a



security model and a security level will determine which security mechanism is employed when handling an SNMP packet. Three security models are available, that is, authentication and encryption, authentication and no encryption, no authentication.

You need to configure SNMP agent to the SNMP version that the management working station supports. The agent can communicate with many management sides.

3. Supported MIB

SNMP of our system supports all MIBII variables (which will be discussed in RFC 1213) and SNMP traps(which will be discussed in RFC 1215).

Our system provides its own MIB extension for each system.

1.1.2 SNMP Configuration Tasks

SNMP configuration commands include:

- Configuring SNMP view
- Creating or modifying the access control for SNMP community
- Configuring the contact method of system administrator and the system's location
- Defining the maximum length of SNMP agent data packet
- Monitoring SNMP state
- Configuring SNMP local engine
- Configuring SNMP trap
- Configuring SNMPv3 group
- Configuring SNMPv3 user
- Configuring snmp-server encryption
- Configuring snmp-server trap-source
- Configuring snmp-server trap-timeout
- Configuring snmp-server trap-add-hostname
- Configuring snmp-server trap-logs



- Configuring snmp -dos-max retry times
- Configuring keep-alive times
- Configuring snmp-server nocode
- Configuring snmp-server event-id
- Configuring snmp-server getbulk-timeout
- Configuring snmp-server getbulk-delay
- Showing snmp running information
- Showing snmp debug information

1. Configuring SNMP view

The SNMP view is to regulate the access rights(include or exclude) for MIB. Use the following command to configure the SNMP view.

Command	Purpose
<code>snmp-server view name oid [excluded included]</code>	Adds the sub tree or table of OID-specified MIB to the name of the SNMP view, and specifies the access right of the object identifier in the name of the SNMB view.

The sub sets that can be accessed in the SNMP view are there maining objects that “include” MIB objects are divided by “exclude” objects. The objects that are not configured are not accessible by default.

After configuring the SNMP view, you can implement SNMP view to the configuration of the SNMP group name, limiting the subsets of the objects that the group name can access.

2. Creating or modifying the access control for SNMP community

You can use the SNMP community character string to define the relationship between SNMP management side and agent. The community character string is similar to the password that enables the access system to log in to the agent. You can specify one or multiple properties relevant with the community character string. These properties are optional:

Allowing to use the community character string to obtain the access list of the IP address at the SNMP management side

Defining MIB views of all MIB object subsets that can access the specified community



Specifying the community with the right to read and write the accessible MIB objects

Configure the community character string in global configuration mode using the following command:

Command	Purpose
snmp-servercommunity [0 7] <i>string</i> [view <i>view-name</i>][ro rw][<i>word</i>]	Defines the group access character string.

You can configure one or multiple group character strings. Run command “no snmp-server community” to remove the specified community character string.

For how to configure the community character string, refer to the part “SNMP Commands”.

3. Configuring the contact method of system administrator and the system’s location

Sys Contact and sys Location are the management variables in the MIB’s system group, respectively defining the link man’s identifier and actual location of the controlled node. These information can be accessed through config files. You can use the following commands in global configuration mode.

Command	Purpose
snmp-servercontact <i>text</i>	Sets the character string for the link man of the node.
snmp-serverlocation <i>text</i>	Sets the character string for the node location.

4. Defining the maximum length of SNMP agent data packet

When SNMP agent receives requests or sends response, you can configure the maximum length of the data packet. Use the following command in global configuration mode:

Command	Purpose
snmp-serverpacket <i>size</i> <i>byte-count</i>	Sets the maximum length of the data packet.

5. Monitoring SNMP state

You can run the following command in global configuration mode to monitor SNMP output/input statistics, including illegal community character string items, number of mistakes and request variables.

Command	Purpose
---------	---------



show snmp	Monitor the SNMP state.
------------------	-------------------------

6. Configuring SNMP local engine

Use the following command to configure the system to send the SNMP local engine:

Command	Purpose
snmp-server engineID local engineID	Configuring SNMP local engine

7. Configuring SNMP trap

Use the following command to configure the system to send the SNMP traps (the second task is optional):

- Configuring the system to send trap

Run the following commands in global configuration mode to configure the system to send trap to a host.

Command	Purpose
snmp-server host [host v6] host community-string [trap-type]	Specifies the receiver of the trap message.
snmp-server host [host v6] host [vrf word] [udp-port port-num] [permit deny event-id] {{version [v1 v2c v3]}} {{[informs traps]} [auth noauth]} community-string/user [authentication configure snmp]	Specifies the receiver, version number and username of the trap message.

When the system is started, the SNMP agent will automatically run. All types of traps are activated. You can use the command `snmp-server host` to specify which host will receive which kind of trap.

Some traps need to be controlled through other commands. For example, if you want SNMP link traps to be sent when an interface is opened or closed, you need to run `snmp trap link-status` in interface configuration mode to activate link traps. To close the setraps, run the interface configuration command `snmp trap link-stat`.

You have to configure the command `snmp-server host` for the host to receive the traps.

- Modifying the running parameter of the trap

As an optional item, it can specify the source interface where traps originate, queue length of message or value of resending interval for each host.



To modify the running parameters of traps, you can run the following optional commands in global configuration mode.

Command	Purpose
snmp-servertrap-source <i>interface</i>	Specifies the source interface where traps originate and sets the sourceIP address for the message.
snmp-serverqueue-length <i>length</i>	Creates the queue length of the message for each host that has traps. Defaultvalue:10
snmp-servertrap-timeout <i>seconds</i>	Defines the frequency to resend traps in there sending queue. Default value:30 seconds

8. Configuring the SNMP binding source address

Run the following command in the global configuration mode to set the source address for the SNMP message.

Command	Purpose
snmpsource-addr <i>ipaddress</i>	Set the source address for the SNMP message.

9. Configuring snmp-server udp-port

Run the following command in the global mode to configure snmp-serverudp-port.

Command	Purpose
snmp-serverudp-port <i>portnum</i>	Set SNMP server udp-port number

10. Configuring SNMPv3 group

Run the following command to configure a group.

Command	Purpose
snmp-server group [<i>groupname</i> {v3[auth noauth priv]}][<i>read</i> readview][<i>write</i> writeview] [<i>notify</i> notifyview] [<i>access</i> access-list]	Configure a SNMPv3group.You can only read all items in the subtree of the Internet by default.

11. Configuring SNMPv3 user

You can run the following command to configure a local user. When an administrator logs in



to a device, he has to user the username and password that are configured on the device. The security level of a user must be higher than or equals to that of the group which the user belongs to. Otherwise, the user cannot pass authentication.

Command	Purp
snmp-server server <i>username</i> groupname {v3[encrypted auth][md5 sha] <i>auth-password</i> }	Configures a local SNMPv3 user.

12. Configuring snmp-server encryption

You can run the following command in global configuration mode to configure snmp-server encryption. Use cipher text to show SHA password and MD5 password. The command is one-off and it cannot be cancelled with command "NO".

Command	Purpose
snmp-server encryption	Use cipher text to show SHA password and MD5 password.

13. Configuring snmp-server trap-source

You can run the following command in global configuration mode to configure snmp-server trap-source. Use command "no" to delete such an interface.

Command1	Purpose
snmp-server <i>interface</i> trap-source	Any SNMP server is with a trap address no matter from which interface SNMP server sends the SNMP trap.

14. Configuring snmp-server trap-timeout

You can run the following command in global configuration mode to configure snmp-server trap-timeout.

Command	Purpose
snmp-server trap-timeout <i>seconds</i>	Before sending the trap, the switch software will find the route of the destination address. If there is no route, the trap will be saved in to the retransmission queue. The command "servertrap-timeout" determines the retransmission interval.

15. Configuring snmp-server trap-add-hostname

Run the following command to configure snmp-servertrap-add-hostname.

Command	Purpose
snmp-servertrap-add-hostname	In a specific time, the network management host needs to locate which host the trap comes from.

16. Configuring snmp-server trap-logs

Using the following command to configure snmp-server trap-logs.

Command	Purpose
snmp-servertrap-logs	Enable snmp-server trap-logs to record the forwarding record of trap as logs.

17. Configuring snmp -dos-max retry times

Set password retry times for logging in snmp in five minutes.

Command	Purpose
snmp-serverset-snmp-dos-maxretrytimes	Set password retry times for logging in snmp in five minutes.

It should be used cooperatively with snmp-server host.

18. Configuring keep-alive times

You can run the following command in global configuration mode to configure snmp-server keep-alive times.

Command	Purpose
snmp-serverkeep-alivetimes	Send keep-alive times regularly to the trap host.

19. Configuring snmp-server nencode

You can run the following command in global configuration mode to configure snmp-server encode information (This is the only tag of the device.).Use command “no” to remove the tag information.



Command	Purpose
snmp-server <i>necode</i> <i>text</i>	Corresponds to snmp private MIB variables.

20. Configuring snmp-server event-id

You can run the following command in global configuration mode to configure `snmp-server event-id`. Use Command “no” to delete the configuration.

Command	Purpose
snmp-server <i>event-id</i> <i>number</i> trap-oid <i>oid</i>	It is used in host configuration and for filtering in forwarding trap.

21. Configuring snmp-server getbulk-timeout

You can run the following command in global configuration mode to configure `snmp-server getbulk-timeout`. If it is time out, all requests from get bulk will not be deal with. Use command “no” to delete the configuration.

Command	Purpose
snmp-server <i>getbulk-timeout</i> <i>seconds</i>	Set get bulk-timeout. If it is time out, all requests from get bulk will not be deal with.

22. Configuring snmp-server getbulk-delay

You can run the following command in global configuration mode to configure `snmp-server getbulk-delay`. Unit is centisecond. Use the no form of the command to delete.

Command	Purpose
snmp-server <i>getbulk-delay</i> <i>ticks</i>	To avoid snmp occupies excessive CPU, sets <code>snmp-server getbulk-delay ticks</code> . Unit: centisecond.

23. Showing snmp running information

Use the `show snmp` command to monitor SNMP input and output statistics, including illegal community string entries, errors, and the number of request variables. Use the `show snmp engineID` command to display SNMP engine information. Use the `show snmp host` command to display SNMP trap host information. Use the `show snmp view` command to display SNMP view information. Use the `show snmp mibs` command to display mib registration information. Use the `show snmp group` command to display SNMP group information. Use the `show snmp user` command to display SNMP user information.

Command	Purpose
show snmpengineID	Show SNMP trap local engine information.
show snmphost	Show SNMP trap host information.
show snmpview	Show snmp view information.
show snmpmibs	Show snmp mibs registration information.
show snmpgroup	Show snmp group information
show snmpuser	Show snmp user information.

24. Showing snmp debug information

Showing information about SNMP error, snmp event and snmp packet.

Command	Purpose
debugsnmperror	Enable the debug switch of SNMP error.
debugsnmpevent	Enable the debug switch of snmp event.
debugsnmppacket	Enable the debug switch of snmp packet

1.1.3 Configuration Example

1. Example 1

```
snmp-server community public RO
snmp-server community private RW
snmp-server host 192.168.10.2 public
```

The above example shows:

How to set the community string public that can only read all MIB variables. How to set the community string private that can read and write all MIB variables. The above command specifies the community string public to send traps to 192.168.10.2 when a system requires to send traps. For example, when a port of a system is in the down state, the system will send a link down trap information to 192.168.10.2.

2. Example 2

```
snmp-server group getter v3auth
snmp-server group setter v3priv write v-write
```



```
snmp-server user get-user getter v3authsha 12345678
```

```
snmp-server user set-user setter v3 encrypted authmd5 12345678
```

```
snmp-server view v-write internet included
```

The above example shows how to use SNMPv3 to manage devices. Group **getter** can browse device information, while group **setter** can set devices. User **get-user** belongs to group **getter** while user **set-user** belongs to group **setter**. For user **get-user**, its security level is authenticate but not encrypt, its password is 12345678, and it uses the **sha** arithmetic to summarize the password. For user **set-user**, its security level is authenticate and encrypt, its password is 12345678, and it uses the **md5** arithmetic to summarize the password.

1.2 RMON Configuration

1.2.1 RMON Configuration Task

RMON configuration tasks include:

- Configuring the rMon alarm function for the switch
- Configuring the rMon event function for the switch
- Configuring the rMon statistics function for the switch
- Configuring the rMon history function for the switch
- Displaying the rMon configuration of the switch

1. Configuring rMon alarm for switch

You can configure the rMon alarm function through the command line or SNMPNMS. If you configure through SNMPNMS, you need to configure the SNMP of the switch. After the alarm function is configured, the device can monitor some statistic value in the system. The following table shows how to set the rMon alarm function:

Command	Purpose
config	Enter the global configuration mode.
rmon alarm index variable interv al { absolute delta } rising-	Add an rMon alarm item. index is the index of the alarm item. Its effective range is from 1 to 65535. variable is the object in the monitored MIB. It must be an effective MIB object in the system. Only objects in the Integer, Counter, Gauge or Time Ticks type can be detected.



thresholdvalue [eventnumber] falling- thresholdvalue [eventnumber] [ownerstring][repeat] at]	interval is the time section for sampling. Its unit is second. Its effective value is from 1 to 2147483647. absolute is used to directly monitor the value of MIB object. Delta is used to monitor the value change of the MIB objects between two samplings. value is the threshold value when an alarm is generated. Event number is the index of an event that is generated when a threshold is reached. Event number is optional. Owner string is to describe the information about the alarm. Repeat is to repeat trigger event.
exit	Enter the management mode again.
write	Save the configuration.

After a rMon alarm item is configured, the device will obtain the value of variable-specified oid after an interval. The obtained value will be compared with the previous value according to the alarm type (absolute or delta). If the obtained value is bigger than the previous value and surpasses the threshold value specified by rising-threshold, an event whose index is event number (If the value of event number is 0 or the event whose index is event number does not exist in the event table, the event will not occur). If the variable-specified oid cannot be obtained, the state of the alarm item in this line is set to invalid. If you run rmon alarm many times to configure alarm items with the same index, only the last configuration is effective. You can run rmon alarm index to cancel alarm items whose indexes are index.

2. Configuring rMon event for switch

The steps to configure the rMon event are shown in the following table:

Step	Command	Purpose
1.	config	Enter the global configuration mode.
2.	rmon event index [description string] [log] [ownerstring] [trap community] [ifctrl interface]	Add a rMon event item. index means the index of the event item. Its effective range is from 1 to 65535. description means the information about the event. log means to add a piece of information to the log table when an event is triggered. trap means a trap message is generated when the event is triggered. community means the name of a community. if ctrl interface is the interface controlling event shut down. owner string is to describe the information about the alarm.
3.	exit	Enter the management mode again.
4.	write	Save the configuration.

After a rMon event is configured, you must set the domain event Last Time Sent of the rMon



event item to sys Up Time when a rMon alarm is triggered. If the log attribute is set to the rMon event, a message is added to the log table. If the trap attribute is set to the rMon event, a trap message is sent out in name of community. If your unmon event many times to configure event items with the same index, only the last configuration is effective. You can run normon event index to cancel event items whose indexes are index.

3. Configuring rMon statistics for switch

The rMon statistics group is used to monitor the statistics information on every port of the device.

The steps to configure the rMon statistics are as follows:

Step	Command	Purpose
1.	config	Enter the global configuration mode.
2.	interfaceiftypeifid	Enter the port mode. if type means the type of the port. if id means the ID of the interface.
3.	rmon collection stats index [ownerstring]	Enable the statistics function on the port. index means the index of the statistics. owner string is to describe the information about the statistics.
4.	exit	Enter the global office mode.
5.	exit	Enter the management mode again.
6.	write	Save the configuration.

If your unman collection stat many times to configure statistics items with the same index, only the last configuration is effective. You can run no rmon collection stats index to cancel statistics items whose indexes are index.

4. Configuring rMon history for switch

The rMon history group is used to collect statistics information of different time sections on a port in a device. The rMon statistics function is configured as follows:

Step	Command	Purpose
------	---------	---------



1.	config	Enter the global configuration command.
2.	interfaceiftypeifid	Enter the port mode. if type means the type of the port. if id means the ID of the interface.
3.	rmon collection historyindex[buckets bucket-number] [intervalsecond] [ownerowner-name]	Enable the history function on the port. index means the index of the history item. Among all data collected by history item, the latest bucket-number items need to be saved. You can browse the history item of the Ethernet to abstain these statistics values. The default value is 50 items. second means the interval to abstain the statistics data every other time. The default value is 1800 seconds. owner string is used to describe some information about the history item.
4.	exit	Enter the global office mode again.
5.	exit	Enter the management mode again.
6.	write	Save the configuration.

After a rMon history item is added, the device will obtain statistics values from the specified port every second seconds. The statistics value will be added to the history item as a piece of information. If your unman collection history index many times to configure history items with the same index, only the last configuration is effective. You can run no rmon history index to cancel history items whose indexes are index.

Note:

Too much system sources will be occupied in the case the value of bucket-number is too big or the value of interval second is too small.



5. Displaying rMon configuration of switch

Run show to display the rMon configuration of the switch.

Command	Purpose
showrmon[alarm][event][statistics][history]	Displays the rmon configuration information. alarm means to display the configuration of the alarm item. event means to show the configuration of the event item and to show the items that are regenerated by the occurrence of events and are contained in the log table. statistics means to display the configuration of the statistics item and statistics values that the device collects from the port. history means to display the configuration of the history item and statistics values that the device collects in the latest specified intervals from the port.

